# SECTION ENGINE CONTROL SYSTEM C

## CONTENTS

MODIFICATION NOTICE	
Major Modification Item	
ENGINE CONTROL SYSTEM	6
System Diagram	
ON BOARD DIAGNOSTIC (OBD) SYSTEM	
Introduction	
Two Trip Detection Logic	
Emission-related Diagnostic Information	
TROUBLE DIAGNOSIS	
Trouble Diagnosis Introduction	
DTC Inspection Priority Chart	
Fail-Safe Chart	
Basic Inspection	
Symptom Matrix Chart	
Engine Control Component Parts Location	
Vacuum Hose Drawing	
Circuit Diagram	36
ECM Harness Connector Terminal Layout	
ECM Terminals and Reference Value	
CONSULT-II Reference Value in Data Monitor	48
Major Sensor Reference Graph in Data Monitor	
Mode	
<b>TROUBLE DIAGNOSIS - SPECIFICATION VALUE</b>	
Description	
Testing Condition	
Inspection Procedure	
Diagnostic Procedure	
TROUBLE DIAGNOSIS FOR INTERMITTENT INCI-	
DENT	
Description	
Diagnostic Procedure	
POWER SUPPLY AND GROUND CIRCUIT	
Wiring Diagram	
Diagnostic Procedure	
Ground Inspection	72
DTC U1000, U1001 CAN COMMUNICATION LINE	
Description	
On Board Diagnosis Logic	
DTC Confirmation Procedure	
Wiring Diagram	74

DTC P0011, P0021 IVT CONTROL	75	F
Description	75	
CONSULT-II Reference Value in Data Monitor M	lode	
		G
On Board Diagnosis Logic	76	
DTC Confirmation Procedure	76	
Overall Function Check		Н
DTC P0102, P0103 MAF SENSOR	78	
Component Description		
CONSULT-II Reference Value in Data Monitor M	lode	r.
	. 70	l
On Board Diagnosis Logic		
DTC Confirmation Procedure		
Wiring Diagram		J
DTC P0117, P0118 ECT SENSOR	82	
Component Description		
On Board Diagnosis Logic		K
DTC Confirmation Procedure		
Wiring Diagram		
DTC P0122, P0123 TP SENSOR		L
Component Description	84	
CONSULT-II Reference Value in Data Monitor M		
	. 84	
On Board Diagnosis Logic		VI
DTC Confirmation Procedure		
Wiring Diagram		
DTC P0138, P0158 HO2S2		
Component Description		
CONSULT-II Reference Value in Data Monitor M		
	. 87	
On Board Diagnosis Logic	87	
DTC Confirmation Procedure	88	
Wiring Diagram		
DTC P0222, P0223 TP SENSOR		
Component Description		
CONSULT-II Reference Value in Data Monitor M	ode	
	. 91	
On Board Diagnosis Logic	91	
DTC Confirmation Procedure		
Wiring Diagram	93	



D

Е

DTC P0327, P0328 KS	94
Component Description	
On Board Diagnosis Logic	
DTC Confirmation Procedure	
Wiring Diagram	95
DTC P0335 CKP SENSOR (POS)	96
Component Description	
CONSULT-II Reference Value in Data Monitor M	
CONSOLT-ITREFERCE VALUEITDAIAMONILOIN	
	. 96
On Board Diagnosis Logic	96
DTC Confirmation Procedure	97
Wiring Diagram	
DTC P0340, P0345 CMP SENSOR (PHASE) .	
Component Description	99
On Board Diagnosis Logic	99
DTC Confirmation Procedure	
Wiring Diagram	
DTC P0550 PSP SENSOR	
Component Description	103
CONSULT-II Reference Value in Data Monitor N	lode
	. 103
On Reard Diagnosia Lagia	
On Board Diagnosis Logic	
DTC Confirmation Procedure	
Wiring Diagram	105
DTC P0605 ECM	106
Component Description	
On Board Diagnosis Logic	
DTC Confirmation Procedure	
DTC P1031, P1032, P1051, P1052 A/F SENSC	
DTC P1031, P1032, P1051, P1052 A/F SENSO	R 1
DTC P1031, P1032, P1051, P1052 A/F SENSC HEATER	0R 1 108
DTC P1031, P1032, P1051, P1052 A/F SENSO HEATER Description	<b>PR 1</b> <b>108</b> 108
DTC P1031, P1032, P1051, P1052 A/F SENSC HEATER	<b>PR 1</b> <b>108</b> 108 lode
DTC P1031, P1032, P1051, P1052 A/F SENSO HEATER Description CONSULT-II Reference Value in Data Monitor M	<b>PR 1</b> <b>108</b> 108 lode 
DTC P1031, P1032, P1051, P1052 A/F SENSO HEATER Description CONSULT-II Reference Value in Data Monitor M On Board Diagnosis Logic	<b>PR 1</b> <b> 108</b> lode . 108 
DTC P1031, P1032, P1051, P1052 A/F SENSO HEATER Description CONSULT-II Reference Value in Data Monitor M On Board Diagnosis Logic	<b>PR 1</b> <b> 108</b> lode . 108 
DTC P1031, P1032, P1051, P1052 A/F SENSO HEATER Description CONSULT-II Reference Value in Data Monitor M On Board Diagnosis Logic DTC Confirmation Procedure	<b>PR 1</b> <b> 108</b> lode 108 108 108
DTC P1031, P1032, P1051, P1052 A/F SENSO HEATER Description CONSULT-II Reference Value in Data Monitor M On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram	<b>PR 1</b> <b>108</b> 108 108 108 108 108 108
DTC P1031, P1032, P1051, P1052 A/F SENSO HEATER Description CONSULT-IIReference Value in Data Monitor M On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram DTC P1065 ECM POWER SUPPLY	<b>PR 1</b> <b>108</b> 108 108 108 108 108 108 108 108
DTC P1031, P1032, P1051, P1052 A/F SENSO HEATER Description CONSULT-II Reference Value in Data Monitor M On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram DTC P1065 ECM POWER SUPPLY Component Description	<b>PR 1</b> <b>108</b> 108 108 108 108 108 108 108 110 <b>112</b> 112
DTC P1031, P1032, P1051, P1052 A/F SENSO HEATER Description CONSULT-II Reference Value in Data Monitor M On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram DTC P1065 ECM POWER SUPPLY Component Description On Board Diagnosis Logic	<b>108</b> 108         108         Iode         108
DTC P1031, P1032, P1051, P1052 A/F SENSO HEATER Description CONSULT-II Reference Value in Data Monitor M On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram DTC P1065 ECM POWER SUPPLY Component Description	<b>108</b> 108         108         Iode         108
DTC P1031, P1032, P1051, P1052 A/F SENSO HEATER Description CONSULT-II Reference Value in Data Monitor M On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram DTC P1065 ECM POWER SUPPLY Component Description On Board Diagnosis Logic	IR 1         108         108         Iode         108         Iode         108         108         108         108         110         110         112         112         112         112         112         112         112
DTC P1031, P1032, P1051, P1052 A/F SENSO HEATER Description CONSULT-II Reference Value in Data Monitor M On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram DTC P1065 ECM POWER SUPPLY Component Description On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram	<b>IR 1 108</b> 108         lode         .108         .108         .108         .108         .108         .108         .108         .108         .108         .108         .110         .112         .112         .112         .112         .112         .112         .112         .112         .113
DTC P1031, P1032, P1051, P1052 A/F SENSO HEATER Description CONSULT-IIReference Value in Data Monitor M On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram DTC P1065 ECM POWER SUPPLY Component Description On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram DTC P1111, P1136 IVT CONTROL SOLENOID	<b>IOR 1 108</b> 100         108         Iode         108         108         108         108         108         110         112         112         112         112         112         113
DTC P1031, P1032, P1051, P1052 A/F SENSO HEATER Description CONSULT-IIReference Value in Data Monitor M On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram DTC P1065 ECM POWER SUPPLY Component Description On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram DTC P1111, P1136 IVT CONTROL SOLENOID VALVE	<b>IOR 1 108</b> Iode         . 108         Iode         . 108         . 108         . 108         . 108         . 108         . 108         . 108         . 108         . 108         . 108         108
DTC P1031, P1032, P1051, P1052 A/F SENSO HEATER Description CONSULT-II Reference Value in Data Monitor M On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram DTC P1065 ECM POWER SUPPLY Component Description On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram DTC P1111, P1136 IVT CONTROL SOLENOID VALVE Component Description	<b>IR 1 108</b> 100         108         Iode         108         108         108         108         108         108         108         110         1112         112         112         112         112         113         114
DTC P1031, P1032, P1051, P1052 A/F SENSO HEATER Description CONSULT-IIReference Value in Data Monitor M On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram DTC P1065 ECM POWER SUPPLY Component Description On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram DTC P1111, P1136 IVT CONTROL SOLENOID VALVE	<b>IR 1 108</b> 100         108         Iode         108         108         108         108         108         108         108         110         1112         112         112         112         112         113         114
DTC P1031, P1032, P1051, P1052 A/F SENSO HEATER Description CONSULT-II Reference Value in Data Monitor M On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram DTC P1065 ECM POWER SUPPLY Component Description On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram DTC P1111, P1136 IVT CONTROL SOLENOID VALVE Component Description	<b>IR 1 108</b> 100         108         Iode         108         108         108         108         108         108         108         110         1112         112         112         112         112         113         114
DTC P1031, P1032, P1051, P1052 A/F SENSO HEATER Description CONSULT-II Reference Value in Data Monitor M On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram DTC P1065 ECM POWER SUPPLY Component Description On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram DTC P1111, P1136 IVT CONTROL SOLENOID VALVE Component Description CONSULT-II Reference Value in Data Monitor M	<b>IR 1 108</b> 100         108         Iode         108         108         108         108         108         108         108         110         112         112         112         112         112         113         114         Iode         114
DTC P1031, P1032, P1051, P1052 A/F SENSO HEATER Description CONSULT-II Reference Value in Data Monitor M On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram DTC P1065 ECM POWER SUPPLY Component Description On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram DTC P1111, P1136 IVT CONTROL SOLENOID VALVE Component Description CONSULT-II Reference Value in Data Monitor M On Board Diagnosis Logic	<b>IR 1 108</b> 100         108         Iode         108         108         108         108         108         108         108         110         112         112         112         112         112         112         113         114         Iode         114         Iode         114
DTC P1031, P1032, P1051, P1052 A/F SENSO HEATER Description CONSULT-II Reference Value in Data Monitor M On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram DTC P1065 ECM POWER SUPPLY Component Description On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram DTC P1111, P1136 IVT CONTROL SOLENOID VALVE Component Description CONSULT-II Reference Value in Data Monitor M On Board Diagnosis Logic DTC Confirmation Procedure	<b>IR 1 108</b> 108         lode         108         108         108         108         108         108         110         112         112         112         112         112         113 <b>114</b> lode         114         lode         114
DTC P1031, P1032, P1051, P1052 A/F SENSO HEATER Description CONSULT-II Reference Value in Data Monitor M On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram DTC P1065 ECM POWER SUPPLY Component Description On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram DTC P1111, P1136 IVT CONTROL SOLENOID VALVE Component Description CONSULT-II Reference Value in Data Monitor M On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram	<b>IR 1 108</b> 108         lode         108         108         108         108         108         108         108         110         112         112         112         112         112         113 <b>114</b> lode         114         lode         114         lode         114         lode         114         lode         114
DTC P1031, P1032, P1051, P1052 A/F SENSO HEATER Description CONSULT-II Reference Value in Data Monitor M On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram DTC P1065 ECM POWER SUPPLY Component Description On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram DTC P1111, P1136 IVT CONTROL SOLENOID VALVE Component Description CONSULT-II Reference Value in Data Monitor M On Board Diagnosis Logic DTC Confirmation Procedure	<b>IR 1 108</b> 108         lode         108         108         108         108         108         108         108         110         112         112         112         112         112         113 <b>114</b> lode         114         lode         114         lode         114         lode         114         lode         114
DTC P1031, P1032, P1051, P1052 A/F SENSO HEATER Description CONSULT-II Reference Value in Data Monitor M On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram DTC P1065 ECM POWER SUPPLY Component Description On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram DTC P1111, P1136 IVT CONTROL SOLENOID VALVE Component Description CONSULT-II Reference Value in Data Monitor M On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram DTC P1121 ELECTRIC THROTTLE CONTROL	<b>IOR 1</b> 108         108         Iode         108         Iode         108         108         108         108         108         108         110         112         112         112         112         112         112         112         112         112         113         0         114         Iode         Iode </td
DTC P1031, P1032, P1051, P1052 A/F SENSO HEATER Description CONSULT-II Reference Value in Data Monitor M On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram DTC P1065 ECM POWER SUPPLY Component Description On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram DTC P1111, P1136 IVT CONTROL SOLENOID VALVE Component Description CONSULT-II Reference Value in Data Monitor M On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram DTC P1121 ELECTRIC THROTTLE CONTROL	<b>IR 1 108</b> Iode         108         Iode         108         Iode         108         108         108         108         108         110         112         112         112         112         112         112         112         112         112         112         113         Iode         114         Iode         Iode         Iode         Iode         Iode         Iode         Iode         Iode         Iode
DTC P1031, P1032, P1051, P1052 A/F SENSO HEATER Description CONSULT-II Reference Value in Data Monitor M On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram DTC P1065 ECM POWER SUPPLY Component Description On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram DTC P1111, P1136 IVT CONTROL SOLENOID VALVE Component Description CONSULT-II Reference Value in Data Monitor M On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram DTC P1121 ELECTRIC THROTTLE CONTROL ACTUATOR Component Description	<b>IR 1 108</b> 108         lode         108         108         108         108         108         108         108         110         112         112         112         112         112         112         112         112         112         112         112         113 <b>114</b> Iode         114         Iode         114         Iode         114         Iode         114         Iode         114         Inta         114         Inta         114         Inta
DTC P1031, P1032, P1051, P1052 A/F SENSO HEATER Description CONSULT-II Reference Value in Data Monitor M On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram DTC P1065 ECM POWER SUPPLY Component Description On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram DTC P1111, P1136 IVT CONTROL SOLENOID VALVE Component Description CONSULT-II Reference Value in Data Monitor M On Board Diagnosis Logic DTC Confirmation Procedure Wiring Diagram DTC P1121 ELECTRIC THROTTLE CONTROL	<b>IR 1 108</b> Iode         108         Iode         108         Iode         108         108         108         108         108         108         108         108         108         110         112         112         112         112         112         112         113 <b>114</b> Iode         114         Io         III         III         III         III         III         III         IIII         IIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIII

FUNCTION       120         Description       120         On Board Diagnosis Logic       120         DTC Confirmation Procedure       120         Wiring Diagram       121         DTC P1124, P1126 THROTTLE CONTROL MOTOR       122         Component Description       122         CONSULT-II Reference Value in Data Monitor Mode       122         DTC Confirmation Procedure       122         DTC Confirmation Procedure       122         DTC Confirmation Procedure       125         On Board Diagnosis Logic       125         On Board Diagnosis Logic       125         On Board Diagnosis Logic       127         DEC P1214 TCS CONTROL UNIT       127         Description       127         DTC Confirmation Procedure       128         DTC P1212 TCS COMMUNICATION LINE       128         DTC P1212 TCS COMMUNICATION LINE       128         DTC Confirmation Procedure       128         DTC Confirmation Procedure       128         DTC P1217 ENGINE OVER TEMPERATURE       129         Description       129         CONSULT-II Reference Value in Data Monitor Mode       130         On Board Diagnosis Logic       131         Overall Function Check	DTC P1122 ELECTRIC THROTTLE CONTROL	A
On Board Diagnosis Logic       120         DTC Confirmation Procedure       120         Wiring Diagram       121         DTCP1124, P1126 THROTTLE CONTROL MOTOR       122         Component Description       122         CON SULT-II Reference Value in Data Monitor Mode       122         DTC P1128 THROTTLE CONTROL MOTOR       122         DTC Confirmation Procedure       122         DTC P1128 THROTTLE CONTROL MOTOR       125         Com Board Diagnosis Logic       125         On Board Diagnosis Logic       125         On Board Diagnosis Logic       125         On Board Diagnosis Logic       127         DTC P1128 THROTTLE CONTROL UNIT       127         Description       127         DTC P1211 TCS CONTROL UNIT       127         DE C P1211 TCS COMMUNICATION LINE       128         DTC P1212 TC SC OMMUNICATION LINE       128         DTC Confirmation Procedure       128         DTC P1217 ENGINE OVER TEMPERATURE       129         Description       129         CONSULT-II Reference Value in Data Monitor Mode       130         On Board Diagnosis Logic       131         Wiring Diagram       135         DTC P1217 ENGINE OVER TEMPERATURE       129		
DTC Confirmation Procedure       120         Wiring Diagram       121         DTC P1124, P1126 THROTTLE CONTROL MOTOR       122         Component Description       122         CONSULT-IIReference Value in Data Monitor Mode       122         DTC Confirmation Procedure       122         DTC Confirmation Procedure       122         Wiring Diagram       124         DTC P1128 THROTTLE CONTROL MOTOR       125         On Board Diagnosis Logic       125         On Board Diagnosis Logic       125         On Board Diagnosis Logic       125         DTC Confirmation Procedure       126         DTC P1211 TCS CONTROL UNIT       127         Description       127         DTC Confirmation Procedure       128         DTC P1212 TCS COMMUNICATION LINE       128         DTC P1212 TCS COMMUNICATION LINE       128         DTC Confirmation Procedure       129         DCONSULT-II REGINE OVER TEMPERATURE       129         Description       129         CONSULT-II Reference Value in Data Monitor Mode       130         On Board Diagnosis Logic       131         Overall Function Check       131         Wiring Diagram       136         DTC P1225 TP SENS		
Wiring Diagram121DTC P1124, P1126 THROTTLE CONTROL MOTORRELAYRELAY122Component Description122CONSULT-II Reference Value in Data Monitor Mode122On Board Diagnosis Logic122DTC Confirmation Procedure122Wiring Diagram124EEDTC P1128 THROTTLE CONTROL MOTOR125Component Description125On Board Diagnosis Logic125DTC Confirmation Procedure125Wiring Diagram126DTC P1211 TCS CONTROL UNIT127Description127DTC Confirmation Procedure127DTC Confirmation Procedure128DTC Confirmation Procedure128DTC Confirmation Procedure128DTC Confirmation Procedure128DTC Confirmation Procedure128DTC P1212 TCS COMMUNICATION LINE128DTC P1217 ENGINE OVER TEMPERATURE129Description130On Board Diagnosis Logic131Overall Function Check131Overall Function Check131Wiring Diagram135DTC P1225 TP SENSOR136DTC Confirmation Procedure137On Board Diagnosis Logic138On Board Diagnosis Logic137DTC Confirmation Procedure137DTC Confirmation Procedure137DTC Confirmation Procedure138On Board Diagnosis Logic138On Board Diagnosis Logic138On Board Dia	On Board Diagnosis Logic	.120 EC
DTC P1124, P1126 THROTTLE CONTROL MOTORI22RELAY122Component Description122CONSULT-II Reference Value in Data Monitor Mode122DTC Confirmation Procedure122DTC P1128 THROTTLE CONTROL MOTOR125Component Description125On Board Diagnosis Logic125DTC P1128 THROTTLE CONTROL MOTOR125On Board Diagnosis Logic125DTC Confirmation Procedure126DTC P1211 TCS CONTROL UNIT127Description127DTC Confirmation Procedure127DTC P1211 TCS COMMUNICATION LINE128DTC P1212 TCS COMMUNICATION LINE128DTC P1212 TCS COMMUNICATION LINE128DTC P1217 ENGINE OVER TEMPERATURE129Description129CONSULT-II Reference Value in Data Monitor Mode130On Board Diagnosis Logic131Overall Function Check131Wiring Diagram135DTC P1225 TP SENSOR136DTC Confirmation Procedure136DTC Confirmation Procedure137On Board Diagnosis Logic136DTC P1225 TP SENSOR136DTC Confirmation Procedure137DTC Confirmation Procedure138On Board Diagnosis Logic138DTC Confirmation Procedure137DTC Confirmation Procedure138DTC Confirmation Procedure138DTC Confirmation Procedure138DTC Confirmation Procedure138On Board Diagnosis Logi		
RELAY122CComponent Description122CONSULT-II Reference Value in Data Monitor Mode122DOn Board Diagnosis Logic122DTC Confirmation Procedure122Wiring Diagram124EEDTC P1128 THROTTLE CONTROL MOTOR125Component Description125DT C Confirmation Procedure125DTC Confirmation Procedure125DTC P1211 TCS CONTROL UNIT127Description127DTC P1211 TCS CONTROL UNIT127DTC Confirmation Procedure127DTC Confirmation Procedure127DTC P1212 TCS COMMUNICATION LINE128DTC P1217 ENGINE OVER TEMPERATURE129Description129CONSULT-II Reference Value in Data Monitor Mode130On Board Diagnosis Logic131Overall Function Check131Wiring Diagram133Main 12 Causes of Overheating136DTC P1225 TP SENSOR136DTC P1226 TP SENSOR137DTC Confirmation Procedure138On Board Diagnosis Logic137DTC P1226 TP SENSOR137DTC Confirmation Procedure138DTC Confirmation Procedure138DTC Confirmation Procedure138DTC P1226 TP SENSOR137DTC Confirmation Procedure138DTC Confirmation Procedure138DTC Confirmation Procedure138DTC Confirmation Procedure138DTC Confirmati		. 121
Component Description         122           CONSULT-II Reference Value in Data Monitor Mode         122           On Board Diagnosis Logic         122           DTC Confirmation Procedure         122           Wiring Diagram         124           E         DTC P1128 THROTTLE CONTROL MOTOR         125           Component Description         125           On Board Diagnosis Logic         125           DTC Confirmation Procedure         125           Wiring Diagram         126           DTC P1211 TCS CONTROL UNIT         127           Description         127           DTC Confirmation Procedure         127           DTC Confirmation Procedure         127           DTC P1212 TCS COMMUNICATION LINE         128           DTC P1212 TCS COMMUNICATION LINE         128           DTC Confirmation Procedure         128           DTC Confirmation Procedure         129           DC CONSULT-II Reference Value in Data Monitor Mode         130           On Board Diagnosis Logic         131           Overall Function Check         131           Wiring Diagram         136           CONSULT-II Reference Value in Data Monitor Mode         130           On Board Diagnosis Logic         136 <td>DICP1124, P1126 IHROTILE CONTROL MOTOR</td> <td>(100 C</td>	DICP1124, P1126 IHROTILE CONTROL MOTOR	(100 C
CONSULT-II Reference Value in Data Monitor Mode       122       D         On Board Diagnosis Logic       122       D         DTC Confirmation Procedure       122         Wiring Diagram       124         DTC P1128 THROTTLE CONTROL MOTOR       125         Component Description       125         DTC Confirmation Procedure       125         DTC Confirmation Procedure       125         DTC P1211 TCS CONTROL UNIT       127         Description       127         DTC Confirmation Procedure       127         DTC Confirmation Procedure       127         DTC Confirmation Procedure       128         DTC Confirmation Procedure       129         CONSULT-II Reference Value in Data Monitor Mode       130         On Board Diagnosis Logic       131         Overall Function Check       131         Wiring Diagram       136         CONSULT-II Reference Value in Data Monitor Mode       136         DTC P1225 TP SENSOR       136         Component Description       136     <		
.122       D         On Board Diagnosis Logic       .122         DTC Confirmation Procedure       .122         Wiring Diagram       .124         DTC P1128 THROTTLE CONTROL MOTOR       .125         Component Description       .125         DTC Confirmation Procedure       .125         DTC Confirmation Procedure       .125         DTC P1211 TCS CONTROL UNIT       .127         DEC P1211 TCS CONTROL UNIT       .127         DTC Confirmation Procedure       .127         DTC Confirmation Procedure       .127         DTC P1212 TCS COMMUNICATION LINE       .128         On Board Diagnosis Logic       .128         On Board Diagnosis Logic       .128         DTC P1217 ENGINE OVER TEMPERATURE       .129         Description       .129         CONSULT-II Reference Value in Data Monitor Mode       .130         On Board Diagnosis Logic       .131         Overall Function Check       .131         Wiring Diagram       .133         Minin 12 Causes of Overheating       .135         DTC P1225 TP SENSOR       .136         DTC P1225 TP SENSOR       .137         On Board Diagnosis Logic       .138         DTC Confirmation Procedure       .		
On Board Diagnosis Logic       122         DTC Confirmation Procedure       122         Wiring Diagram       124         DTC P1128 THROTTLE CONTROL MOTOR       125         Component Description       125         On Board Diagnosis Logic       125         DTC Confirmation Procedure       125         Wiring Diagram       126         DTC P1211 TCS CONTROL UNIT       127         Description       127         DTC Confirmation Procedure       127         DTC Confirmation Procedure       127         DTC Confirmation Procedure       128         DTC CONSULT-IReference Value in Data Monitor Mode       130         On Board Diagnosis Logic       131         Overall Function Check       131         Wiring Diagram       133         K       Main 12 Causes of Overheating       135         DTC P1225 TP SENSOR       136         On Board Diagnosis Logic       137         DTC Confirmation Procedure       137         DTC Confirmation Procedure <td< td=""><td></td><td></td></td<>		
DTC Confirmation Procedure122Wiring Diagram124PTC P1128 THROTTLE CONTROL MOTOR125Component Description125On Board Diagnosis Logic125DTC Confirmation Procedure126DTC P1211 TCS CONTROL UNIT127Description127Description127DTC Confirmation Procedure127DTC Confirmation Procedure127DTC Confirmation Procedure128DTC P1212 TCS COMMUNICATION LINE128DTC Confirmation Procedure128DTC Confirmation Procedure128DTC Confirmation Procedure129DC CONSULT-II Reference Value in Data Monitor Mode130On Board Diagnosis Logic131Overall Function Check131Wiring Diagram135DTC P1225 TP SENSOR136Component Description136DTC Confirmation Procedure137Main 12 Causes of Overheating135DTC P1225 TP SENSOR136DTC Confirmation Procedure137DTC Confirmation Procedure137DTC Confirmation Procedure137DTC Confirmation Procedure138DTC Confirmation Procedure140CONSULT-II Reference Value in Data Monitor Mode		
Wiring Diagram         124         E           DTC P1128 THROTTLE CONTROL MOTOR         125           Component Description         125           On Board Diagnosis Logic         125           DTC Confirmation Procedure         125           DTC P1211 TCS CONTROL UNIT         127           Description         127           Drscription         127           DTC Confirmation Procedure         127           DTC Confirmation Procedure         127           DTC Confirmation Procedure         128           DTC Confirmation Procedure         128           DTC Confirmation Procedure         128           DTC Confirmation Procedure         128           DTC P1217 ENGINE OVER TEMPERATURE         129           Description         129           CONSULT-II Reference Value in Data Monitor Mode         130           On Board Diagnosis Logic         131           Overall Function Check         131           Wiring Diagram         136           DTC P1225 TP SENSOR         136           On Board Diagnosis Logic         136           DTC Confirmation Procedure         137           On Board Diagnosis Logic         137           DTC Confirmation Procedure         137		
DTC P1128 THROTTLE CONTROL MOTOR         125           Component Description         125           On Board Diagnosis Logic         125           DTC Confirmation Procedure         125           Wiring Diagram         126           DTC P1211 TCS CONTROL UNIT         127           Description         127           DTC P1211 TCS CONTROL UNIT         127           DTC Confirmation Procedure         127           DTC Confirmation Procedure         128           On Board Diagnosis Logic         128           On Board Diagnosis Logic         128           DTC P1212 TCS COMMUNICATION LINE         128           DTC Confirmation Procedure         128           DTC P1217 ENGINE OVER TEMPERATURE         129           Description         129           CONSULT-IIReference Valuein Data Monitor Mode         131           Overall Function Check         131           Wiring Diagram         136           DTC P1225 TP SENSOR         136           On Board Diagnosis Logic         136           DTC P1226 TP SENSOR         137           On Board Diagnosis Logic         136           DTC P1226 TP SENSOR         137           On Board Diagnosis Logic         138		101
Component Description       125         On Board Diagnosis Logic       125         DTC Confirmation Procedure       125         Wiring Diagram       126         DTC P1211 TCS CONTROL UNIT       127         Description       127         On Board Diagnosis Logic       127         DTC Confirmation Procedure       127         DTC Confirmation Procedure       128         DTC P1212 TCS COMMUNICATION LINE       128         DTC Confirmation Procedure       129         CONSULT-II Reference Value in Data Monitor Mode       130         On Board Diagnosis Logic       131         Overall Function Check       131         Wiring Diagram       133         Main 12 Causes of Overheating       135         DTC P1225 TP SENSOR       136         Component Description       136         DTC P1226 TP SENSOR       137         On Board Diagnosis Logic       137         DTC Confirmation Procedure       138         DTC P1229 SENSOR POWER SUPPLY       138 </td <td>DTC P1128 THROTTLE CONTROL MOTOR</td> <td>.125</td>	DTC P1128 THROTTLE CONTROL MOTOR	.125
On Board Diagnosis Logic125DTC Confirmation Procedure125Wiring Diagram126DTC P1211 TCS CONTROL UNIT127Description127DTC Confirmation Procedure127DTC Confirmation Procedure127DTC P1212 TCS COMMUNICATION LINE128DTC P1212 TCS COMMUNICATION LINE128DTC Confirmation Procedure128DTC Confirmation Procedure128DTC Confirmation Procedure128DTC P1217 ENGINE OVER TEMPERATURE129Description129CONSULT-II Reference Value in Data Monitor Mode130JOn Board Diagnosis Logic131Overall Function Check131Wiring Diagram135DTC P1225 TP SENSOR136DTC P1226 TP SENSOR137On Board Diagnosis Logic137DTC Confirmation Procedure137On Board Diagnosis Logic137DTC Confirmation Procedure137DTC Confirmation Procedure137DTC Confirmation Procedure137DTC Confirmation Procedure137DTC Confirmation Procedure138On Board Diagnosis Logic138DTC Confirmation Procedure138DTC P1229 SENSOR POWER SUPPLY138On Board Diagnosis Logic140CONSULT-II Reference Value in Data Monitor Mode140ConSULT-II Reference Value in Data Monitor Mode140On Board Diagnosis Logic140On Board Diagnosis Logic140DTC Con		
DTC Confirmation Procedure125Wiring Diagram126DTC P1211 TCS CONTROL UNIT127Description127Description127DTC Confirmation Procedure127DTC P1212 TCS COMMUNICATION LINE128DTC P1212 TCS COMMUNICATION LINE128DTC Confirmation Procedure128DTC Confirmation Procedure128DTC Confirmation Procedure128DTC Confirmation Procedure128DTC Confirmation Procedure129Description129CONSULT-II Reference Value in Data Monitor Mode130JOn Board Diagnosis Logic131Overall Function Check131Wiring Diagram133Main 12 Causes of Overheating135DTC P1225 TP SENSOR136DTC Confirmation Procedure136DTC Confirmation Procedure137On Board Diagnosis Logic137DTC Confirmation Procedure137DTC Confirmation Procedure137DTC Confirmation Procedure138DTC Confirmation Procedure138DTC Confirmation Procedure138DTC Confirmation Procedure138DTC P1229 SENSOR POWER SUPPLY138On Board Diagnosis Logic138DTC Confirmation Procedure140CONSULT-II Reference Value in Data Monitor Mode140ConSULT-II Reference Value in Data Monitor Mode140On Board Diagnosis Logic140DTC Confirmation Procedure140On Board Di		125
Wiring Diagram       126         DTC P1211 TCS CONTROL UNIT       127         Description       127         Dr Board Diagnosis Logic       127         DTC Confirmation Procedure       127         DTC P1212 TCS COMMUNICATION LINE       128         Description       128         Dr C P1212 TCS COMMUNICATION LINE       128         Dr DTC Confirmation Procedure       128         DTC Confirmation Procedure       128         DTC Confirmation Procedure       128         DTC Confirmation Procedure       128         DTC Confirmation Procedure       129         CONSULT-II Reference Value in Data Monitor Mode       130         On Board Diagnosis Logic       131         Overall Function Check       131         Wiring Diagram       133         Main 12 Causes of Overheating       135         DTC P1225 TP SENSOR       136         On Board Diagnosis Logic       136         DTC P1226 TP SENSOR       137         On Board Diagnosis Logic       137         DTC Confirmation Procedure       137         DTC Confirmation Procedure       137         DTC Confirmation Procedure       138         DTC P1229 SENSOR POWER SUPPLY       138		
Description127GOn Board Diagnosis Logic127DTC Confirmation Procedure127DTC P1212 TCS COMMUNICATION LINE128Description128DTC Confirmation Procedure128DTC Confirmation Procedure128DTC Confirmation Procedure129Description129Description129Description130JOn Board Diagnosis LogicOn Board Diagnosis Logic131Overall Function Check131Wiring Diagram135DTC P1225 TP SENSOR136Component Description136On Board Diagnosis Logic136On Board Diagnosis Logic137On Board Diagnosis Logic136DTC P1225 TP SENSOR136DTC Confirmation Procedure137DTC Confirmation Procedure137DTC P1226 TP SENSOR137DTC P1229 SENSOR POWER SUPPLY138On Board Diagnosis Logic138DTC Confirmation Procedure137DTC P1229 SENSOR POWER SUPPLY138On Board Diagnosis Logic138DTC P1271, P1281 A/F SENSOR 1140CONSULT-II Reference Value in Data Monitor Mode140On Board Diagnosis Logic140On Bo	Wiring Diagram	. 126
On Board Diagnosis Logic127DTC Confirmation Procedure127DTC P1212 TCS COMMUNICATION LINE128Description128On Board Diagnosis Logic128DTC Confirmation Procedure128DTC P1217 ENGINE OVER TEMPERATURE129Description129CONSULT-II Reference Value in Data Monitor Mode130JOn Board Diagnosis Logic131Overall Function Check131Wiring Diagram135DTC P1225 TP SENSOR136On Board Diagnosis Logic136On Board Diagnosis Logic136DTC P1225 TP SENSOR136DTC Confirmation Procedure136DTC P1226 TP SENSOR137On Board Diagnosis Logic137DTC Confirmation Procedure137On Board Diagnosis Logic138DTC P1229 SENSOR POWER SUPPLY138On Board Diagnosis Logic138DTC Confirmation Procedure138DTC P1271, P1281 A/F SENSOR 1140CONSULT-II Reference Value in Data Monitor Mode140On Board Diagnosis Logic140On Board Diagnosis Logic140	DTC P1211 TCS CONTROL UNIT	
DTC Confirmation Procedure127DTC P1212 TCS COMMUNICATION LINE128Description128On Board Diagnosis Logic128DTC Confirmation Procedure128DTC P1217 ENGINE OVER TEMPERATURE129Description129CONSULT-II Reference Value in Data Monitor Mode130On Board Diagnosis Logic131Overall Function Check131Wiring Diagram135DTC P1225 TP SENSOR136Component Description136On Board Diagnosis Logic136DTC P1225 TP SENSOR136DTC Confirmation Procedure137DTC Confirmation Procedure137DTC Confirmation Procedure137DTC Confirmation Procedure138On Board Diagnosis Logic138DTC Confirmation Procedure138DTC P1229 SENSOR POWER SUPPLY138On Board Diagnosis Logic138DTC Confirmation Procedure139DTC Confirmation Procedure139DTC Confirmation Procedure140ConsULT-II Reference Value in Data Monitor Mode140On Board Diagnosis Logic140On Board Diagnosis Logic140DTC Confirmation Procedure140On Board Diagnosis Logic140On Board Diagnosis Logic140<	Description	
DTC P1212 TCS COMMUNICATION LINE       128         Description       128         On Board Diagnosis Logic       128         DTC Confirmation Procedure       128         DTC P1217 ENGINE OVER TEMPERATURE       129         Description       129         CONSULT-IIReference Value in Data Monitor Mode       130         On Board Diagnosis Logic       131         Overall Function Check       131         Wiring Diagram       133         Main 12 Causes of Overheating       136         DTC P1225 TP SENSOR       136         Component Description       136         DTC P1226 TP SENSOR       137         DTC Confirmation Procedure       138         On Board Diagnosis Logic       138         DTC Confirmation Procedure       138         DTC Confirmation Procedure       138         DTC P1229 SENSOR POWER SUPPLY       138         On Board Diagnosis Logic       138         DTC Confirmation Procedure       139         DTC P1271, P1281 A/F SENSOR 1       140<		
Description128On Board Diagnosis Logic128DTC Confirmation Procedure128DTC P1217 ENGINE OVER TEMPERATURE129Description129CONSULT-II Reference Value in Data Monitor Mode130On Board Diagnosis Logic131Overall Function Check131Wiring Diagram135DTC P1225 TP SENSOR136Component Description136On Board Diagnosis Logic136DTC P1225 TP SENSOR136DTC Confirmation Procedure136DTC Confirmation Procedure137DTC Confirmation Procedure137DTC Confirmation Procedure137DTC Confirmation Procedure138On Board Diagnosis Logic138DTC Confirmation Procedure138DTC Confirmation Procedure138DTC Confirmation Procedure138DTC Confirmation Procedure138DTC Confirmation Procedure138DTC P1229 SENSOR POWER SUPPLY138On Board Diagnosis Logic140ConsultT-II Reference Value in Data Monitor Mode140CONSULT-II Reference Value in Data Monitor Mode140On Board Diagnosis Logic140DTC Confirmation Procedure140On Board Diagnosis Logic140On Board Diagnosis Logic140Or Board Diagnosis Logic140On Board Diagnosis Logic140On Board Diagnosis Logic140On Board Diagnosis Logic140On Board Diagnosis Logic		
On Board Diagnosis Logic128DTC Confirmation Procedure128DTC P1217 ENGINE OVER TEMPERATURE129Description129CONSULT-II Reference Value in Data Monitor Mode130On Board Diagnosis Logic131Overall Function Check131Wiring Diagram135DTC P1225 TP SENSOR136Component Description136On Board Diagnosis Logic136DTC P1226 TP SENSOR136DTC Confirmation Procedure137On Board Diagnosis Logic137DTC Confirmation Procedure137DTC Confirmation Procedure137DTC Confirmation Procedure137DTC Confirmation Procedure138On Board Diagnosis Logic138DTC Confirmation Procedure138DTC P1229 SENSOR POWER SUPPLY138On Board Diagnosis Logic138DTC Confirmation Procedure139DTC P1271, P1281 A/F SENSOR 1140Consult-II Reference Value in Data Monitor Mode140On Board Diagnosis Logic140DTC Confirmation Procedure140On Board Diagnosis Logic140DTC P1271, P1281 A/F SENSOR 1140On Board Diagnosis Logic140On Board Diagnosis Logic140Or Board Diagnosis Logic140Or Board Diagnosis Logic140Or Board Diagnosis Logic140On Board Diagnosis Logic140Or Board Diagnosis Logic140Or Board Diagnosis Logic140		
DTC Confirmation Procedure128DTC P1217 ENGINE OVER TEMPERATURE129Description129CONSULT-II Reference Value in Data Monitor Mode130On Board Diagnosis Logic131Overall Function Check131Wiring Diagram133Main 12 Causes of Overheating135DTC P1225 TP SENSOR136Component Description136On Board Diagnosis Logic136DTC Confirmation Procedure137On Board Diagnosis Logic137DTC Confirmation Procedure137DTC Confirmation Procedure137DTC Confirmation Procedure138On Board Diagnosis Logic138DTC Confirmation Procedure138DTC Confirmation Procedure138DTC Confirmation Procedure138DTC Confirmation Procedure138DTC Confirmation Procedure138DTC Confirmation Procedure138DTC Confirmation Procedure140Consult I-II Reference Value in Data Monitor Mode140On Board Diagnosis Logic140DTC Confirmation Procedure140On Board Diagnosis Logic140Or Board Diagnosis Logic140On Board Diagnosis Logic140DTC Confirmation Procedur	Description	. 128
DTC P1217 ENGINE OVER TEMPERATURE129Description129CONSULT-II Reference Value in Data Monitor Mode130On Board Diagnosis Logic131Overall Function Check131Wiring Diagram133Main 12 Causes of Overheating135DTC P1225 TP SENSOR136Component Description136DTC P1226 TP SENSOR136DTC Confirmation Procedure137On Board Diagnosis Logic137DTC P1226 TP SENSOR137DTC Confirmation Procedure137DTC Confirmation Procedure137DTC Confirmation Procedure138On Board Diagnosis Logic138DTC Confirmation Procedure138DTC Confirmation Procedure138DTC Confirmation Procedure138DTC Confirmation Procedure138DTC Confirmation Procedure138DTC Confirmation Procedure138DTC Confirmation Procedure140Component Description140CONSULT-II Reference Value in Data Monitor Mode140On Board Diagnosis Logic140DTC Confirmation Procedure140Orn Board Diagnosis Logic140DTC Confirmation Procedure140On Board Diagnosis Logic140Orn Board Diagnosis Logic140 <td></td> <td></td>		
Description129CONSULT-II Reference Value in Data Monitor Mode130On Board Diagnosis Logic131Overall Function Check131Wiring Diagram133Main 12 Causes of Overheating135DTC P1225 TP SENSOR136Component Description136On Board Diagnosis Logic136DTC Confirmation Procedure136DTC P1226 TP SENSOR137DTC Confirmation Procedure137On Board Diagnosis Logic137DTC Confirmation Procedure137DTC Confirmation Procedure137DTC Confirmation Procedure138On Board Diagnosis Logic138DTC Confirmation Procedure138DTC Confirmation Procedure138DTC Confirmation Procedure138DTC Confirmation Procedure138DTC Confirmation Procedure140Component Description140CONSULT-II P1281 A/F SENSOR 1140CONSULT-II Reference Value in Data Monitor Mode140DTC Confirmation Procedure140On Board Diagnosis Logic140DTC Confirmation Procedure140On Board Diagnosis Logic140DTC Confirmation Procedure140On Board Diagnosis Logic140Or Board Diagnosis Logic140DTC Confirmation Procedure140Or Board Diagnosis Logic140DTC Confirmation Procedure140Overall Function Check141		
CONSULT-II Reference Value in Data Monitor Mode1301301310 n Board Diagnosis Logic1310 verall Function Check131Wiring Diagram133Main 12 Causes of Overheating135DTC P1225 TP SENSOR136Component Description1360 n Board Diagnosis Logic136DTC P1226 TP SENSOR136DTC Confirmation Procedure136DTC P1226 TP SENSOR137On Board Diagnosis Logic137On Board Diagnosis Logic137DTC Confirmation Procedure137DTC Confirmation Procedure137DTC Confirmation Procedure138On Board Diagnosis Logic138DTC Confirmation Procedure138DTC Confirmation Procedure138DTC Confirmation Procedure138DTC Confirmation Procedure140Component Description140CONSULT-II Reference Value in Data Monitor Mode140On Board Diagnosis Logic140DTC Confirmation Procedure140On Board Diagnosis Logic140DTC Confirmation Procedure140On Board Diagnosis Logic140DTC Confirmation Procedure140On Board Diagnosis Logic140On Board Diagnosis Logic140DTC Confirmation Procedure140On Board Diagnosis Logic140DTC Confirmation Procedure140Overall Function Check141		
.130       .131         On Board Diagnosis Logic       .131         Overall Function Check       .131         Wiring Diagram       .133         Main 12 Causes of Overheating       .135         DTC P1225 TP SENSOR       .136         Component Description       .136         DTC P1225 TP SENSOR       .136         On Board Diagnosis Logic       .136         DTC Confirmation Procedure       .136         DTC P1226 TP SENSOR       .137         DTC Confirmation Procedure       .137         DTC Confirmation Procedure       .137         DTC Confirmation Procedure       .137         DTC P1229 SENSOR POWER SUPPLY       .138         On Board Diagnosis Logic       .138         DTC Confirmation Procedure       .138         DTC Confirmation Procedure       .138         DTC P1229 SENSOR POWER SUPPLY       .138         On Board Diagnosis Logic       .140         Component Description       .140         Component Description       .140         CONSULT-II Reference Value in Data Monitor Mode       .140         On Board Diagnosis Logic       .140         DTC Confirmation Procedure       .140         On Board Diagnosis Logic       .140		
On Board Diagnosis Logic131Overall Function Check131Wiring Diagram133Main 12 Causes of Overheating135DTC P1225 TP SENSOR136Component Description136On Board Diagnosis Logic136DTC P1226 TP SENSOR136DTC Confirmation Procedure136DTC P1226 TP SENSOR137Component Description137On Board Diagnosis Logic137DTC Confirmation Procedure137DTC Confirmation Procedure137DTC P1229 SENSOR POWER SUPPLY138On Board Diagnosis Logic138DTC Confirmation Procedure138DTC Confirmation Procedure138DTC P1229 SENSOR POWER SUPPLY138On Board Diagnosis Logic140Component Description140Consult Lagram140Consult T-II Reference Value in Data Monitor Mode140DTC Confirmation Procedure140On Board Diagnosis Logic140Orn Board Diagnosis Logic140Orneal Diagnosis Logic140DTC Confirmation Procedure140Orneal Diagnosis Logic140DTC Confirmation Procedure140On Board Diagnosis Logic140Orneal Diagnosis Logic140Orneal Diagnosis Logic140Orneal Diagnosis Logic140DTC Confirmation Procedure140Orerall Function Check141		
Overall Function Check131Wiring Diagram133Main 12 Causes of Overheating135DTC P1225 TP SENSOR136Component Description136On Board Diagnosis Logic136DTC Confirmation Procedure136DTC P1226 TP SENSOR137Component Description137On Board Diagnosis Logic137DTC P1226 TP SENSOR137DTC Confirmation Procedure137DTC Confirmation Procedure137DTC Confirmation Procedure138On Board Diagnosis Logic138DTC Confirmation Procedure138DTC Confirmation Procedure138DTC Confirmation Procedure138DTC Confirmation Procedure140Component Description140Consult -II Reference Value in Data Monitor Mode140On Board Diagnosis Logic140DTC Confirmation Procedure140On Board Diagnosis Logic140Orn Board Diagnosis Logic140On Board Diagnosis Logic140On Board Diagnosis Logic140Ort Confirmation Procedure140On Board Diagnosis Logic140Ort Confirmation Procedure140On Board Diagnosis Logic140On Board Diagnosis Logic140Ort Confirmation Procedure140Ort Confirmation Procedure140Ort Confirmation Procedure140Ort Confirmation Procedure140Ort Confirmation Procedure140Ort Co		
Wiring Diagram133KMain 12 Causes of Overheating135DTC P1225 TP SENSOR136Component Description136On Board Diagnosis Logic136DTC Confirmation Procedure136DTC P1226 TP SENSOR137Component Description137On Board Diagnosis Logic137DTC Confirmation Procedure137DTC Confirmation Procedure137DTC Confirmation Procedure137DTC P1229 SENSOR POWER SUPPLY138On Board Diagnosis Logic138DTC Confirmation Procedure138Wiring Diagram139DTC P1271, P1281 A/F SENSOR 1140Component Description140CONSULT-II Reference Value in Data Monitor Mode140On Board Diagnosis Logic140On Board Diagnosis Logic140Or Confirmation Procedure140Or Board Diagnosis Logic140Or Confirmation Procedure140Or C	Overall Function Check	131
Main 12 Causes of Overheating135DTC P1225 TP SENSOR136Component Description136On Board Diagnosis Logic136DTC Confirmation Procedure136DTC P1226 TP SENSOR137Component Description137On Board Diagnosis Logic137DTC Confirmation Procedure137DTC Confirmation Procedure137DTC Confirmation Procedure137DTC P1229 SENSOR POWER SUPPLY138On Board Diagnosis Logic138DTC Confirmation Procedure138DTC Confirmation Procedure138DTC P1271, P1281 A/F SENSOR 1140Component Description140CONSULT-II Reference Value in Data Monitor Mode140On Board Diagnosis Logic140DTC Confirmation Procedure140On Board Diagnosis Logic140On Board Diagnosis Logic140On Board Diagnosis Logic140Or Confirmation Procedure140On Board Diagnosis Logic140On Board Diagnosis Logic140Orc Confirmation Procedure140Orerall Function Check141		
DTC P1225 TP SENSOR136Component Description136On Board Diagnosis Logic136DTC Confirmation Procedure136DTC P1226 TP SENSOR137Component Description137On Board Diagnosis Logic137DTC Confirmation Procedure137DTC Confirmation Procedure137DTC Confirmation Procedure138On Board Diagnosis Logic138DTC P1229 SENSOR POWER SUPPLY138On Board Diagnosis Logic138DTC Confirmation Procedure138DTC Confirmation Procedure138DTC P1271, P1281 A/F SENSOR 1140Component Description140CONSULT-II Reference Value in Data Monitor Mode140On Board Diagnosis Logic140DTC Confirmation Procedure140On Board Diagnosis Logic140On Board Diagnosis Logic140On Board Diagnosis Logic140Orc Confirmation Procedure140Ort Confirmation Procedure140On Board Diagnosis Logic140DTC Confirmation Procedure140Ort Confirmation Procedure140Ort Confirmation Procedure140Ort Confirmation Procedure140Ort Confirmation Procedure140Ort Confirmation Procedure140Ort Confirmation Procedure140Oterall Function Check141	Main 12 Causes of Overheating	. 135
On Board Diagnosis Logic	DTC P1225 TP SENSOR	. 136
On Board Diagnosis Logic       136         DTC Confirmation Procedure       136         DTC P1226 TP SENSOR       137         Component Description       137         On Board Diagnosis Logic       137         DTC Confirmation Procedure       137         DTC Confirmation Procedure       137         DTC P1229 SENSOR POWER SUPPLY       138         On Board Diagnosis Logic       138         DTC Confirmation Procedure       138         DTC Confirmation Procedure       138         DTC Confirmation Procedure       138         DTC Confirmation Procedure       138         DTC P1271, P1281 A/F SENSOR 1       140         Component Description       140         CONSULT-II Reference Value in Data Monitor Mode       140         On Board Diagnosis Logic       140         On Board Diagnosis Logic       140         Or Board Diagnosis Logic       140         Or Confirmation Procedure       140         Or Confirmation Procedure       140         Or Board Diagnosis Logic       140         Or Confirmation Procedure       140         Or confirmation Procedure       140         Or Ward Diagnosis Logic       140         Or Ward Diagnosis Logic <td>Component Description</td> <td>. 136</td>	Component Description	. 136
DTC P1226 TP SENSOR137Component Description137On Board Diagnosis Logic137DTC Confirmation Procedure137DTC P1229 SENSOR POWER SUPPLY138On Board Diagnosis Logic138DTC Confirmation Procedure138DTC Confirmation Procedure138DTC Confirmation Procedure138DTC Confirmation Procedure140Component Description140CONSULT-II Reference Value in Data Monitor Mode140On Board Diagnosis Logic140Or Board Diagnosis Logic140Or Confirmation Procedure140On Board Diagnosis Logic140Or Board Diagnosis Logic140DTC Confirmation Procedure140Or Board Diagnosis Logic140DTC Confirmation Procedure140Overall Function Check141	On Board Diagnosis Logic	. 136 👘
Component Description		
Component Description       137         On Board Diagnosis Logic       137         DTC Confirmation Procedure       137         DTC P1229 SENSOR POWER SUPPLY       138         On Board Diagnosis Logic       138         DTC Confirmation Procedure       138         DTC Confirmation Procedure       138         DTC Confirmation Procedure       138         DTC P1271, P1281 A/F SENSOR 1       140         Component Description       140         CONSULT-II Reference Value in Data Monitor Mode       140         On Board Diagnosis Logic       140         On Board Diagnosis Logic       140         Or Confirmation Procedure       140         Or Werall Function Check       141		B /
DTC Confirmation Procedure137DTC P1229 SENSOR POWER SUPPLY138On Board Diagnosis Logic138DTC Confirmation Procedure138Wiring Diagram139DTC P1271, P1281 A/F SENSOR 1140Component Description140CONSULT-II Reference Value in Data Monitor Mode140On Board Diagnosis Logic140On Board Diagnosis Logic140Overall Function Procedure141	Component Description	. 137
DTC P1229 SENSOR POWER SUPPLY       138         On Board Diagnosis Logic       138         DTC Confirmation Procedure       138         Wiring Diagram       139         DTC P1271, P1281 A/F SENSOR 1       140         Component Description       140         CONSULT-II Reference Value in Data Monitor Mode       140         On Board Diagnosis Logic       140         Or Board Diagnosis Logic       140         Overall Function Check       141		
On Board Diagnosis Logic       138         DTC Confirmation Procedure       138         Wiring Diagram       139         DTC P1271, P1281 A/F SENSOR 1       140         Component Description       140         CONSULT-II Reference Value in Data Monitor Mode       140         On Board Diagnosis Logic       140         DTC Confirmation Procedure       140         Overall Function Check       141		
DTC Confirmation Procedure		
Wiring Diagram139DTC P1271, P1281 A/F SENSOR 1140Component Description140CONSULT-II Reference Value in Data Monitor Mode140On Board Diagnosis Logic140DTC Confirmation Procedure140Overall Function Check141		
DTC P1271, P1281 A/F SENSOR 1		
Component Description		139
CONSULT-II Reference Value in Data Monitor Mode 140 On Board Diagnosis Logic140 DTC Confirmation Procedure140 Overall Function Check141		
. 140 On Board Diagnosis Logic	CONSULT_IIReference Value in Data Manitar Made	. 1 <del>4</del> 0
On Board Diagnosis Logic		
DTC Confirmation Procedure140 Overall Function Check141		
Overall Function Check141		
winny Diagraffi142	Wiring Diagram	

\_\_\_\_

. . . . .

\_ \_ .

DTC P1272, P1282 A/F SENSOR 1	144
Component Description	144
CONSULT-II Reference Value in Data Monitor Mo	nde
	.144
On Board Diagnosis Logic	
DTC Confirmation Procedure	
Overall Function Check	
Wiring Diagram	
DTC P1276, P1286 A/F SENSOR 1	
Component Description	
CONSULT-IIReferenceValue in Data Monitor Mo	
CONSOLT-ITReference value in Data Monitor Mit	.148
On Reard Diagnosia Logia	
On Board Diagnosis Logic	
Overall Function Check	
Wiring Diagram	
DTC P1564 ASCD STEERING SWITCH	
Component Description	
CONSULT-IIReferenceValue in Data Monitor Mo	
	.152
On Board Diagnosis Logic	
DTC Confirmation Procedure	
Wiring Diagram	154
DTC P1572 ASCD BRAKE SWITCH	155
Component Description	155
CONSULT-II Reference Value in Data Monitor Mo	
	.155
On Board Diagnosis Logic	155
DTC Confirmation Procedure	
Overall Function Check	
Wiring Diagram	
DTC P1574 ASCD VEHICLE SPEED SENSOR	
Component Description	
On Board Diagnosis Logic	
DTC Confirmation Procedure	
DTC P1700 CVT CONTROL SYSTEM	
Description DTC P1706 PNP SWITCH	
Component Description	
CONSULT-IIReferenceValue in DataMonitorMo	
	.162
On Board Diagnosis Logic	162
DTC Confirmation Procedure	
Overall Function Check	
Wiring Diagram	164
DTC P1715 INPUT SPEED SENSOR (PRIMAR	
SPEED SENSOR)	
Description	
CONSULT-II Reference Value in Data Monitor Mo	ode
	.165
On Board Diagnosis Logic	165
DTC Confirmation Procedure	165
DTC P1720 VSS	
Description	
CONSULT-II Reference Value in Data Monitor Mo	
	.167
On Board Diagnosis Logic	
DTC Confirmation Procedure	
DTC P1805 BRAKE SWITCH	
Description	

CONSULT-II Reference Value in Data Monitor Mo	
	.169
On Board Diagnosis Logic	169
DTC Confirmation Procedure	169
Wiring Diagram	171
DTC P2122, P2123 APP SENSOR	172
Component Description	
CONSULT-II Reference Value in Data Monitor Mo	
	.172
On Roard Diagnosia Logia	
On Board Diagnosis Logic	172
DTC Confirmation Procedure	
Wiring Diagram	174
DTC P2127, P2128 APP SENSOR	
Component Description	175
CONSULT-II Reference Value in Data Monitor Mo	de
	.175
On Board Diagnosis Logic	
DTC Confirmation Procedure	176
Wiring Diagram	
	1//
DTC P2135 TP SENSOR	
Component Description	
CONSULT-II Reference Value in Data Monitor Mo	de
	·178
On Board Diagnosis Logic	178
DTC Confirmation Procedure	
Wiring Diagram	
DTC P2138 APP SENSOR	100
Component Description	
CONSULT-II Reference Value in Data Monitor Mo	
On Poord Diagnosis Logis	·181
On Board Diagnosis Logic	·181
DTC Confirmation Procedure	·181 ····181 ····182
DTC Confirmation Procedure Wiring Diagram	·181 ····181 ····182 ····183
DTC Confirmation Procedure Wiring Diagram HO2S2 HEATER	·181 ····181 ····182 ····183 · <b>···184</b>
DTC Confirmation Procedure Wiring Diagram HO2S2 HEATER Wiring Diagram —LHD Models—	·181 ····181 ····182 ····183 ····184
DTC Confirmation Procedure Wiring Diagram HO2S2 HEATER Wiring Diagram —LHD Models— IAT SENSOR	·181 ····181 ····182 ····183 ····184 ····184 ····186
DTC Confirmation Procedure Wiring Diagram HO2S2 HEATER Wiring Diagram —LHD Models— IAT SENSOR	·181 ····181 ····182 ····183 ····184 ····184 ····186
DTC Confirmation Procedure Wiring Diagram HO2S2 HEATER Wiring Diagram —LHD Models— IAT SENSOR Wiring Diagram	·181 ····182 ····182 ····183 ····184 ····184 ····186
DTC Confirmation Procedure Wiring Diagram HO2S2 HEATER Wiring Diagram —LHD Models— IAT SENSOR Wiring Diagram HO2S2	·181 ····182 ····183 ····183 ····184 ····184 ····186 ····186 ····187
DTC Confirmation Procedure Wiring Diagram HO2S2 HEATER Wiring Diagram —LHD Models— Wiring Diagram HO2S2 Wiring Diagram —LHD Models—	·181 ····181 ····182 ····183 ····184 ····186 ····186 ····187 ····187
DTC Confirmation Procedure Wiring Diagram HO2S2 HEATER Wiring Diagram —LHD Models— Wiring Diagram HO2S2 Wiring Diagram —LHD Models— IGNITION SIGNAL	·181 ····181 ····182 ····183 ····183 ····184 ····186 ····186 ····187 ····187 ····189
DTC Confirmation Procedure Wiring Diagram HO2S2 HEATER Wiring Diagram —LHD Models— Wiring Diagram HO2S2 Wiring Diagram —LHD Models— IGNITION SIGNAL Wiring Diagram	·181 ····181 ····182 ····183 ····184 ····184 ····186 ····186 ····187 ····187 ····189 ····189
DTC Confirmation Procedure Wiring Diagram	·181 ····181 ····182 ····183 ····184 ····186 ····186 ····187 ····187 ····189 ···
DTC Confirmation Procedure Wiring Diagram	·181 ····182 ····182 ····183 ····184 ····184 ····186 ····186 ····187 ····187 ····189 ····189 ····
DTC Confirmation Procedure	·181 ····181 ····182 ····182 ····183 ····184 ····184 ····186 ····186 ····187 ····187 ····189 ··· ···189 ····
DTC Confirmation Procedure Wiring Diagram	·181 ····182 ····182 ····183 ····184 ····184 ····186 ····186 ····187 ····187 ····189 ····189 ····192 ····193
DTC Confirmation Procedure Wiring Diagram	·181 ····182 ····182 ····183 ····184 ····184 ····186 ····186 ····187 ····187 ····189 ····192 ····192 ····193 ····193
DTC Confirmation Procedure Wiring Diagram	·181 ····182 ····182 ····183 ····184 ····184 ····186 ····186 ····187 ····187 ····189 ····192 ····192 ····193 ····193
DTC Confirmation Procedure	·181 ····181 ····182 ····183 ····184 ····184 ····186 ····186 ····187 ····187 ····187 ····187 ····192 ····192 ····193 ····194
DTC Confirmation Procedure	·181 ····181 ····182 ····183 ····184 ····184 ····186 ····186 ····187 ····187 ····187 ····187 ····187 ····192 ····192 ····193 ····194 ····194
DTC Confirmation Procedure	·181 ····181 ····182 ····183 ····184 ····184 ····186 ····186 ····186 ····187 ····187 ····187 ····187 ····189 ····192 ····193 ····193 ····194 ····195
DTC Confirmation Procedure	·181 ····181 ····182 ····183 ····184 ····184 ····186 ····186 ····186 ····187 ····187 ····187 ····187 ····189 ····192 ····193 ····194 ····195
DTC Confirmation Procedure	·181 ····181 ····182 ····182 ····183 ····184 ····184 ····186 ····186 ····186 ····187 ····187 ····193 ····193 ····194 ····195 ···196
DTC Confirmation Procedure	·181 ····182 ····182 ····183 ····184 ····184 ····186 ····186 ····187 ····187 ····187 ····192 ····193 ····193 ····194 ····195 ····196 ····196
DTC Confirmation Procedure	·181 ····181 ····182 ····183 ····184 ····186 ····186 ····186 ····187 ····187 ····187 ····187 ····187 ····192 ····193 ····193 ····194 ····195 ····196 ····197
DTC Confirmation Procedure	·181 ····181 ····182 ····183 ····184 ····184 ····186 ····186 ····186 ····187 ····187 ····187 ····192 ····193 ····193 ····194 ····195 ····196 ····197 ····197
DTC Confirmation Procedure	·181 ····181 ····182 ····182 ····182 ····184 ····184 ····186 ····186 ····186 ····186 ····187 ····193 ····193 ····193 ····194 ····195 ····196 ····197 ····198
DTC Confirmation Procedure	·181 ····181 ····182 ····182 ····182 ····184 ····184 ····186 ····186 ····186 ····186 ····187 ····193 ····193 ····193 ····194 ····195 ····196 ····197 ····198
DTC Confirmation Procedure	·181 ····181 ····182 ····182 ····182 ····182 ····184 ····184 ····186 ····186 ····186 ····187 ····187 ····193 ····193 ····194 ····194 ····195 ····196 ····197 ···198 ····198 ····198 ····198
DTC Confirmation Procedure	·181 ····181 ····182 ····183 ····184 ····184 ····186 ····186 ····186 ····187 ····187 ····187 ····192 ····193 ····193 ····194 ····195 ····196 ····197 ···198 ····198 ····198 ····198 ····198 ····198 ····198 ····198 ····198 ····198 ····198 ····198 ····198 ····198 ····198

MIL AND DATA LINK CONNECTOR	200
Wiring Diagram	200
SERVICE DATA AND SPECIFICATIONS (SDS) .	203
Fuel Pressure	203
Idle Speed and Ignition Timing	203
Mass Air Flow Sensor	203
Intake Air Temperature Sensor	203
Engine Coolant Temperature Sensor	203
Air Fuel Ratio (A/F) Sensor 1 Heater	203
Heated Oxygen Sensor 2 Heater	203
Throttle Control Motor	203
Injector	203
Fuel Pump	203

EC

С

D

Е

F

G

Н

I

J

Κ

L

Μ

А

## MODIFICATION NOTICE Major Modification Item


• Air fuel ratio (A/F) sensor 1 is applied.

PFP:00000

ABS00H4J

#### **ENGINE CONTROL SYSTEM**

## ENGINE CONTROL SYSTEM System Diagram





PFP:23710

ABS00GSB

А

EC

С

D

Е

F

G

Н

I

J

Κ

L

Μ

## **ON BOARD DIAGNOSTIC (OBD) SYSTEM**

#### Introduction

PFP:00028

ABS00GSP

The ECM has an on board diagnostic system, which detects malfunctions related to engine sensors or actuators. The ECM also records various emission-related diagnostic information including:

Emission-related diagnostic information
Diagnostic Trouble Code (DTC)
Freeze Frame data
1st Trip Diagnostic Trouble Code (1st Trip DTC)
1st Trip Freeze Frame data

The above information can be checked using procedures listed in the table below.

×: Applicable —: Not applicable

	DTC	1st trip DTC	Freeze Frame data	1st trip Freeze Frame data
CONSULT-II	×	×	×	×
ECM	×	×*	_	_

\*: When DTC and 1st trip DTC simultaneously appear on the display, they cannot be clearly distinguished from each other.

The malfunction indicator lamp (MIL) on the instrument panel lights up when the same malfunction is detected in two consecutive trips (Two trip detection logic), or when the ECM enters fail-safe mode. (Refer to EC-292, "Fail-Safe Chart" .)

## **Two Trip Detection Logic**

ABSOOGSO

When a malfunction is detected for the first time, 1st trip DTC and 1st trip Freeze Frame data are stored in the ECM memory. The MIL will not light up at this stage. <1st trip>

If the same malfunction is detected again during the next drive, the DTC and Freeze Frame data are stored in the ECM memory, and the MIL lights up. The MIL lights up at the same time when the DTC is stored. <2nd trip> The "trip" in the "Two Trip Detection Logic" means a driving mode in which self-diagnosis is performed during vehicle operation. When the ECM enters fail-safe mode (Refer to EC-292, "Fail-Safe Chart" .), the DTC is stored in the ECM memory even in the 1st trip.

When there is an open circuit on MIL circuit, the ECM cannot warn the driver by lighting up MIL when there is malfunction on engine control system.

Therefore, when electrical controlled throttle and part of ECM related diagnoses are continuously detected as NG for 5 trips, ECM warns the driver that engine control system malfunctions and MIL circuit is open by means of operating fail-safe function.

The fail-safe function also operates when above diagnoses except MIL circuit are detected and demands the driver to repair the malfunction.

Engine operating condition in fail-safe mode Engine speed will not rise more than 2,500 rpm due to the fuel cut

#### **Emission-related Diagnostic Information** EMISSION-RELATED DIAGNOSTIC INFORMATION ITEMS

ABSOOGSE

×: Applicable	-: Not applicable
---------------	-------------------

				×: Applica	able –: Not applicable
Items	DTC	DTC*1		MIL	Deference page
(CONSULT-II screen terms)	CONSULT-II	ECM*2	- Trip	IVIIL	Reference page
CAN COMM CIRCUIT	U1000	1000* <sup>3</sup>	2	—	<u>EC-352</u>
CAN COMM CIRCUIT	U1001	1001* <sup>3</sup>	2	—	<u>EC-352</u>
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	P0000	0000	_	_	_
INT/V TIM CONT-B1	P0011	0011	2	—	<u>EC-354</u>
INT/V TIM CONT-B2	P0021	0021	2	—	<u>EC-354</u>
MAF SEN/CIRCUIT	P0102	0102	1	×	<u>EC-357</u>
MAF SEN/CIRCUIT	P0103	0103	1	×	<u>EC-357</u>
ECT SEN/CIRC	P0117	0117	2	×	EC-361

Revision: 2006 December



Items	DTC*1				Deference nore	Δ
(CONSULT-II screen terms)	CONSULT-II	ECM* <sup>2</sup>	Trip	MIL	Reference page	А
ECT SEN/CIRC	P0118	0118	2	×	<u>EC-361</u>	
TP SEN 2/CIRC	P0122	0122	1	×	<u>EC-364</u>	EC
TP SEN 2/CIRC	P0123	0123	1	×	<u>EC-364</u>	
HO2S2 (B1)	P0138	0138	2	×	<u>EC-368</u>	С
HO2S2 (B2)	P0158	0158	2	×	<u>EC-368</u>	C
TP SEN 1/CIRC	P0222	0222	1	×	<u>EC-374</u>	
TP SEN 1/CIRC	P0223	0223	1	×	<u>EC-374</u>	D
KNOCK SEN/CIRC-B1	P0327	0327	2	_	<u>EC-378</u>	
KNOCK SEN/CIRC-B1	P0328	0328	2	_	<u>EC-378</u>	_
CKP SEN/CIRCUIT	P0335	0335	2	×	<u>EC-381</u>	E
CMP SEN/CIRC-B1	P0340	0340	2	×	<u>EC-385</u>	
CMP SEN/CIRC-B2	P0345	0345	2	×	<u>EC-385</u>	F
PW ST P SEN/CIRC	P0550	0550	2	_	<u>EC-391</u>	
ECM	P0605	0605	1 or 2	× or —	<u>EC-394</u>	
A/F SEN1 HTR (B1)	P1031	1031	2	×	<u>EC-396</u>	G
A/F SEN1 HTR (B1)	P1032	1032	2	×	<u>EC-396</u>	
A/F SEN1 HTR (B2)	P1051	1051	2	×	<u>EC-396</u>	Н
A/F SEN1 HTR (B2)	P1052	1052	2	×	EC-396	
ECM BACK UP/CIRCUIT	P1065	1065	2	×	<u>EC-402</u>	
INT/V TIM V/CIR-B1	P1111	1111	2	×	<u>EC-405</u>	
ETC ACTR	P1121	1121	1	×	<u>EC-411</u>	
ETC FUNCTION/CIRC	P1122	1122	1	×	EC-413	J
ETC MOT PWR	P1124	1124	1	×	<u>EC-416</u>	J
ETC MOT PWR	P1126	1126	1	×	<u>EC-416</u>	
ETC MOT	P1128	1128	1	×	<u>EC-420</u>	Κ
INT/V TIM V/CIR-B2	P1136	1136	2	×	<u>EC-405</u>	
TCS C/U FUNCTN	P1211	1211	2	_	<u>EC-423</u>	
TCS/CIRC	P1212	1212	2		<u>EC-424</u>	L
ENG OVER TEMP	P1217	1217	1	×	<u>EC-425</u>	
CTP LEARNING	P1225	1225	2	_	<u>EC-434</u>	Μ
CTP LEARNING	P1226	1226	2		EC-435	
SENSOR POWER/CIRC	P1229	1229	1	×	<u>EC-436</u>	
A/F SENSOR1 (B1)	P1271	1271	2	×	<u>EC-439</u>	
A/F SENSOR1 (B1)	P1272	1272	2	×	<u>EC-445</u>	
A/F SENSOR1 (B1)	P1276	1276	2	×	<u>EC-451</u>	
A/F SENSOR1 (B2)	P1281	1281	2	×	<u>EC-439</u>	
A/F SENSOR1 (B2)	P1282	1282	2	×	<u>EC-445</u>	
A/F SENSOR1 (B2)	P1286	1286	2	×	<u>EC-451</u>	
ASCD SW	P1564	1564	1	_	<u>EC-457</u>	
ASCD BRAKE SW	P1572	1572	1		<u>EC-461</u>	
ASCD VHL SPD SEN	P1574	1574	1		<u>EC-466</u>	
NATS MALFUNCTION	P1610 - P1615	1610 - 1615	2		<u>BL-116</u>	
CVT C/U FUNCT	P1700	1700	1		<u>EC-468</u>	

**EC-8** 

Items	DT	C* <sup>1</sup>	Trip	MIL	Poforonoo nago
(CONSULT-II screen terms)	CONSULT-II	ECM*2	- Trip	IVIIL	Reference page
P-N POS SW/CIRCUIT	P1706	1706	2	×	<u>EC-469</u>
IN PULY SPEED	P1715	1715	2	_	<u>EC-473</u>
V/SP SEN (A/T OUT)	P1720	1720	2	—	<u>EC-475</u>
BRAKE SW/CIRCUIT	P1805	1805	1	×	<u>EC-477</u>
APP SEN 1/CIRC	P2122	2122	1	×	<u>EC-481</u>
APP SEN 1/CIRC	P2123	2123	1	×	<u>EC-481</u>
APP SEN 2/CIRC	P2127	2127	1	×	<u>EC-485</u>
APP SEN 2/CIRC	P2128	2128	1	×	<u>EC-485</u>
TP SENSOR	P2135	2135	1	×	<u>EC-489</u>
APP SENSOR	P2138	2138	1	×	<u>EC-493</u>

\*1: 1st trip DTC No. is the same as DTC No.

\*2: In Diagnostic Test Mode II (Self-diagnostic results)

\*3: The trouble shooting for this DTC needs CONSULT-II.

#### DTC AND 1ST TRIP DTC

The 1st trip DTC (whose number is the same as the DTC number) is displayed for the latest self-diagnostic result obtained. If the ECM memory was cleared previously, and the 1st trip DTC did not reoccur, the 1st trip DTC will not be displayed.

If a malfunction is detected during the 1st trip, the 1st trip DTC is stored in the ECM memory. The MIL will not light up (two trip detection logic). If the same malfunction is not detected in the 2nd trip (meeting the required driving pattern), the 1st trip DTC is cleared from the ECM memory. If the same malfunction is detected in the 2nd trip, both the 1st trip DTC and DTC are stored in the ECM memory and the MIL lights up. In other words, the DTC is stored in the ECM memory and the MIL lights up. In other words, the DTC is stored in the ECM memory and the MIL lights up when the same malfunction occurs in two consecutive trips. If a 1st trip DTC is stored and a non-diagnostic operation is performed between the 1st and 2nd trips, only the 1st trip DTC will continue to be stored. For fail-safe items, the DTC is stored in the ECM memory even in the 1st trip.

Procedures for clearing the DTC and the 1st trip DTC from the ECM memory are described in <u>EC-283, "HOW</u> <u>TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"</u>.

When a 1st trip DTC is detected, check, print out or write down and erase (1st trip) DTC and Freeze Frame data as specified in Work Flow procedure Step 2, refer to <u>EC-286, "WORK FLOW"</u>. Then perform DTC Confirmation Procedure or Overall Function Check to try to duplicate the problem. If the malfunction is duplicated, the item requires repair.

#### How to Read DTC and 1st Trip DTC

DTC and 1st trip DTC can be read by the following methods.

#### With CONSULT-II

CONSULT-II displays the DTC in "SELF-DIAG RESULTS" mode. Examples: P0117, P0340, P1065, etc. (CONSULT-II also displays the malfunctioning component or system.)

#### **Without CONSULT-II**

The number of blinks of the MIL in the Diagnostic Test Mode II (Self-Diagnostic Results) indicates the DTC. Example: 0117, 0340, 1065, etc.

- 1st trip DTC No. is the same as DTC No.
- Output of a DTC indicates a malfunction. However, the Diagnostic Test Mode II does not indicate whether the malfunction is still occurring or has occurred in the past and has returned to normal. CONSULT-II can identify malfunction status as shown below. Therefore, using CONSULT-II (if available) is recommended.

A sample of CONSULT-II display for DTC and 1st trip DTC is shown below. DTC or 1st trip DTC of a malfunction is displayed in "SELF-DIAGNOSTIC RESULTS" mode of CONSULT-II. Time data indicates how many times the vehicle was driven after the last detection of a DTC.

If the DTC is being detected currently, the time data will be [0].

If a 1st trip DTC is stored in the ECM, the time data will be [1t].

	SELF DIAG RESU	JLTS TIME	SELF DI	AG RESULTS		
DTC	CKP SEN/CIRCUIT [P0335 ]	0	CKP SEN/CI [P0335		-	
display			ay			
					PBIB0911E	

#### FREEZE FRAME DATA AND 1ST TRIP FREEZE FRAME DATA

The ECM records the driving conditions such as fuel system status, engine coolant temperature, short term fuel trim, long term fuel trim, engine speed, vehicle speed, base fuel schedule and intake air temperature at the moment a malfunction is detected.

Data which are stored in the ECM memory, along with the 1st trip DTC, are called 1st trip freeze frame data. The data, stored together with the DTC data, are called freeze frame data and displayed on CONSULT-II.

Only one set of freeze frame data (either 1st trip freeze frame data or freeze frame data) can be stored in the ECM. 1st trip freeze frame data is stored in the ECM memory along with the 1st trip DTC. There is no priority for 1st trip freeze frame data and it is updated each time a different 1st trip DTC is detected. However, once freeze frame data (2nd trip detection/MIL on) is stored in the ECM memory, 1st trip freeze frame data is no longer stored. Remember, only one set of freeze frame data can be stored in the ECM.

Both 1st trip freeze frame data and freeze frame data (along with the DTCs) are cleared when the ECM memory is erased. Procedures for clearing the ECM memory are described in <u>EC-283, "HOW TO ERASE EMIS-SION-RELATED DIAGNOSTIC INFORMATION"</u>.


#### HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION

## How to Erase DTC

#### WITH CONSULT-II

The emission related diagnostic information in the ECM can be erased by selecting "ERASE" in the "SELF-DIAG RESULTS" mode with CONSULT-II.

- 1. If the ignition switch stays ON after repair work, be sure to turn ignition switch OFF once. Wait at least 10 seconds and then turn it ON (engine stopped) again.
- 2. Turn CONSULT-II ON and touch "ENGINE".
- 3. Touch "SELF-DIAG RESULTS".
- 4. Touch "ERASE". (The DTC in the ECM will be erased.)



PBIB2392E

EC-10

F

Н

1

K

M

#### **WITHOUT CONSULT-II**

- 1. If the ignition switch stays ON after repair work, be sure to turn ignition switch OFF once.
- 2. Wait at least 10 seconds and then turn it ON (engine stopped) again.
- 3. Change the diagnostic test mode from Mode II to Mode I by depressing the accelerator pedal.
- If the battery is disconnected, the emission-related diagnostic information will be lost within 24 hours.
- The following data are cleared when the ECM memory is erased.
- Diagnostic trouble codes
- 1st trip diagnostic trouble codes
- Freeze frame data
- 1st trip freeze frame data

Actual work procedures are explained using a DTC as an example. Be careful so that not only the DTC, but all of the data listed above, are cleared from the ECM memory during work procedures.

# Trouble Diagnosis Introduction INTRODUCTION

The engine has an ECM to control major systems such as fuel control, ignition control, idle air control system, etc. The ECM accepts input signals from sensors and instantly drives actuators. It is essential that both input and output signals are proper and stable. At the same time, it is important that there are no malfunctions such as vacuum leaks, fouled spark plugs, or other malfunctions with the engine.

It is much more difficult to diagnose an incident that occurs intermittently rather than continuously. Most intermittent incidents are caused by poor electric connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.


A visual check only may not find the cause of the incidents. A road test with CONSULT-II or a circuit tester connected should be performed. Follow the Work Flow on  $\underline{\text{EC-286}}$ .


Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a driveability complaint. The customer can supply good information about such incidents, especially intermittent ones. Find out what symptoms are present and under what conditions they occur. A Diagnostic Worksheet like the example on  $\underline{\text{EC-290}}$  should be used.

Start your diagnosis by looking for conventional malfunctions first. This will help troubleshoot driveability malfunctions on an electronically controlled engine vehicle. PFP:00004

А

## Sensors ECM Actuators C D MEF036D








Н

#### WORK FLOW Overall Sequence



\*2: Include 1st trip freeze frame data.

PBIB3126E

Detailed	Flow
----------	------

## 1. GET INFORMATION FOR SYMPTOM

Get the detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred) using the EC-289, "DIAGNOSTIC WORKSHEET" . EC

>> GO TO 2.

## 2. CHECK DTC\*<sup>1</sup>

1.	Check DTC* <sup>1</sup> .	D
2.	Perform the following procedure if DTC <sup>*1</sup> is displayed.	
_	Record DTC <sup>*1</sup> and freeze frame data <sup>*2</sup> . (Print them out with CONSULT-II.)	Е
-	Erase DTC*1 . (Refer to EC-283, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION" .)	
-	Study the relationship between the cause detected by $DTC^{*1}$ and the symptom described by the customer. (Symptom Matrix Chart is useful. Refer to <u>EC-298, "Symptom Matrix Chart"</u> .)	F
3.	Check related service bulletins for information.	
ls a	any symptom described and any DTC detected?	G
S	ymptom is described, DTC* <sup>1</sup> is displayed>>GO TO 3. ymptom is described, DTC* <sup>1</sup> is not displayed>>GO TO 4. ymptom is not described, DTC* <sup>1</sup> is displayed>>GO TO 5.	Н
3.	CONFIRM THE SYMPTOM	
DÍ Co res	to confirm the symptom described by the customer (except MIL ON). AGNOSIS WORK SHEET is useful to verify the incident. nnect CONSULT-II to the vehicle in "DATA MONITOR (AUTO TRIG)" mode and check real time diagnosis sults. rify relation between the symptom and the condition when the symptom is detected.	J
	>> GO TO 5.	K
4.	CONFIRM THE SYMPTOM	
DÍ Co	to confirm the symptom described by the customer. AGNOSIS WORK SHEET is useful to verify the incident. nnect CONSULT-II to the vehicle in "DATA MONITOR (AUTO TRIG)" mode and check real time diagnosis sults.	M

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6.

А

С

## 5. PERFORM DTC CONFIRMATION PROCEDURE

Perform DTC Confirmation Procedure for the displayed DTC<sup>\*1</sup>, and then make sure that DTC<sup>\*1</sup> is detected again.

At this time, always connect CONSULT-II to the vehicle, and check diagnostic results in real time on "DATA MONITOR (AUTO TRIG)".

If two or more DTCs<sup>\*1</sup> are detected, refer to <u>EC-291, "DTC Inspection Priority Chart"</u> and determine trouble diagnosis order.

#### NOTE:

- Freeze frame data<sup>\*2</sup> is useful if the DTC<sup>\*1</sup> is not detected.
- Perform Overall Function Check if DTC Confirmation Procedure is not included on Service Manual. This simplified check procedure is an effective alternative though DTC<sup>\*1</sup> cannot be detected during this check. If the result of Overall Function Check is NG, it is the same as the detection of DTC<sup>\*1</sup> by DTC Confirmation Procedure.

#### <u>Is DTC\*1</u> detected?

Yes >> GO TO 10.

No >> Check according to EC-338, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".

#### 6. PERFORM BASIC INSPECTION

Perform EC-293, "Basic Inspection" .


With CONSULT-II>>GO TO 7. Without CONSULT-II>>GO TO 9.

#### 7. PERFORM DATA MONITOR (SPEC) MODE

With CONSULT-II Make sure that "MAS A/F SE-B1", "B/FUEL SCHDL", and "A/F ALPHA-B1", "A/F ALPHA-B2" are within the SP value using CON-SULT-II "DATA MONITOR (SPEC)" mode. Refer to <u>EC-329, "Diagnostic Procedure"</u>.

Are they within the SP value?

Yes >> GO TO 9. No >> GO TO 8.



#### 8. DETECT MALFUNCTIONING PART BY TROUBLE DIAGNOSIS - SPECIFICATION VALUE

Detect malfunctioning part according to <u>EC-328, "TROUBLE DIAGNOSIS - SPECIFICATION VALUE"</u>. Is malfunctioning part detected?

Yes >> GO TO 11. No >> GO TO 9.

#### 9. DETECT MALFUNCTIONING SYSTEM BY SYMPTOM MATRIX CHART

Detect malfunctioning system according to <u>EC-298</u>, "Symptom Matrix Chart" based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

>> GO TO 10.

1	0	-	DETECT	MALFUNCTIONING PART
-	-	-		

	А
Inspect the system. Is malfunctioning part detected? Yes >> GO TO 11.	EC
No >> Monitor input data from related sensors or check voltage SULT-II. Refer to <u>EC-323, "CONSULT-II Reference Value</u> <u>nals and Reference Value"</u> .	e of related ECM terminals using CON-
11. REPAIR OR REPLACE THE MALFUNCTIONING PART	
1. Repair or replace the malfunctioning part.	D
<ol> <li>Reconnect parts or connectors after repair and replacement.</li> <li>Check DTC. If DTC is displayed, erase it, refer to <u>EC-283, "HeplaGNOSTIC INFORMATION"</u>.</li> </ol>	OW TO ERASE EMISSION-RELATED
>> GO TO 12.	F
12. FINAL CHECK	ı
When DTC was detected in step 2, perform DTC Confirmation Proce and then make sure that the malfunction have been repaired securely. When symptom was described from the customer, refer to confirmed	
that the symptom is not detected.	Н
OK or NG	
NG (DTC <sup>*1</sup> is detected)>>GO TO 10. NG (Symptom remains)>>GO TO 6. OK >> 1. Before returning the vehicle to the customer, make sure (Refer to <u>EC-283, "How to Erase DTC"</u> .)	e to erase unnecessary DTC* <sup>1</sup> in ECM.
2. INSPECTION END	J
<ul><li>*1: Include 1st trip DTC.</li><li>*2: Include 1st trip freeze frame data.</li></ul>	
DIAGNOSTIC WORKSHEET	К
Description	
There are many operating conditions that lead to the malfunction of engine components. A good grasp of such conditions can make trou- bleshooting faster and more accurate.	
In general, each customer feels differently about a incident. It is important to fully understand the symptoms or conditions for a cus- tomer complaint. Utilize a diagnostic worksheet like the one on the next page in order to organize all the information for troubleshooting.	WHAT Vehicle & engine model WHEN Date, Frequencies WHERE Road conditions HOW Operating conditions, Weather conditions,

Some conditions may cause the MIL to come on steady or blink and DTC to be detected. Examples:

• Vehicle ran out of fuel, which caused the engine to misfire.

Symptoms

#### Worksheet Sample

Customer nar	me MR/MS	Model & Year	VIN
Engine #		Trans.	Mileage
Incident Date		Manuf. Date	In Service Date
Fuel and fuel	uel filler cap		
	☐ Startability	Impossible to start No combus Partial combustion affected by th Partial combustion NOT affected Possible but hard to start Othe	hrottle position d by throttle position
Symptoms	🗌 Idling	□ No fast idle □ Unstable □ H □ Others [	High idle 🛛 Low idle ]
	Driveability	Stumble Surge Knock Intake backfire Exhaust backfi Others [	
	Engine stall	At the time of start While idling While accelerating While dece	elerating
Incident occu	rrence	☐ Just after delivery ☐ Recently ☐ In the morning ☐ At night [	☐ In the daytime
Frequency	All the time Under certain conditions Sometimes		ditions 🗌 Sometimes
Weather cond	ditions	□ Not affected	
	Weather	🗌 Fine 🗌 Raining 🗌 Snowing	Others [ ]
	Temperature	🗌 Hot 🗌 Warm 🗌 Cool 🗌	Cold Humid °F
		Cold During warm-up	After warm-up
Engine condit	tions	Engine speed	4,000 6,000 8,000 rpm
Road condition	ons	🗌 In town 🗌 In suburbs 🗌 Hig	hway 🗌 Off road (up/down)
Driving condit	tions	While accelerating While cruis	•
		Vehicle speed 0 10 20	30 40 50 60 MPH
Malfunction in	ndicator lamp	□ Turned on □ Not turned on	

MTBL0017

#### **DTC Inspection Priority Chart**

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

#### NOTE:

# If DTC U1000 and/or U1001 is displayed with other DTC, first perform the trouble diagnosis for DTC U1000, U1001. Refer to EC-352.

Priority	Detected items (DTC)	
1	U1000 U1001 CAN communication line	
	P0102 P0103 Mass air flow sensor	
	P0117 P0118 Engine coolant temperature sensor	
	• P0122 P0123 P0222 P0223 P1225 P1226 P2135 Throttle position sensor	
	P0327 P0328 Knock sensor	
	P0335 Crankshaft position sensor (POS)	
	P0340 P0345 Camshaft position sensor (PHASE)	
	• P0605 ECM	
	P1229 Sensor power supply	
	• P1610 - P1615 NATS	
	P1700 CVT control system	
	P1706 Park/Neutral position (PNP) switch	
	P2122 P2123 P2127 P2128 P2138 Accelerator pedal position sensor	
2	P0138 P0158 Heated oxygen sensor 2	
	P0550 Power steering pressure sensor	
	• P1031 P1032 P1051 P1052 A/F sensor 1 heater	
	P1065 ECM power supply	
	P1111 P1136 Intake valve timing control solenoid valve	
	P1122 Electric throttle control function	
	P1124 P1126 P1128 Electric throttle control actuator	
	• P1217 Engine over temperature (OVERHEAT)	
	• P1271 P1272 P1276 P1281 P1282 P1286 A/F sensor 1	
	P1720 Vehicle speed sensor	
	P1805 Brake switch	
3	P0011 P0021 Intake valve timing control	
	P1121 Electric throttle control actuator	
	P1211 TCS control unit	
	P1212 TCS communication line	
	P1564 ASCD steering switch	
	P1572 ASCD brake switch	
	P1574 ASCD vehicle speed sensor	
	<ul> <li>P1715 Primary speed sensor</li> </ul>	

ABS00GT0

#### **Fail-Safe Chart**

ABS00GT1

When the DTC listed below is detected, the ECM enters fail-safe mode and the MIL lights up.

DTC No.	Detected items	Engine opera	ating condition in fail-safe mode
P0102 P0103	Mass air flow sensor circuit	Engine speed will not rise more than 2,400 rpm due to the fuel cut.	
P0122 P0123 P0222 P0223 P2135	Throttle position sensor	The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees. The ECM regulates the opening speed of the throttle valve to be slower than the normal condition. So, the acceleration will be poor.	
actuator		malfunction:)	tor does not function properly due to the return spring ctuator by regulating the throttle opening around the I not rise more than 2,000 rpm.
	(When throttle valve opening angle in fail-safe mode is not in specified range:) ECM controls the electric throttle control actuator by regulating the throttle opening to 20 degrees or less.		
	the engine stalls.	ive is stuck open:) s down gradually by fuel cut. After the vehicle stops, sition, and engine speed will not exceed 1,000 rpm or	
P1122	Electric throttle control function	ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.	
P1124 P1126	Throttle control motor relay	ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.	
P1128	Throttle control motor	ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.	
P1229	Sensor power supply	ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.	
P1805	Brake switch	ECM controls the electric throttle co small range. Therefore, acceleration will be poor	ontrol actuator by regulating the throttle opening to a r.
		Vehicle condition	Driving condition
		When engine is idling	Normal
		When accelerating	Poor acceleration
P2122 P2123 P2127 P2128 P2138	Accelerator pedal position sensor	order for the idle position to be with	tle control actuator in regulating the throttle opening ir hin +10 degrees. eed of the throttle valve to be slower than the normal

 When there is an open circuit on MIL circuit, the ECM cannot warn the driver by lighting up MIL when there is malfunction on engine control system.
 Therefore, when electrical controlled throttle and part of ECM related diagnoses are continuously detected as NG for 5 trips, ECM warns the driver that engine control system malfunctions and MIL circuit is open by


means of operating fail-safe function. The fail-safe function also operates when above diagnoses except MIL circuit are detected and demands the driver to repair the malfunction.


Engine speed will not rise more than 2,500 rpm due to the fuel cut
I

## **Basic Inspection**

#### 1. INSPECTION START

- 1. Check service records for any recent repairs that may indicate a related malfunction, or a current need for scheduled maintenance.
- 2. Open engine hood and check the following:
- Harness connectors for improper connections
- Wiring harness for improper connections, pinches and cut
- Vacuum hoses for splits, kinks and improper connections \_
- Hoses and ducts for leaks
- Air cleaner clogging
- Gasket
- 3. Confirm that electrical or mechanical loads are not applied.
- Headlamp switch is OFF.
- Air conditioner switch is OFF.
- Rear window defogger switch is OFF.
- Steering wheel is in the straight-ahead position, etc.
- 4. Start engine and warm it up until engine coolant temperature indicator points the middle of gauge. Ensure engine stays below 1,000 rpm.






- Run engine at about 2,000 rpm for about 2 minutes under no-5. load.
- 6. Make sure that no DTC is displayed with CONSULT-II or ECM [Diagnostic Test Mode II (Self-diagnostic results)].

#### OK or NG


OK	>> GO TO 3.
NG	>> GO TO 2.



## 2. REPAIR OR REPLACE

Repair or replace components as necessary.

>> GO TO 3.



Z50

ABS00H2M


А

F

## 3. CHECK TARGET IDLE SPEED

#### (P) With CONSULT-II

- 1. Run engine at about 2,000 rpm for about 2 minutes under no-load.
- 2. Rev engine (2,000 to 3,000 rpm) two or three times under noload, then run engine at idle speed for about 1 minute.



NO DTC

SEF058

XXX rpm

3. Read idle speed in "DATA MONITOR" mode with CONSULT-II. DATA MONITOR  $625 \pm 50$  rpm (in P or N position) MONITOR ENG SPEED

#### **Without CONSULT-II**

- 1. Run engine at about 2,000 rpm for about 2 minutes under no-load.
- Rev engine (2,000 to 3,000 rpm) two or three times under no-load, then run engine at idle speed for about 2. 1 minute.
- Check idle speed. 3.

#### $625 \pm 50$ rpm (in P or N position)

#### OK or NG

OK >> GO TO 10. NG >> GO TO 4.

#### 4. PERFORM ACCELERATOR PEDAL RELEASED POSITION LEARNING

- 1. Stop engine.
- 2. Perform Accelerator Pedal Released Position Learning.

>> GO TO 5.

#### 5. PERFORM THROTTLE VALVE CLOSED POSITION LEARNING

Perform Throttle Valve Closed Position Learning.

>> GO TO 6.

#### 6

Perform Idle Air Volume Learning. s Idle Air Volume Learning carried out successfully?	
<u>Yes or No</u> Yes >> GO TO 7.	
No >> 1. Follow the instruction of Idle Air Volume Learning. 2. GO TO 4.	
7. CHECK TARGET IDLE SPEED AGAIN	
With CONSULT-II	
<ol> <li>Start engine and warm it up to normal operating temperature.</li> <li>Read idle speed in "DATA MONITOR" mode with CONSULT-II.</li> </ol>	
$625 \pm 50$ rpm (in P or N position)	DATA MONITOR MONITOR NO DTC
<ul> <li>Without CONSULT-II</li> <li>Start engine and warm it up to normal operating temperature.</li> <li>Check idle speed.</li> </ul>	ENG SPEED XXX rpm COOLAN TEMP/S XXX 'C
625 $\pm$ 50 rpm (in P or N position)	
DK or NG OK >> GO TO 10. NG >> GO TO 8.	SEF174Y
3. DETECT MALFUNCTIONING PART	
<ul> <li>Check the following.</li> <li>Check camshaft position sensor (PHASE) and circuit. Refer to EC</li> <li>Check crankshaft position sensor (POS) and circuit. Refer to EC-3</li> <li>OK or NG</li> <li>OK &gt;&gt; GO TO 9.</li> <li>NG &gt;&gt; 1. Repair or replace.</li> <li>2. GO TO 4.</li> </ul>	
9. CHECK ECM FUNCTION	


2. Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to <u>BL-116</u>, "NATS(Nissan Anti-Theft System)"

>> GO TO 4.

## 10. CHECK IGNITION TIMING

- 1. Run engine at idle.
- 2. Check ignition timing with a timing light.

15  $\pm$  5° BTDC (in P or N position)



#### OK or NG

#### OK >> INSPECTION END

NG >> GO TO 11.

## 11. PERFORM ACCELERATOR PEDAL RELEASED POSITION LEARNING

- 1. Stop engine.
- 2. Perform Accelerator Pedal Released Position Learning.

>> GO TO 12.

## 12. PERFORM THROTTLE VALVE CLOSED POSITION LEARNING

Perform Throttle Valve Closed Position Learning.

>> GO TO 13.

## 13. PERFORM IDLE AIR VOLUME LEARNING

Perform Idle Air Volume Learning.

Is Idle Air Volume Learning carried out successfully?

Yes or No

- Yes >> GO TO 14.
- No >> 1. Follow the instruction of Idle Air Volume Learning.

2. GO TO 4.

## 14. CHECK TARGET IDLE SPEED AGAIN

#### With CONSULT-II

- 1. Start engine and warm it up to normal operating temperature.
- 2. Read idle speed in "DATA MONITOR" mode with CONSULT-II.

#### 625 $\pm$ 50 rpm (in P or N position)

#### **Without CONSULT-II**

- 1. Start engine and warm it up to normal operating temperature.
- 2. Check idle speed.

#### 625 $\pm$ 50 rpm (in P or N position)


#### OK or NG

OK >> GO TO 15. NG >> GO TO 17.

## 15. CHECK IGNITION TIMING AGAIN

- 1. Run engine at idle.
- 2. Check ignition timing with a timing light.

#### $15\pm5^\circ$ BTDC (in P or N position)



OK or NG

OK >> INSPECTION END

NG >> GO TO 16.

#### 16. CHECK TIMING CHAIN INSTALLATION

Check timing chain installation. Refer to EM-19, "TIMING CHAIN" .

OK or NG

OK >> GO TO 17.

- NG >> 1. Repair the timing chain installation.
  - 2. GO TO 4.

## 17. DETECT MALFUNCTIONING PART

Check the following.

- Check camshaft position sensor (PHASE) and circuit. Refer to EC-385 .
- Check crankshaft position sensor (POS) and circuit. Refer to EC-381 .

#### OK or NG

OK >> GO TO 18. NG >> 1. Repair or replace. 2. GO TO 4. 

 DATA MONITOR
 NO DTC

 MONITOR
 NO DTC

 ENG SPEED
 XXX rpm

 COOLAN TEMP/S
 XXX 'C

 B
 SEF174Y

|

Н

F

K

Z50

## 18. CHECK ECM FUNCTION

- 1. Substitute another known-good ECM to check ECM function. (ECM may be the cause of an incident, but this is a rare case.)
- 2. Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to <u>BL-116,</u> <u>"NATS(Nissan Anti-Theft System)"</u>.

>> GO TO 4.

#### Symptom Matrix Chart SYSTEM — BASIC ENGINE CONTROL SYSTEM

ABS00GT2

		SYMPTOM												
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)
Warrant	y symptom code	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA
Fuel	Fuel pump circuit	1	1	2	3	2		2	2			3		2
	Fuel pressure regulator system	3	3	4	4	4	4	4	4	4		4		
	Injector circuit	1	1	2	3	2		2	2			2		
	Evaporative emission system	3	3	4	4	4	4	4	4	4		4		
Air	Positive crankcase ventilation system	3	3	4	4	4	4	4	4	4		4	1	
	Incorrect idle speed adjustment		5				1	1	1	1		1		
	Electric throttle control actuator	1	1	2	3	3	2	2	2	2		2		2
Ignition	Incorrect ignition timing adjustment	3	3	1	1	1		1	1			1		
	Ignition circuit	1	1	2	2	2		2	2			2		
Power s	upply and ground circuit	2	2	3	3	3		3	3		2	3		
Mass ai	r flow sensor circuit	1			2									
Engine	coolant temperature sensor circuit		1	2	3	2	3	2	2	3		2		
Air fuel I	ratio (A/F) sensor 1 circuit			2	5	2		2	2			2		
Throttle	position sensor circuit						2			2				
Accelera	ator pedal position sensor circuit			3	2	1	2			2				
Knock s	ensor circuit			2								3		
Cranksh	aft position sensor (POS) circuit	2	2											
Camsha	ft position sensor (PHASE) circuit	3	2											
Vehicle	speed signal circuit		2	3		3						3		
Power s	teering pressure sensor circuit		2					3	3					
ECM		2	2	3	3	3	3	3	3	3	3	3		
Intake v	alve timing control solenoid valve circuit		3	2		1	3	2	2	3		3		
Park/ne	utral position switch circuit			3		3		3	3			3		

Revision: 2006 December

						S	YMPT	OM						
	3				NOI					HIGH				A
	(EXCP. HA)		SPOT		ACCELERATION					ATURE	NOI	z	(GE)	EC
	HARD/NO START/RESTART (E)	ENGINE STALL	HESITATION/SURGING/FLAT SI	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCE	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)	C
Warranty symptom code	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	•
VIAS control solenoid valve circuit					1									F
Refrigerant pressure sensor circuit		2				3			3		4			•
Electrical load signal circuit							3							G
Air conditioner circuit	2	2	3	3	3	3	3	3	3		3		2	
ABS actuator and electric unit (control unit)			4											

1 - 6: The numbers refer to the order of inspection.

(continued on next page)

#### **SYSTEM — ENGINE MECHANICAL & OTHER**

							S`	YMPT	ОМ						
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDRE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)	
Warranty	y symptom code	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Fuel	Fuel tank	5													
	Fuel piping	J		5	5	5		5	5			5			
	Vapor lock		5												
	Valve deposit														
	Poor fuel (Heavy weight gasoline, Low octane)	5		5	5	5		5	5			5			

J

Κ

L

Μ

		SYMPTOM												
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)
Warranty s	ymptom code	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA
Air	Air duct													
	Air cleaner													
	Air leakage from air duct (Mass air flow sensor — electric throttle control actuator) Electric throttle control actuator	5	5	5	5	5	5	5	5	5	-	5		
	Air leakage from intake manifold/Collec- tor/Gasket													
Cranking	Battery	_ 1	1	1		1		1	1					1
	Generator circuit					1		1						1
	Starter circuit	3 6										1		
	Signal plate													
	PNP switch	4												
Engine	Cylinder head	_	_	_	_	-		-	_			_		
	Cylinder head gasket	- 5	5	5	5	5		5	5		4	5	3	
	Cylinder block						-			-				
	Piston												4	
	Piston ring		0	0	0	0		0				-		
	Connecting rod	- 6	6	6	6	6		6	6			6		
	Bearing	-												
	Crankshaft	-												
Valve	Timing chain													
mecha- nism	Camshaft													
	Intake valve timing control	5	5	5	5	5		5	5			5		
	Intake valve												2	
	Exhaust valve	1											3	
Exhaust	Exhaust manifold/Tube/Muffler/Gasket	5	5	5	5	5		5	5			5		
	Three way catalyst		5	5	5	5		5	5			5		
Lubrica- tion	Oil pan/Oil strainer/Oil pump/Oil filter/Oil gallery/Oil cooler	5	5	5	5	5		5	5			5		
ŀ	Oil level (Low)/Filthy oil													

							S	YMPT	OM						
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)	EC C D
Warranty	symptom code	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Cooling	Radiator/Hose/Radiator filler cap														F
	Thermostat									5					
	Water pump	- -	5	5	5	5		5	5		4	Б			G
	Water gallery	5	5	5	5			5	5		4	5			
	Cooling fan	-								5					
	Coolant level (Low)/Contaminated coolant									5					Н
NATS (Nis	ssan Anti-theft system)	1	1												

1 - 6: The numbers refer to the order of inspection.

Κ


L

Μ


J

#### **Engine Control Component Parts Location**





PBIB2666E



PBIB2667E

А

С

D

Е

F


G

Н


J

Κ

L





PBIB2669E




PBIB2670E


EC-32











PBIB2290E











PBIB2671E

**EC-34** 

F

G

Н

I


J

Κ

L

Μ

ABS00GT4




NOTE: Do not use soapy water or any type of solvent while installing vacuum hose or purge hoses.

Refer to EC-279, "System Diagram" for Vacuum Control System.


PBIB1754E

EC-35






ABS00GT5




TBWB1172E

## ECM Harness Connector Terminal Layout




# ECM Terminals and Reference Value PREPARATION

- 1. ECM is located behind the glove box. For this inspection, remove glove box.
- 2. Remove ECM harness connector.



- 4. Connect a break-out box (SST) and Y-cable adapter (SST) between the ECM and ECM harness connector.
  - Use extreme care not to touch 2 pins at one time.
  - Data is for comparison and may not be exact.



ABS00GT6


ABS00GT7

F

E

Н

Μ



### ECM INSPECTION TABLE

Specification data are reference values and are measured between each terminal and ground. Pulse signal is measured by CONSULT-II.

#### **CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECMs transistor. Use a ground other than ECM terminals, such as the ground.

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
1	В	ECM ground	[Engine is running] • Idle speed	Body ground
2	G/B	A/F sensor 1 heater (bank 1)	[Engine is running] • Warm-up condition • Idle speed	Approximately 5V★

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
3	R	Throttle control motor relay power supply	[Ignition switch: ON]	BATTERY VOLTAGE (11 - 14V)
4	G	Throttle control motor (Close)	[Ignition switch: ON] • Engine stopped • Shift lever: D • Accelerator pedal: Fully released	0 - 14V★
5	R	Throttle control motor (Open)	[Ignition switch: ON] • Engine stopped • Shift lever: D • Accelerator pedal: Fully depressed	0 - 14V★
6	L/R	Heated oxygen sensor 2 heater (bank 2)	<ul> <li>[Engine is running]</li> <li>Engine speed is below 3,600 rpm after the following conditions are met.</li> <li>Engine: After warming up</li> <li>Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load.</li> <li>[Ignition switch: ON]</li> <li>Engine stopped</li> <li>[Engine is running]</li> <li>Engine speed is above 3,600 rpm.</li> </ul>	0 - 1.0V BATTERY VOLTAGE (11 - 14V)
10	Y	Intake valve timing control solenoid valve (bank 2)	<ul> <li>[Engine is running]</li> <li>Warm-up condition</li> <li>Idle speed</li> <li>[Engine is running]</li> <li>Warm-up condition</li> <li>Engine speed is 2,000 rpm.</li> </ul>	BATTERY VOLTAGE (11 - 14V) 7 - 12V★
11	Ρ	Intake valve timing control solenoid valve (bank 1)	<ul> <li>[Engine is running]</li> <li>Warm-up condition</li> <li>Idle speed</li> <li>[Engine is running]</li> <li>Warm-up condition</li> <li>Engine speed is 2,000 rpm.</li> </ul>	BATTERY VOLTAGE (11 - 14V) 7 - 12V★

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)	A
12	W	Power steering pressure sen-	<ul><li>[Engine is running]</li><li>Steering wheel is being turned.</li></ul>	0.5 - 4.5V	EC
12	vv	sor	<ul><li>[Engine is running]</li><li>Steering wheel is not being turned.</li></ul>	0.4 - 0.8V	
		W Crankshaft position sensor (POS)	[Engine is running] • Warm-up condition • Idle speed NOTE: The pulse cycle changes depending on rpm at idle.	Approximately 1.6V★	C D E
13	v				Approximately 1.4V★
	14 W	Camshaft position sensor (PHASE) (bank 2)	<ul> <li>[Engine is running]</li> <li>Warm-up condition</li> <li>Idle speed</li> <li>NOTE:</li> <li>The pulse cycle changes depending on rpm at idle.</li> </ul>	1.0 - 4.0V★	H I J
14			(PHASE) (bank 2)	[Engine is running] • Engine speed is 2,000 rpm.	1.0 - 4.0V★
15	W	Knock sensor	[Engine is running] • Idle speed	Approximately 2.5V	M
16	LG/B			Approximately 3.1V	-
35	O/L		[Engine is running]	Approximately 2.6V	-
56	BR/Y	A/F sensor 1 (Bank 1)	Warm-up condition     Idle speed	Approximately 2.3V	-
75	Y/R			Approximately 2.3V	

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
21	L/W	L/W Injector No. 5 R/Y Injector No. 3 R/B Injector No. 1	<ul> <li>[Engine is running]</li> <li>Warm-up condition</li> <li>Idle speed</li> <li>NOTE:</li> <li>The pulse cycle changes depending on rpm at idle.</li> </ul>	BATTERY VOLTAGE (11 - 14V)★
22 23				
24	V	A/F sensor 1 heater (Bank 2)	[Engine is running] • Warm-up condition • Idle speed	Approximately 5V★
25	P/L	Heated oxygen sensor 2 heater (bank 1)	<ul> <li>[Engine is running]</li> <li>Engine speed is below 3,600 rpm after the following conditions are met.</li> <li>Engine: After warming up</li> <li>Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load.</li> <li>[Ignition switch: ON]</li> <li>Engine stopped</li> <li>[Engine is running]</li> </ul>	0 - 1.0V BATTERY VOLTAGE (11 - 14V)
29	G/Y	VIAS control solenoid valve	<ul> <li>Engine speed is above 3,600 rpm.</li> <li>[Engine is running]</li> <li>Idle speed</li> <li>[Engine is running]</li> <li>Engine speed is between 1,800 and 3,600 rpm.</li> </ul>	BATTERY VOLTAGE (11 - 14V) 0 - 1.0V

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)	А
	33 Y	Camshaft position sensor (PHASE) (bank 1)	<ul> <li>[Engine is running]</li> <li>Warm-up condition</li> <li>Idle speed</li> <li>NOTE:</li> <li>The pulse cycle changes depending on rpm at idle.</li> </ul>	1.0 - 4.0V★	EC C
33			[Engine is running] • Engine speed is 2,000 rpm.	1.0 - 4.0V★	E
34	Y/G	Intake air temperature sensor	[Engine is running]	Approximately 0 - 4.8V Output voltage varies with intake air temperature.	G
40	40       R/G       Injector No. 6         41       L/Y       Injector No. 4         42       W/L       Injector No. 2         Injector No. 2       Injector No. 2	Injector No. 4	<ul> <li>Warm-up condition</li> <li>Idle speed</li> <li>NOTE:</li> <li>The pulse cycle changes depending on rpm</li> </ul>	BATTERY VOLTAGE (11 - 14V)★	H
				BATTERY VOLTAGE (11 - 14V)★	K
44	BR/W	Electronic controlled engine mount-1	<ul> <li>[Engine is running]</li> <li>Engine speed is above 950 rpm.</li> <li>[Engine is running]</li> <li>For 2 seconds after engine speed is 950 rpm or less.</li> <li>[Engine is running]</li> <li>2 seconds after engine speed is 950 rpm or less.</li> </ul>	BATTERY VOLTAGE (11 - 14V) 0 - 1.0V 2.0 - 3.0V	M

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
			[Engine is running] • Idle speed	BATTERY VOLTAGE (11 - 14V)★
45	45 GR/L EVAP c control s	control solenoid valve	<ul> <li>[Engine is running]</li> <li>Engine speed is about 2,000 rpm (More than 100 seconds after starting engine).</li> </ul>	BATTERY VOLTAGE (11 - 14V)★
47	G	Sensor power supply (Throt- tle position sensor)	[Ignition switch: ON]	Approximately 5V
49	R/W	Sensor power supply (Refrigerant pressure sensor)	[Ignition switch: ON]	Approximately 5V
50	W	Throttle position sensor 1	<ul> <li>[Ignition switch: ON]</li> <li>Engine stopped</li> <li>Shift lever: D</li> <li>Accelerator pedal: Fully released</li> </ul>	More than 0.36V
50	v		<ul> <li>[Ignition switch: ON]</li> <li>Engine stopped</li> <li>Shift lever: D</li> <li>Accelerator pedal: Fully depressed</li> </ul>	Less than 4.75V
			[Ignition switch: ON]	Approximately 0.4V
51	G/W	/W Mass air flow sensor	<ul><li>[Engine is running]</li><li>Warm-up condition</li><li>Idle speed</li></ul>	0.9 - 1.2V
	0.11		<ul> <li>[Engine is running]</li> <li>Warm-up condition</li> <li>Engine is revving from idle to about 4,000 rpm</li> </ul>	0.9 - 1.2 to Approximately 2.4V (Check for linear voltage rise in response to engine being increased to about 4,000 rpm)
55	W	Heated oxygen sensor 2 (bank 2)	<ul> <li>[Engine is running]</li> <li>Revving engine from idle to 3,000 rpm quickly after the following conditions are met</li> <li>Engine: After warming up</li> <li>Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul>	0 - Approximately 1.0V
57	Р			Approximately 2.6V
58	SB	A/E concert (Damis 2)	[Engine is running]	Approximately 2.3V
76	G/Y	A/F sensor 1 (Bank 2)	<ul> <li>Warm-up condition</li> <li>Idle speed</li> </ul>	Approximately 3.1V
77	LG			Approximately 2.3V

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)	А
60	BR/R	Ignition signal No. 5	<ul> <li>[Engine is running]</li> <li>Warm-up condition</li> <li>Idle speed</li> <li>NOTE:</li> <li>The pulse cycle changes depending on rpm at idle.</li> </ul>	0 - 0.3V★	EC C
61 62	L/R Y/R	Ignition signal No. 3 Ignition signal No. 1	<ul> <li>[Engine is running]</li> <li>Warm-up condition</li> <li>Engine speed is 2,500 rpm.</li> </ul>	0.1 - 0.6V★	D E F
63	W/R	Electronic controlled engine mount-2	<ul> <li>[Engine is running]</li> <li>Engine speed is below 950 rpm.</li> <li>[Engine is running]</li> <li>For 2 seconds after engine speed is 950 rpm or more.</li> </ul>	BATTERY VOLTAGE (11 - 14V) 0 - 1.0V	G
			<ul> <li>[Engine is running]</li> <li>2 seconds after engine speed is 950 rpm or more.</li> </ul>	2.0 - 3.0V	H
66	В	Sensor ground (Throttle position sensor)	[Engine is running]  • Warm-up condition  • Idle speed	Approximately 0V	J
67	В	Sensor ground	[Engine is running] • Warm-up condition • Idle speed	Approximately 0V	K
68	W/G	Sensor power supply (PSP sensor)	[Ignition switch: ON]	Approximately 5V	
69	R	Throttle position sensor 2	<ul> <li>[Ignition switch: ON]</li> <li>Engine stopped</li> <li>Shift lever: D</li> <li>Accelerator pedal: Fully released</li> </ul>	Less than 4.75V	M
	, i		<ul> <li>[Ignition switch: ON]</li> <li>Engine stopped</li> <li>Shift lever: D</li> <li>Accelerator pedal: Fully depressed</li> </ul>	More than 0.36V	
70	W	Refrigerant pressure sensor	<ul> <li>[Engine is running]</li> <li>Warm-up condition</li> <li>Both A/C switch and blower fan switch are ON (Compressor operates.)</li> </ul>	1.0 - 4.0V	_
73	Y/B	Engine coolant temperature sensor	[Engine is running]	Approximately 0 - 4.8V Output voltage varies with engine coolant temperature.	

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
74	W	Heated oxygen sensor 2 (bank 1)	<ul> <li>[Engine is running]</li> <li>Revving engine from idle to 3,000 rpm quickly after the following conditions are met</li> <li>Engine: After warming up</li> <li>Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul>	0 - Approximately 1.0V
78	В	Sensor ground (Heated oxygen sensor 2)	<ul> <li>[Engine is running]</li> <li>Warm-up condition</li> <li>Idle speed</li> </ul>	Approximately 0V
79 80 81	GR/R GR G/R	Ignition signal No. 6 Ignition signal No. 4 Ignition signal No. 2	<ul> <li>[Engine is running]</li> <li>Warm-up condition</li> <li>Idle speed</li> <li>NOTE:</li> <li>The pulse cycle changes depending on rpm at idle.</li> <li>[Engine is running]</li> <li>Warm-up condition</li> <li>Engine speed is 2,500 rpm.</li> </ul>	0 - 0.3V★ 
82	В	Sensor ground (APP sensor 1)	[Engine is running] • Warm-up condition • Idle speed	Approximately 0V
83	G	Sensor ground (APP sensor 2)	[Engine is running] • Warm-up condition • Idle speed	Approximately 0V
85	0	Data link connector	[Ignition switch: ON] • CONSULT-II is disconnected.	Approximately 5V - Battery volt- age (11 - 14V)
86	Р	CAN communication line	[Ignition switch: ON]	Approximately 1.1 - 2.3V Output voltage varies with the communication status
90	R/W	Sensor power supply (APP sensor 1)	[Ignition switch: ON]	Approximately 5V
91	Р	Sensor power supply (APP sensor 2)	[Ignition switch: ON]	Approximately 5V
94	L	CAN communication line	[Ignition switch: ON]	Approximately 2.6 - 3.2V Output voltage varies with the communication status.
98	W/R	Accelerator pedal position sensor 2	[Ignition switch: ON]         • Engine stopped         • Accelerator pedal: Fully released         [Ignition switch: ON]         • Engine stopped         • Accelerator pedal: Fully depressed	0.25 - 0.5V 2.0 - 2.5V

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
			[Ignition switch: ON] • ASCD steering switch: OFF	Approximately 4V
			[Ignition switch: ON] • MAIN switch: Pressed	Approximately 0V
99	G/Y	ASCD steering switch	[Ignition switch: ON] • CANCEL switch: Pressed	Approximately 1V
			[Ignition switch: ON] • RESUME/ACCELERATE switch: Pressed	Approximately 3V
			[Ignition switch: ON] • SET/COAST switch: Pressed	Approximately 2V
101	R/G	Stop lamp switch	[Ignition switch: OFF] • Brake pedal: Fully released	Approximately 0V
			[Ignition switch: OFF] • Brake pedal: Slightly Depressed	BATTERY VOLTAGE (11 - 14V)
102	G/W	PNP switch	[Ignition switch: ON] • Shift lever: P or N	Approximately 0V
			[Ignition switch: ON] • Except above position	BATTERY VOLTAGE (11 - 14V)
104	P/L	Throttle control motor relay	[Ignition switch: OFF] [Ignition switch: ON]	BATTERY VOLTAGE (11 - 14V) 0 - 1.0V
			[Ignition switch: ON]	0-1.00
	106 W Accelerator pedal posit sensor 1	W Accelerator pedal position	<ul> <li>Engine stopped</li> <li>Accelerator pedal: Fully released</li> </ul>	0.5 - 1.0V
106			[Ignition switch: ON] • Engine stopped • Accelerator pedal: Fully Depressed	4.2 - 4.8V
400	L /D		[Ignition switch: ON] • Brake pedal: Slightly Depressed	Approximately 0V
108	L/B	ASCD brake switch	[Ignition switch: ON] • Brake pedal: Fully released	BATTERY VOLTAGE (11 - 14V)
			[Ignition switch: OFF]	0V
109	R	Ignition switch	[Ignition switch: ON]	BATTERY VOLTAGE (11 - 14V)
111	111 W/B	ECM relay (Self shut-off)	<ul> <li>[Engine is running]</li> <li>[Ignition switch: OFF]</li> <li>For a few seconds after turning ignition switch OFF</li> </ul>	0 - 1.5V
		(Self shut-off)	(Self shut-off)	<ul> <li>[Ignition switch: OFF]</li> <li>More than a few seconds after turning ignition switch OFF</li> </ul>
113	B/P	Fuel pump relay	<ul> <li>[Ignition switch: ON]</li> <li>For 1 second after turning ignition switch ON.</li> <li>[Engine is running]</li> </ul>	0 - 1.5V
			<ul> <li>[Ignition switch: ON]</li> <li>More than 1 second after turning ignition switch ON.</li> </ul>	BATTERY VOLTAGE (11 - 14V)

EC-46

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
115 116	B B	ECM ground	[Engine is running] • Idle speed	Body ground
119 120	R/B R/B	Power supply for ECM	[Ignition switch: ON]	BATTERY VOLTAGE (11 - 14V)
121	W/L	Power supply for ECM (Back- up)	[Ignition switch: OFF]	BATTERY VOLTAGE (11 - 14V)

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

## **CONSULT-II** Reference Value in Data Monitor

Remarks:

• Specification data are reference values.

 Specification data are reference values.
 Specification data are output/input values which are detected or supplied by the ECM at the connector.
 \* Specification data may not be directly related to their components signals/values/operations.
 i.e. Adjust ignition timing with a timing light before monitoring IGN TIMING, because the monitor may show the specification data in spite of the ignition timing not being adjusted to the specification data. This IGN TIMING monitors the data calculated by the ECM at the connector. EC

MONITOR ITEM	CONDITION		SPECIFICATION
ENG SPEED	Run engine and compare CONSL tion.	JLT-II value with the tachometer indica-	Almost the same speed as the tachometer indication.
MAS A/F SE-B1	• See EC-328, "TROUBLE DIAGNO	DSIS - SPECIFICATION VALUE".	
B/FUEL SCHDL	• See EC-328, "TROUBLE DIAGNO	DSIS - SPECIFICATION VALUE".	
A/F ALPHA-B1 A/F ALPHA-B2	• See EC-328, "TROUBLE DIAGNO	OSIS - SPECIFICATION VALUE".	
COOLAN TEMP/S	Engine: After warming up		More than 70°C (158°F)
A/F SEN1 (B1) A/F SEN1 (B2)	• Engine: After warming up	Maintaining engine speed at 2,000 rpm	Fluctuates around 1.5 V
HO2S2 (B1) HO2S2 (B2)	<ul> <li>Revving engine from idle to 3,000 tions are met</li> </ul>	rpm quickly after the following condi-	0 - 0.3V ←→ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1) HO2S2 MNTR (B2)	<ul> <li>Engine: After warning up</li> <li>Keeping the engine speed betwee at idle for 1 minute under no load</li> </ul>	en 3,500 and 4,000 rpm for 1 minute and	$LEAN \longleftrightarrow RICH$
VHCL SPEED SE	• Turn drive wheels and compare C indication.	ONSULT-II value with the speedometer	Almost the same speed as the speedometer indication
BATTERY VOLT	Ignition switch: ON (Engine stopp)	ed)	11 - 14V
ACCEL SEN 1	Ignition switch: ON	Accelerator pedal: Fully released	0.5 - 1.0V
ACCEL SEN 2*	(Engine stopped)	Accelerator pedal: Fully depressed	4.2 - 4.8V
THRTL SEN 1	Ignition switch: ON	Accelerator pedal: Fully released	More than 0.36V
THRTL SEN 1 THRTL SEN 2*	<ul><li>(Engine stopped)</li><li>Shift lever: D</li></ul>	Accelerator pedal: Fully depressed	Less than 4.75V
START SIGNAL	• Ignition switch: $ON \rightarrow START \rightarrow O$	N	$OFF \rightarrow ON \rightarrow OFF$
CLSD THL POS	Ignition switch: ON     (Engine stopped)	Accelerator pedal: Fully released	ON
CESD THE FUS		Accelerator pedal: Slightly depressed	OFF
	<ul> <li>Engine: After warming up, idle</li> </ul>	Air conditioner switch: OFF	OFF
AIR COND SIG	the engine	Air conditioner switch: ON (Compressor operates.)	ON
P/N POSI SW	Ignition switch: ON	Shift lever: P or N	ON
		Shift lever: Except above	OFF
PW/ST SIGNAL	• Engine: After warming up, idle	Steering wheel: Not being turned	OFF
W/ST SIGNAL	the engine	Steering wheel: Being turned	ON
LOAD SIGNAL	<ul> <li>Ignition switch: ON</li> </ul>	Rear window defogger switch is ON and/or lighting switch is in 2nd.	ON
LOAD SIGNAL		Rear window defogger switch is OFF and lighting switch is OFF.	OFF
IGNITION SW	• Ignition switch: $ON \rightarrow OFF \rightarrow ON$	•	$ON\toOFF\toON$
	• Engine: After warming up, idle	Heater fan is operating	ON
HEATER FAN SW	the engine	Heater fan is not operating	OFF
	• Ignition switch: ON	Brake pedal: Fully released	OFF
BRAKE SW	<ul> <li>Ignition switch: ON</li> </ul>	Brake pedal: Slightly depressed	ON

ABS00GT9

А

MONITOR ITEM	COI	NDITION	SPECIFICATION
	Engine: After warming up	Idle	2.0 - 3.0 msec
INJ PULSE-B1 INJ PULSE-B2	<ul> <li>Shift lever: P or N</li> <li>Air conditioner switch: OFF</li> <li>No load</li> </ul>	2,000 rpm	1.9 - 2.9 msec
	Engine: After warming up	Idle	13° - 18° BTDC
IGN TIMING	<ul> <li>Shift lever: P or N</li> <li>Air conditioner switch: OFF</li> <li>No load</li> </ul>	2,000 rpm	25° - 45° BTDC
	Engine: After warming up	Idle	0%
PURG VOL C/V	<ul> <li>Shift lever: P or N</li> <li>Air conditioner switch: OFF</li> <li>No load</li> </ul>	2,000 rpm	_
	Engine: After warming up	Idle	–5° - 5°CA
INT/V TIM (B1) INT/V TIM (B2)	<ul> <li>Shift lever: P or N</li> <li>Air conditioner switch: OFF</li> <li>No load</li> </ul>	2,000 rpm	Approx. 0° - 30°CA
	Engine: After warming up	Idle	0% - 2%
INT/V SOL (B1) INT/V SOL (B2)	<ul> <li>Shift lever: P or N</li> <li>Air conditioner switch: OFF</li> <li>No load</li> </ul>	2,000 rpm	Approx. 0% - 50%
	• Engine: After warming up	1,800 - 3,600 rpm	ON
VIAS S/V		Except above conditions	OFF
	• Engine: After warming up, idle the engine	Air conditioner switch: OFF	OFF
AIR COND RLY		Air conditioner switch: ON (Compressor operates)	ON
ENGINE MOUNT	<ul> <li>Engine: After warming up</li> </ul>	Below 950 rpm	IDLE
		Above 950 rpm	TRVL
FUEL PUMP RLY	<ul> <li>For 1 second after turning ignition</li> <li>Engine running or cranking</li> </ul>	n switch ON	ON
	Except above conditions		OFF
THRTL RELAY	Ignition switch: ON		ON
		Engine coolant temperature is 94°C (201°F) or less	OFF
COOLING FAN	<ul> <li>Engine: After warming up, idle the engine</li> <li>Air conditioner switch: OFF</li> </ul>	Engine coolant temperature is between 95°C (203°F) and 99°C (210°F)	LOW
		Engine coolant temperature is 100°C (212°F) or more	н
		after the following conditions are met.	
HO2S2 HTR (B1) HO2S2 HTR (B2)	<ul> <li>Engine: After warming up</li> <li>Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul>		ON
	• Engine speed: Above 3,600 rpm		OFF
I/P PULLY SPD	Vehicle speed: More than 20 km/h (12 MPH)		Almost the same speed as the tachometer indication
VEHICLE SPEED	• Turn drive wheels and compare C indication.	Almost the same speed as the speedometer indication	
A/F S1 HTR (B1) A/F S1 HTR (B2)	• Engine: After warming up, idle the	engine	0 - 100%

MONITOR ITEM	COM	NDITION	SPECIFICATION	٥
AC PRESS SEN	<ul> <li>Engine: Idle</li> <li>Both A/C switch and blower fan switch: ON (Compressor operates)</li> </ul>		1.0 - 4.0V	A
VHCL SPEED SE	• Turn drive wheels and compare C indication.	ONSULT-II value with the speedometer	Almost the same speed as the speedometer indication	EC
SET VHCL SPD	• Engine: Running	ASCD: Operating.	The preset vehicle speed is displayed.	C
MAIN SW	Ignition switch: ON	MAIN switch: Pressed	ON	0
MAIN SW		MAIN switch: Released	OFF	
		CANCEL switch: Pressed	ON	D
CANCEL SW	<ul> <li>Ignition switch: ON</li> </ul>	CANCEL switch: Released	OFF	
	Ignition switch: ON	RESUME/ACCELERATE switch: Pressed	ON	E
RESUME/ACC SW		RESUME/ACCELERATE switch: Released	OFF	
SET SW	Ignition switch: ON	SET/COAST switch: Pressed	ON	F
SETSW		SET/COAST switch: Released	OFF	
	Ignition switch: ON	Brake pedal: Fully released	ON	G
BRAKE SW1		Brake pedal: Slightly depressed	OFF	0
	Ignition switch: ON	Brake pedal: Fully released	OFF	
BRAKE SW2		Brake pedal: Slightly depressed	ON	Н
CRUISE LAMP	Ignition switch: ON	MAIN switch: Pressed at the 1st time $\rightarrow$ at the 2nd time	$ON\toOFF$	
	MAIN switch: ON	ASCD is operating	ON	
SET LAMP	<ul> <li>When vehicle speed is between 40 km/h (25 MPH) and 200 km/h (124 MPH)</li> </ul>	ASCD is not operating	OFF	J

\*: Accelerator pedal position sensor 2 signal and throttle position sensor 2 signal are converted by ECM internally. Thus, they differ from ECM terminals voltage signal.

Κ

L

Μ


## Major Sensor Reference Graph in Data Monitor Mode

The following are the major sensor reference graphs in "DATA MONITOR" mode.

### CLSD THL POS, ACCEL SEN 1, THRTL SEN 1


Below is the data for "CLSD THL POS", "ACCEL SEN 1" and "THRTL SEN 1" when depressing the accelerator pedal with the ignition switch ON and with selector lever in D position.

The signal of "ACCEL SEN 1" and "THRTL SEN 1" should rise gradually without any intermittent drop or rise after "CLSD THL POS" is changed from ON to OFF.




### ENG SPEED, MAS A/F SE-B1, THRTL SEN 1, HO2S2 (B1), INJ PULSE-B1

Below is the data for "ENG SPEED", "MAS A/F SE-B1", "THRTL SEN 1", "HO2S2 (B1)" and "INJ PULSE-B1" when revving engine quickly up to 4,800 rpm under no load after warming up engine sufficiently. Each value is for reference, the exact value may vary.



ABS00GTA



### **TROUBLE DIAGNOSIS - SPECIFICATION VALUE**

## Description

The specification (SP) value indicates the tolerance of the value that is displayed in "DATA MONITOR (SPEC)" mode of CONSULT-II during normal operation of the Engine Control System. When the value in "DATA MONI-TOR (SPEC)" mode is within the SP value, the Engine Control System is confirmed OK. When the value in "DATA MONITOR (SPEC)" mode is NOT within the SP value, the Engine Control System may have one or more malfunctions.

The SP value is used to detect malfunctions that may affect the Engine Control System, but will not light the MIL.

The SP value will be displayed for the following three items:

- B/FUEL SCHDL (The fuel injection pulse width programmed into ECM prior to any learned on board correction)
- A/F ALPHA-B1/B2 (The mean value of air-fuel ratio feedback correction factor per cycle)
- MAS A/F SE-B1 (The signal voltage of the mass air flow sensor)

## **Testing Condition**

- Vehicle driven distance: More than 5,000 km (3,107 miles)
- Barometric pressure: 98.3 104.3 kPa (0.983 1.043 bar, 1.003 1.064 kg/cm<sup>2</sup>, 14.25 15.12 psi)
- Atmospheric temperature: 20 30°C (68 86°F)
- Engine coolant temperature: 75 95°C (167 203°F)
- Transmission: Warmed-up\*1
- Electrical load: Not applied\*2
- Engine speed: Idle

\*1: After the engine is warmed up to normal operating temperature, drive vehicle until "ATF TEMP SEN" (CVT fluid temperature sensor signal) indicates more than 60°C (140°F).


\*2: Rear window defogger switch, air conditioner switch, lighting switch are OFF. Steering wheel is straight ahead.

## **Inspection Procedure**

### NOTE:

Perform "DATA MONITOR (SPEC)" mode in maximum scale display.

- 1. Perform EC-293, "Basic Inspection" .
- 2. Confirm that the testing conditions indicated above are met.
- Select "B/FUEL SCHDL", "A/F ALPHA-B1", "A/F ALPHA-B2" and "MAS A/F SE-B1" in "DATA MONITOR (SPEC)" mode with CONSULT-II.
- 4. Make sure that monitor items are within the SP value.
- 5. If NG, go to EC-329, "Diagnostic Procedure" .




PFP:00031

ARSONGTR


ABS00GTC

ABS00GTD



PBIB2268E

EC-54



PBIB3214E

#### DETAILED PROCEDURE А 1. CHECK "A/F ALPHA-B1", "A/F ALPHA-B2" 1. Start engine. EC 2. Confirm that the testing conditions are met. Refer to EC-328, "Testing Condition". 3. Select "A/F ALPHA-B1", "A/F ALPHA-B2" in "DATA MONITOR DATA MONITOR (SPEC) (SPEC)" mode, and make sure that the each indication is within MONITOR NO DTC the SP value. ENG SPEED XXX rpm NOTE: Check "A/F ALPHA-B1", "A/F ALPHA-B2" for approximately 1 1600 3200 4800 640 minute because they may fluctuate. It is NG if the indication is A/F ALPHA-B1 XX % out of the SP value even a little. 75 125 OK or NG 100 150 OK >> GO TO 17. F NG (Less than the SP value)>>GO TO 2. NG (More than the SP value)>>GO TO 3. PRIR2360F F 2. CHECK "B/FUEL SCHDL" Select "B/FUEL SCHDL" in "DATA MONITOR (SPEC)" mode, and DATA MONITOR (SPEC) make sure that the indication is within the SP value. MONITOR NO DTC OK or NG ENG SPEED XX rpm OK >> GO TO 4. NG (More than the SP value)>>GO TO 19. 1600 3200 4800 Н 640 B/FUEL SCHDL X.X msec 1000 3.8 1.3 0.0 25 5 0 PBIB2332E 1 3. CHECK "B/FUEL SCHDL" Select "B/FUEL SCHDL" in "DATA MONITOR (SPEC)" mode, and DATA MONITOR (SPEC) make sure that the indication is within the SP value. MONITOR NO DTC OK or NG ENG SPEED XX rpm OK >> GO TO 6. 1600 4800 NG (More than the SP value)>>GO TO 6. 3200 640 NG (Less than the SP value)>>GO TO 25. B/FUEL SCHDL X.X msec 188 1.3 1 0.0 2.5 3.8 5.0 Μ PBIB2332E

### 4. CHECK "A/F ALPHA-B1", "A/F ALPHA-B2"

- 1. Stop the engine.
- 2. Disconnect PCV hose, and then plug it.
- 3. Start engine.
- 4. Select "A/F ALPHA-B1", "A/F ALPHA-B2" in "DATA MONITOR (SPEC)" mode, and make sure that the each indication is within the SP value.

OK or NG

OK >> GO TO 5. NG >> GO TO 6.

### 5. CHANGE ENGINE OIL

- 1. Stop the engine.
- 2. Change engine oil.

### NOTE:

This symptom may occur when a large amount of gasoline is mixed with engine oil because of driving conditions (such as when engine oil temperature does not rise enough since a journey distance is too short during winter). The symptom will not be detected after changing engine oil or changing driving condition.

### >> INSPECTION END

## 6. CHECK FUEL PRESSURE

Check fuel pressure.

### OK or NG

OK >> GO TO 9.

NG (Fuel pressure is too high)>>Replace fuel pressure regulator. GO TO 8. NG (Fuel pressure is too low)>>GO TO 7.

## 7. DETECT MALFUNCTIONING PART

- 1. Check the following.
- Clogged and bent fuel hose and fuel tube
- Clogged fuel filter
- Fuel pump and its circuit (Refer to <u>EC-519, "FUEL PUMP CIRCUIT"</u>.)
- 2. If NG, repair or replace the malfunctioning part. If OK, replace fuel pressure regulator.

>> GO TO 8.

### 8. CHECK "A/F ALPHA-B1", "A/F ALPHA-B2"

### 1. Start engine.

2. Select "A/F ALPHA-B1", "A/F ALPHA-B2" in "DATA MONITOR (SPEC)" mode, and make sure that the each indication is within the SP value.

OK or NG

### OK >> INSPECTION END

NG >> GO TO 9.

### 9. PERFORM POWER BALANCE TEST

- 1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.
- 2. Make sure that the each cylinder produces a momentary engine speed drop.

### OK or NG

OK >> GO TO 12. NG >> GO TO 10.

ACTIVE TES	от.	1
	51	
POWER BALANCE		
MONITOF	1	
ENG SPEED	XXX rpm	
MAS A/F SE-B1	XXX V	
		PBIB0133E

10. DETECT MALFUNCTIONING PART	Δ
<ul> <li>Intake air leakage</li> <li>Low compression pressure</li> </ul>	EC
<ol> <li>If NG, repair or replace the malfunctioning part. If OK, replace fuel injector. (It may be caused by leakage from fuel injector or clogging.)</li> <li>&gt;&gt; GO TO 11.</li> <li>CHECK "A/F ALPHA-B1", "A/F ALPHA-B2"</li> </ol>	D
<ol> <li>Start engine.</li> <li>Select "A/F ALPHA-B1", "A/F ALPHA-B2" in "DATA MONITOR (SPEC)" mode, and make sure that the each indication is within the SP value.</li> <li><u>OK or NG</u></li> <li>OK &gt;&gt; INSPECTION END</li> <li>NG &gt;&gt; GO TO 12.</li> </ol>	E F
12. CHECK A/F SENSOR 1 FUNCTION	G
<ul> <li>Perform all DTC Confirmation Procedure related with A/F sensor 1.</li> <li>For DTC P1271, P1281, refer to <u>EC-439, "DTC Confirmation Procedure"</u>.</li> <li>For DTC P1272, P1282, refer to <u>EC-445, "DTC Confirmation Procedure"</u>.</li> <li>For DTC P1276, P1286, refer to <u>EC-452, "Overall Function Check"</u>.</li> <li>OK or NG</li> </ul>	H
OK >> GO TO 15. NG >> GO TO 13. <b>13. CHECK A/F SENSOR 1 CIRCUIT</b>	J
Perform Wiring Diagram according to corresponding DTC. >> GO TO 14. 14. СНЕСК "А/F ALPHA-B1", "A/F ALPHA-B2"	K
<ol> <li>Start engine.</li> <li>Select "A/F ALPHA-B1", "A/F ALPHA-B2" in "DATA MONITOR (SPEC)" mode, and make sure that the each indication is within the SP value.</li> <li><u>OK or NG</u></li> <li>OK &gt;&gt; INSPECTION END</li> <li>NG &gt;&gt; GO TO 15.</li> <li>15. DISCONNECT AND RECONNECT ECM HARNESS CONNECTOR</li> </ol>	Μ

- 1. Stop the engine.
- 2. Disconnect ECM harness connector. Check pin terminal and connector for damage, and then reconnect it.

>> GO TO 16.

## 16. CHECK "А/F ALPHA-B1", "А/F ALPHA-B2"

### 1. Start engine.

2. Select "A/F ALPHA-B1", "A/F ALPHA-B2" in "DATA MONITOR (SPEC)" mode, and make sure that the each indication is within the SP value.

OK or NG

### OK >> INSPECTION END

NG >> Detect malfunctioning part according to <u>EC-298, "Symptom Matrix Chart"</u>.


### 17. CHECK "B/FUEL SCHDL"

Select "B/FUEL SCHDL" in "DATA MONITOR (SPEC)" mode, and make sure that the indication is within the SP value.

### OK or NG

### OK >> INSPECTION END

NG (More than the SP value)>>GO TO 18. NG (Less than the SP value)>>GO TO 25.



## 18. DETECT MALFUNCTIONING PART

- 1. Check for the cause of large engine friction. Refer to the following.
- Engine oil level is too high
- Engine oil viscosity
- Belt tension of power steering, alternator, A/C compressor, etc. is excessive
- Noise from engine
- Noise from transmission, etc.
- 2. Check for the cause of insufficient combustion. Refer to the following.
- Valve clearance malfunction
- Intake valve timing control function malfunction
- Camshaft sprocket installation malfunction, etc.

>> Repair or replace malfunctioning part, and then GO TO 30.

## 19. CHECK INTAKE SYSTEM

Check for the cause of uneven air flow through mass air flow sensor. Refer to the following.

- Crushed air ducts
- Malfunctioning seal of air cleaner element
- Uneven dirt of air cleaner element
- Improper specification of intake air system

### OK or NG

OK >> GO TO 21.

NG >> Repair or replace malfunctioning part, and then GO TO 20.

20. CHECK "A/F ALPHA-B1", "A/F ALPHA-B2", AND "B/FUEL SCHDL"	А
Select "A/F ALPHA-B1", "A/F ALPHA-B2", and "B/FUEL SCHDL" in "DATA MONITOR (SPEC)" mode, and make sure that the each indication is within the SP value.	1
OK or NG	EC
OK >> <b>INSPECTION END</b> NG ("B/FUEL SCHDL" is more, "A/F ALPHA-B1", "A/F ALPHA-B2" are less than the SP value)>>GO TO 21.	
21. DISCONNECT AND RECONNECT MASS AIR FLOW SENSOR HARNESS CONNECTOR	С
<ol> <li>Stop the engine.</li> <li>Disconnect mass air flow sensor harness connector. Check pin terminal and connector for damage and then reconnect it again.</li> </ol>	D
>> GO TO 22.	Е
22. CHECK "A/F ALPHA-B1", "A/F ALPHA-B2"	F
1. Start engine.	I
2. Select "A/F ALPHA-B1", "A/F ALPHA-B2" in "DATA MONITOR (SPEC)" mode, and make sure that the each indication is within the SP value.	G
OK or NG OK >> 1. Detect malfunctioning part of mass air flow sensor circuit and repair it. Refer to <u>EC-357, "DTC</u> <u>P0102, P0103 MAF SENSOR"</u> .	Н
2. GO TO 29. NG >> GO TO 23.	
23. CHECK "MAS A/F SE-B1"	
Select "MAS A/F SE-B1" in "DATA MONITOR (SPEC)" mode, and make sure that the indication is within the SP value.	J
OK or NG       Inclusion       Inclusion         OK       >> GO TO 24.         NG (More than the SP value)>>Replace mass air flow sensor, and then GO TO 29.       Inclusion	K
0.00 0.65 1.30 1.95 2.60	L
PBIB2370E	М

## 24. REPLACE ECM

- 1. Replace ECM.
- 2. Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to <u>BL-116,</u> <u>"NATS(Nissan Anti-Theft System)"</u>.
- 3. Perform Accelerator Pedal Released Position Learning.
- 4. Perform Throttle Valve Closed Position Learning.
- 5. Perform Idle Air Volume Learning.

>> GO TO 29.

## 25. CHECK INTAKE SYSTEM

Check for the cause of uneven air flow through mass air flow sensor. Refer to the following.

- Crushed air ducts
- Malfunctioning seal of air cleaner element
- Uneven dirt of air cleaner element
- Improper specification of intake air system

OK or NG

OK >> GO TO 27.

NG >> Repair or replace malfunctioning part, and then GO TO 26.

## 26. CHECK "B/FUEL SCHDL"

Select "B/FUEL SCHDL" in "DATA MONITOR (SPEC)" mode, and make sure that the indication is within the SP value.

### OK or NG

OK >> INSPECTION END

NG (Less than the SP value)>>GO TO 27.


## 27. СНЕСК "МАЅ А/Ғ ЅЕ-В1"

Select "MAS A/F SE-B1" in "DATA MONITOR (SPEC)" mode, and make sure that the indication is within the SP value.

### OK or NG

OK >> GO TO 28.

NG (Less than the SP value)>>Replace mass air flow sensor, and then GO TO 30.



## 28. CHECK INTAKE SYSTEM

Check for the cause of air leak after the mass air flow sensor. Refer to the following.

- Disconnection, looseness, and cracks in air duct
- Looseness of oil filler cap
- Disconnection of oil level gauge
- Open stuck, breakage, hose disconnection, or cracks of PCV valve
- Disconnection or cracks of EVAP purge hose, open stuck of EVAP canister purge volume control solenoid valve
- Malfunctioning seal of rocker cover gasket
- Disconnection, looseness, or cracks of hoses, such as vacuum hose, connecting to intake air system parts
- Malfunctioning seal of intake air system, etc.

>> GO TO 30.

## 29. CHECK "A/F ALPHA-B1", "A/F ALPHA-B2", AND "B/FUEL SCHDL"

Select "A/F ALPHA-B1", "A/F ALPHA-B2", and "B/FUEL SCHDL" in "DATA MONITOR (SPEC)" mode, and make sure that the each indication is within the SP value.

### OK or NG

### OK >> INSPECTION END

NG >> Detect malfunctioning part according to EC-298, "Symptom Matrix Chart".

## EC-61

30.	CHECK "B/FUEL SCHDL"	А
Select	"B/FUEL SCHDL" in "DATA MONITOR (SPEC)" mode, and then make sure that the indication is within value.	
OK or		EC
OK NG	>> INSPECTION END >> Detect malfunctioning part according to <u>EC-298, "Symptom Matrix Chart"</u> .	С
		D
		E
		F
		G
		Н
		I
		J
		K
		L
		Μ

## **TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT**

### Description

Intermittent incidents may occur. In many cases, the malfunction resolves itself (the part or circuit function returns to normal without intervention). It is important to realize that the symptoms described in the customer's complaint often do not recur on (1st trip) DTC visits. Realize also that the most frequent cause of intermittent incidents occurrences is poor electrical connections. Because of this, the conditions under which the incident occurred may not be clear. Therefore, circuit checks made as part of the standard diagnosis may not indicate the specific malfunctioning area.

#### **Common Intermittent Incidents Report Situations**

STEP in Work Flow	Situation
2	The CONSULT-II is used. The SELF-DIAG RESULTS screen shows time data other than [0] or [1t].
3 or 4	The symptom described by the customer does not recur.
5	(1st trip) DTC does not appear during the DTC Confirmation Procedure.
10	The Diagnosis for PXXXX does not indicate the malfunctioning area.

## **Diagnostic Procedure**

## 1. INSPECTION START

Erase (1st trip) DTCs. Refer to GI-23, "How to Perform Efficient Diagnosis for an Electrical Incident" .

>> GO TO 2.

### 2. CHECK GROUND TERMINALS

Check ground terminals for corroding or loose connection.

Refer to EC-351, "Ground Inspection" .

OK or NG

OK >> GO TO 3.

NG >> Repair or replace.

## 3. SEARCH FOR ELECTRICAL INCIDENT

Perform <u>GI-23, "How to Perform Efficient Diagnosis for an Electrical Incident"</u>, "INCIDENT SIMULATION TESTS".

OK or NG


OK >> INSPECTION END

NG >> Repair or replace.

PFP:00006

ABSONGTE

ABS00GTG




Specification data are reference values and are measured between each terminal and ground.

#### **CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
		Ignition switch	[Ignition switch: OFF]	0V
109	R		[Ignition switch: ON]	BATTERY VOLTAGE (11 - 14V)
111	W/B	ECM relay (Self shut-off)	[Engine is running] [Ignition switch: OFF]	0.451
			<ul> <li>For a few seconds after turning ignition switch OFF</li> </ul>	0 - 1.5V
			[Ignition switch: OFF]	
			<ul> <li>More than a few seconds after turning igni- tion switch OFF</li> </ul>	BATTERY VOLTAGE (11 - 14V)
119 120	R/B R/B	Power supply for ECM	[Ignition switch: ON]	BATTERY VOLTAGE (11 - 14V)



TBWA0682E

EC-66

Specification data are reference values and are measured between each terminal and ground.

#### **CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
1	В	ECM ground	[Engine is running] • Idle speed	Body ground
115 116	B B	ECM ground	[Engine is running] • Idle speed	Body ground

## **Diagnostic Procedure**

### **1. INSPECTION START**

#### Start engine.

Is engine running?

Yes or No

Yes >> GO TO 8. No >> GO TO 2.


## 2. CHECK ECM POWER SUPPLY CIRCUIT-I

- 1. Turn ignition switch OFF and then ON.
- 2. Check voltage between ECM terminal 109 and ground with CONSULT-II or tester.

### Voltage: Battery voltage

#### OK or NG

OK >> GO TO 4. NG >> GO TO 3.



## **3. DETECT MALFUNCTIONING PART**

Check the following.


- Fuse block (J/B) connector M1
- 10A fuse
- Harness for open or short between ECM and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

ABS00GTI

## 4. CHECK GROUND CONNECTIONS

- 1. Turn ignition switch OFF.
- 2. Loosen and retighten two ground screws on the body. Refer to <u>EC-351, "Ground Inspection"</u>.



#### OK or NG

OK >> GO TO 5.

NG >> Repair or replace ground connections.

### 5. CHECK ECM GROUND CIRCUIT FOR OPEN AND SHORT-I

1.	Disconnect ECM harness connector.
----	-----------------------------------

2. Check harness continuity between ECM terminals 1, 115, 116 and ground. Refer to Wiring Diagram.

### Continuity should exist.

3. Also check harness for short to power.

### OK or NG

OK >> GO TO 7. NG >> GO TO 6.

### 6. DETECT MALFUNCTIONING PART

#### Check the following.

- Harness connectors F102, M82
- Harness for open or short between ECM and ground


>> Repair open circuit or short to power in harness or connectors.

## 7. CHECK ECM POWER SUPPLY CIRCUIT-II

- 1. Reconnect ECM harness connector.
- 2. Turn ignition switch ON.
- 3. Check voltage between IPDM E/R terminal 17 and ground with CONSULT-II or tester.

### Voltage: Battery voltage

OK or NG



EC

F

Н

K

Μ

## 8. CHECK ECM POWER SUPPLY CIRCUIT-III

- 1. Turn ignition switch ON and then OFF.
- 2. Check voltage between ECM terminals 119, 120 and ground with CONSULT-II or tester.

Voltage: After turning ignition switch OFF, battery voltage will exist for a few seconds, then drop approximately 0V.

#### OK or NG

OK >> GO TO 15.

- NG (Battery voltage does not exist.)>>GO TO 9.
- NG (Battery voltage exists for more than a few seconds.)>>GO TO 12.


### 9. CHECK ECM POWER SUPPLY CIRCUIT-IV

- 1. Turn ignition switch OFF.
- 2. Check voltage between ECM terminal 111 and ground with CONSULT-II or tester.

#### Voltage: Battery voltage

#### OK or NG

OK >> GO TO 10. NG >> GO TO 12.



O CONNECTOR

PBIB1630F

119, 120

ECM

## 10. CHECK ECM POWER SUPPLY CIRCUIT-V

- 1. Disconnect ECM harness connector.
- 2. Disconnect IPDM E/R harness connector E7.
- 3. Check harness continuity between ECM terminals 119, 120 and IPDM E/R terminal 18. Refer to Wiring Diagram.

### Continuity should exist.

4. Also check harness for short to ground and short to power.

### OK or NG

OK >> GO TO 18. NG >> GO TO 11.


### 11. DETECT MALFUNCTIONING PART

Check the following.

- Harness or connectors E110, M7
- Harness for open or short between ECM and IPDM E/R

>> Repair open circuit or short to ground or short to power in harness or connectors.

12. CHECK ECM POWER SUPPLY CIRCUIT-VII	А
<ol> <li>Disconnect ECM harness connector.</li> <li>Disconnect IPDM E/R harness connector E9.</li> <li>Check harness continuity between ECM terminal 111 and IPDM E/R terminal 46. Refer to Wiring Diagram.</li> </ol>	EC
<ul><li>Continuity should exist.</li><li>4. Also check harness for short to ground and short to power.</li></ul>	С
<u>OK or NG</u> OK >> GO TO 14. NG >> GO TO 13.	D
13. DETECT MALFUNCTIONING PART	E
<ul> <li>Check the following.</li> <li>Harness or connectors E109, M6</li> <li>Harness for open or short between ECM and IPDM E/R</li> <li>&gt;&gt; Repair open circuit or short to ground or short to power in harness or connectors.</li> </ul>	F
14. CHECK 15A FUSE	G
<ol> <li>Disconnect 15A fuse from IPDM E/R.</li> <li>Check 15A fuse.</li> <li>OK or NG</li> <li>OK &gt;&gt; GO TO 18.</li> <li>NG &gt;&gt; Replace 15A fuse.</li> </ol>	H
15. CHECK GROUND CONNECTIONS	J
Loosen and retighten two ground screws on the body. Refer to EC-351, "Ground Inspection".  Instrument panel removed Body ground Body ground	ĸ



OK or NG

OK >> GO TO 16.

NG >> Repair or replace ground connections.

## 16. CHECK ECM GROUND CIRCUIT FOR OPEN AND SHORT-II

- 1. Disconnect ECM harness connector.
- 2. Check harness continuity between ECM terminals 1, 115, 116 and ground. Refer to Wiring Diagram.

#### Continuity should exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 18. NG >> GO TO 17.

## 17. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F102, M82
- Harness for open or short between ECM and ground

>> Repair open circuit or short to power in harness or connectors.

## 18. CHECK INTERMITTENT INCIDENT

Refer to EC-338, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT".


OK or NG

- OK >> Replace IPDM E/R.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

### **Ground Inspection**

Ground connections are very important to the proper operation of electrical and electronic circuits. Ground connections are often exposed to moisture, dirt and other corrosive elements. The corrosion (rust) can become an unwanted resistance. This unwanted resistance can change the way a circuit works. Electronically controlled circuits are very sensitive to proper grounding. A loose or corroded ground can drastically affect an electronically controlled circuit. A poor or corroded ground can easily affect the circuit. Even when the ground connection looks clean, there can be a thin film of rust on the surface. When inspecting a ground connection follow these rules:

- Remove the ground bolt or screw.
- Inspect all mating surfaces for tarnish, dirt, rust, etc.
- Clean as required to assure good contact.
- Reinstall bolt or screw securely.
- Inspect for "add-on" accessories which may be interfering with the ground circuit.
- If several wires are crimped into one ground eyelet terminal, check for proper crimps. Make sure all of the wires are clean, securely fastened and providing a good ground path. If multiple wires are cased in one eyelet make sure no ground wires have excess wire insulation.



ABS00GTJ

А

EC

С

D

Е

# DTC U1000, U1001 CAN COMMUNICATION LINE

# Description

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

# **On Board Diagnosis Logic**

The MIL will not light up for these diagnoses.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
U1000 1000 U1001 1001	CAN communication line	<ul> <li>ECM cannot communicate to other control units.</li> <li>ECM cannot communicate for more than the specified time.</li> </ul>	<ul> <li>Harness or connectors (CAN communication line is open or shorted) (Refer to <u>LAN-3, "Precautions When</u> <u>Using CONSULT-II"</u>)</li> </ul>

# **DTC Confirmation Procedure**

- 1. Turn ignition switch ON and wait at least 3 seconds.
- 2. Select "DATA MONITOR" mode with CONSULT-II.
- 3. If 1st trip DTC is detected, check possible cause items.

Z50


PFP:23710


ABS00GTK

ABS00GTL

ABSOOGTM

## DTC U1000, U1001 CAN COMMUNICATION LINE





TBWB0486E


EC-74

# DTC P0011, P0021 IVT CONTROL

#### Description SYSTEM DESCRIPTION

Sensor	Input signal to ECM	ECM function	Actuator
Crankshaft position sensor (POS)	Engine speed and piston position	Intake valve timing control	Intake valve timing control solenoid valve
Camshaft position sensor (PHASE)	Engine speed and piston position		
Engine coolant temperature sensor	Engine coolant temperature		
Wheel sensor*	Vehicle speed		

\*: This signal is sent to the ECM through CAN Communication line



This mechanism hydraulically controls cam phases continuously with the fixed operating angle of the intake valve.

The ECM receives signals such as crankshaft position, camshaft position, engine speed, and engine coolant temperature. Then, the ECM sends ON/OFF pulse duty signals to the intake valve timing control solenoid valve depending on driving status. This makes it possible to control the shut/open timing of the intake valve to increase engine torque in low/mid speed range and output in high-speed range.

# **CONSULT-II Reference Value in Data Monitor Mode**

ABS00GTQ

PFP:23796

ABSOOGTP

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
	• Engine: After warming up	Idle	–5° - 5°CA
INT/V TIM (B1)	<ul> <li>Shift lever: P or N</li> </ul>		
INT/V TIM (B2)	Air conditioner switch: OFF	2,000 rpm	Approx. 0° - 30°CA
	<ul> <li>No-load</li> </ul>		
	Engine: After warming up	Idle	0% - 2%
INT/V SOL (B1)	<ul> <li>Shift lever: P or N</li> </ul>		
INT/V SOL (B2)	Air conditioner switch: OFF	2,000 rpm	Approx. 0% - 50%
	<ul> <li>No-load</li> </ul>		

# **On Board Diagnosis Logic**

ABS00GTR

А

F

Н

ABS00GTS

The MIL will not lights up for these diagnoses.

DTC No.	Trouble diagnosis name	Detecting condition	Possible cause	EC
P0011			Crankshaft position sensor (POS)	
0011 (Daula 1)			Camshaft position sensor (PHASE)	
(Bank 1)	-		<ul> <li>Intake valve control solenoid valve</li> </ul>	С
P0021	Intake valve timing control performance	There is a gap between angle of target and phase-control angle degree.	<ul> <li>Accumulation of debris to the signal pick-up portion of the camshaft</li> </ul>	
0021 (Bank 2)			Timing chain installation	D
			<ul> <li>Foreign matter caught in the oil groove for intake valve timing control</li> </ul>	

### FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode.

Detected items	Engine operating condition in fail-safe mode	F
Intake valve timing control	The signal is not energized to the solenoid valve and the valve control does not function.	

# **DTC Confirmation Procedure**

#### **CAUTION:**

#### Always drive at a safe speed.

#### NOTE:

- If DTC P0011 or P0021 is displayed with DTC P1111 or P1136, first perform trouble diagnosis for DTC P1111 or P1136. Refer to <u>EC-405</u>.
- If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### **TESTING CONDITION:**

Before performing the following procedure, confirm that battery voltage is between 10V and 16V at Jidle.

#### B WITH CONSULT-II

- 1. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
- 2. Start engine and warm it up to the normal operating temperature.
- 3. Maintain the following conditions for at least 6 consecutive seconds.

Hold the accelerator pedal as steady as possible.

ENG SPEED	1,200 - 2,000 rpm (A constant rotation is maintained.)	
COOLAN TEMP/S	More than 60°C (140°F)	
Selector lever	P or N position	

#### 4. Let engine idle for 10 seconds.

- 5. If 1st trip DTC is detected, check possible cause items. If 1st trip DTC is not detected, go to next step.
- 6. Maintain the following conditions for at least 20 consecutive seconds.

ENG SPEED	1,700 - 3,175 rpm (A constant rotation is maintained.)	
COOLAN TEMP/S	70 - 105°C (158 - 221°F)	
Selector lever	1st or 2nd position	
Driving location uphill	Driving vehicle uphill (Increased engine load will help maintain the driving conditions required for this test.)	


7. If 1st trip DTC is detected, check possible cause items.

# **Overall Function Check**

Use this procedure to check the overall function of the intake valve timing control system. During this check, a 1st trip DTC might not be confirmed.

#### **WITHOUT CONSULT-II**

- 1. Start engine and warm it up to normal operating temperature.
- 2. Turn ignition switch OFF and wait at least 10 seconds.
- 3. Turn ignition switch ON.
- 4. Set the tester probe between ECM terminal 11 [IVT control solenoid valve (bank 1) signal] or 10 [IVT control solenoid valve (bank 2) signal] and ground.
- 5. Start engine and let it idle.
- Check the voltage under the following conditions. Verify that the oscilloscope screen shows the signal wave as shown below.



★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

7. If NG, check possible cause items.

ABS00GTT

# DTC P0102, P0103 MAF SENSOR

# DTC P0102, P0103 MAF SENSOR

# **Component Description**

The mass air flow sensor is placed in the stream of intake air. It measures the intake flow rate by measuring a part of the entire intake flow. The mass air flow sensor controls the temperature of the hot wire to a certain amount. The heat generated by the hot wire is reduced as the intake air flows around it. The more air, the greater the heat loss.

Therefore, the electric current supplied to hot wire is changed to maintain the temperature of the hot wire as air flow increases. The ECM detects the air flow by means of this current change.

# **CONSULT-II Reference Value in Data Monitor Mode**

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION	-
MAS A/F SE-B1	• See EC-328, "TROUBLE DIAGNOSIS - SPECIFICATION VALUE".		

# **On Board Diagnosis Logic**

These self-diagnoses have the one trip detection logic.


DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause	F
P0102 0102	Mass air flow sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul> <li>Harness or connectors (The sensor circuit is open or shorted.)</li> <li>Intake air leaks</li> <li>Mass air flow sensor</li> </ul>	
P0103 0103	Mass air flow sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	<ul> <li>Harness or connectors (The sensor circuit is open or shorted.)</li> <li>Mass air flow sensor</li> </ul>	J

### FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MIL lights up.

Detected items	Engine operating condition in fail-safe mode	L
Mass air flow sensor circuit	Engine speed will not rise more than 2,400 rpm due to the fuel cut.	_

**EC-78** 



ARSONGTY

ABS00GTZ

F

Κ

М

А

### **DTC Confirmation Procedure**


#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### PROCEDURE FOR DTC P0102

#### With CONSULT-II

- 1. Turn ignition switch ON.
- Select "DATA MONITOR" mode with CONSULT-II.
- 3. Start engine and wait at least 5 seconds.
- 4. If DTC is detected, check possible cause items.




#### **Without CONSULT-II**

- 1. Start engine and wait at least 5 seconds.
- 2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- 3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
- 4. If DTC is detected, check possible cause items.

#### **PROCEDURE FOR DTC P0103**

#### With CONSULT-II

- 1. Turn ignition switch ON.
- 2. Select "DATA MONITOR" mode with CONSULT-II.
- 3. Wait at least 5 seconds.
- 4. If DTC is detected, check possible cause items. If DTC is not detected, go to next step.
- 5. Start engine and wait at least 5 seconds.
- 6. If DTC is detected, check possible cause items.




#### **Without CONSULT-II**


- 1. Turn ignition switch ON and wait at least 5 seconds.
- 2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- 3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
- 4. If DTC is detected, check possible cause items. If DTC is not detected, go to next step.
- 5. Turn ignition switch OFF, wait at least 10 seconds.
- 6. Start engine and wait at least 5 seconds.
- 7. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- 8. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
- 9. If DTC is detected, check possible cause items.

ABS00GU0

# DTC P0102, P0103 MAF SENSOR

#### Wiring Diagram LHD MODELS





TBWB0489E

EC-80

ABS00GU1

А

# DTC P0117, P0118 ECT SENSOR

# **Component Description**

The engine coolant temperature sensor is used to detect the engine coolant temperature. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the engine coolant temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.

#### Gasket Gasket SEF594K SEF5

Sensor

# <Reference data>

Engine coolant temperature

Engine coolant temperature °C (°F)	Voltage* V	Resistance $k\Omega$
-10 (14)	4.4	7.0 - 11.4
20 (68)	3.5	2.1 - 2.9
50 (122)	2.2	0.68 - 1.00
90 (194)	0.9	0.236 - 0.260

\*: This data is reference value and is measured between ECM terminal 73 (Engine coolant temperature sensor) and ground.

#### **CAUTION:**

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

# **On Board Diagnosis Logic**

DTC No.	Trouble Diagnosis Name	DTC Detecting Condition	Possible Cause	-
P0117 0117	Engine coolant tem- perature sensor cir- cuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul> <li>Harness or connectors</li> <li>(The sensor circuit is open or shorted.)</li> </ul>	K
P0118 0118	Engine coolant tem- perature sensor cir- cuit high input	An excessively high voltage from the sensor is sent to ECM.	Engine coolant temperature sensor	L



PFP:22630

Terminal

ABS00GU5

А

EC

F

F

Н

Μ

ABS00GU6

#### FAIL-SAFE MODE

ECM enters fail-safe mode when the malfunction is detected.

Detected items Engine operating condition in fail-safe mode			
	Engine coolant temperature will be determined by ECM based on the time after turning ignition switch ON or START. CONSULT-II displays the engine coolant temperature decided by ECM.		
	Condition	Engine coolant temperature decided (CONSULT-II display)	
Engine coolant temper-	Just as ignition switch is turned ON or START	40°C (104°F)	
ature sensor circuit	More than approx. 4 minutes after ignition ON or START	80°C (176°F)	
	Except as shown above	40 - 80°C (104 - 176°F) (Depends on the time)	
	When the fail-safe system for engine coolant tempera while engine is running.	ature sensor is activated, the cooling fan operates	


# **DTC Confirmation Procedure**

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### B WITH CONSULT-II

- 1. Turn ignition switch ON.
- 2. Select "DATA MONITOR" mode with CONSULT-II.
- 3. Wait at least 5 seconds.
- 4. If 1st trip DTC is detected, check possible cause items.





ABS00GU7

#### **WITHOUT CONSULT-II**

- 1. Turn ignition switch ON and wait at least 5 seconds.
- 2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- 3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
- 4. If 1st trip DTC is detected, check possible cause items.

# Wiring Diagram





TBWA0691E


EC-83

# DTC P0122, P0123 TP SENSOR

# **Component Description**

Electric throttle control actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.



# CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
THRTL SEN 1	Ignition switch: ON	Accelerator pedal: Fully released	More than 0.36V
THRTL SEN 2*	(Engine stopped) • Shift lever: D	Accelerator pedal: Fully depressed	Less than 4.75V

\*: Throttle position sensor 2 signal is converted by ECM internally. Thus, it differ from ECM terminal voltage signal.

# **On Board Diagnosis Logic**

These self-diagnoses have the one trip detection logic.

Throttle position output voltage 0.7 0.7 0.7		Sensor 2		
U U	0 4	59	0 135	5
Throttl	e valve openi	ng angle (de	g) <sub>РВІВ0145Е</sub>	

ABSONGLID

ABS00GUE

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0122 0122	Throttle position sensor 2 circuit low input	An excessively low voltage from the TP sensor 2 is sent to ECM.	• Harness or connectors (TP sensor 2 circuit is open or shorted.)
P0123 0123	Throttle position sensor 2 circuit high input	An excessively high voltage from the TP sensor 2 is sent to ECM.	<ul> <li>(APP sensor 2 circuit is shorted)</li> <li>Electric throttle control actuator (TP sensor 2)</li> <li>Accelerator pedal position sensor (APP sensor 2)</li> </ul>

#### **FAIL-SAFE MODE**

When the malfunction is detected, ECM enters fail-safe mode and the MIL lights up.

Engine operation condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.

The ECM regulates the opening speed of the throttle valve to be slower than the normal condition.

So, the acceleration will be poor.

PFP:16119

ABS00GUC

### **DTC Confirmation Procedure**

#### NOTE:


If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### **TESTING CONDITION:**

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

#### B WITH CONSULT-II

- 1. Turn ignition switch ON.
- 2. Select "DATA MONITOR" mode with CONSULT-II.
- 3. Start engine and let it idle for 1 second.
- 4. If DTC is detected, check possible cause items.



#### **WITHOUT CONSULT-II**

- 1. Start engine and let it idle for 1 second.
- 2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- 3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
- 4. If DTC is detected, check possible cause items.

ABS00GUF



Н

J

Κ


Т

Μ

EC

А

Wiring Diagram



TBWA0699E

**EC-86** 

ABS00GUG

# DTC P0138, P0158 H02S2

# **Component Description**

The heated oxygen sensor 2, after three way catalyst (manifold), monitors the oxygen level in the exhaust gas on each bank.

Even if switching characteristics of the air fuel ratio (A/F) sensor 1 are shifted, the air-fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2.

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.

Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.

# **CONSULT-II Reference Value in Data Monitor Mode**


Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
HO2S2 (B1) HO2S2 (B2)	<ul> <li>Revving engine from idle to 3,000 rpm quickly after the following condi- tions are met</li> </ul>	0 - 0.3V ←→ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1) HO2S2 MNTR (B2)	<ul> <li>Engine: After warning up</li> <li>Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load</li> </ul>	$LEAN \leftarrow \rightarrow RICH$

# **On Board Diagnosis Logic**

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the air fuel ratio (A/F) sensor 1. The oxygen storage capacity of the three way catalyst (manifold) causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the voltage is unusually high during the various driving condition such as fuel-cut.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0138 0138 (Bank 1) P0158 0158 (Bank 2)	Heated oxygen sensor 2 circuit high voltage	An excessively high voltage from the sensor is sent to ECM.	<ul> <li>Harness or connectors (The sensor circuit is open or shorted)</li> <li>Heated oxygen sensor 2</li> </ul>



ABS00H2P

ABSOOH20

ΟK NG 1.2V 1V ٥v PBIB1848E

PFP:226A0

ABS00H2N

### **DTC Confirmation Procedure**

#### NOTE:


If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### WITH CONSULT-II

- 1. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
- 2. Start engine and warm it up to the normal operating temperature.
- 3. Turn ignition switch OFF and wait at least 10 seconds.
- 4. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
- 5. Let engine idle for 2 minutes.
- 6. If 1st trip DTC is detected, check possible cause items.

#### **WITHOUT CONSULT-II**

- 1. Start engine and warm it up to the normal operating temperature.
- 2. Turn ignition switch OFF and wait at least 10 seconds.
- 3. Start engine and keep the engine speed between 3,500 and 4,000 rpm for at least 1 minute under no load.
- 4. Let engine idle for 2 minutes.
- 5. Turn ignition switch OFF and wait at least 10 seconds and then turn ON.
- 6. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
- 7. If 1st trip DTC is detected, check possible cause items.





K

L

Μ


Н

ABS00H2Q

A


#### Wiring Diagram LHD MODELS Bank 1

ABS00H2R



EC-89

# DTC P0138, P0158 HO2S2



TBWB0630E

EC-90

# DTC P0222, P0223 TP SENSOR

# **Component Description**

Electric throttle control actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has the two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.

### Throttle position sensor output voltage Sensor 1 Sensor 2 45 90 135 Throttle valve opening angle (deg) PBIB0145E

6.0

Throttle position sensor

# CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
THRTL SEN 1	Ignition switch: ON	Accelerator pedal: Fully released	More than 0.36V
THRTL SEN 2*	(Engine stopped) • Shift lever: D	Accelerator pedal: Fully depressed	Less than 4.75V

\*: Throttle position sensor 2 signal is converted by ECM internally. Thus, it differ from ECM terminal voltage signal.

# On Board Diagnosis Logic

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0222 0222	Throttle position sensor 1 circuit low input	An excessively low voltage from the TP sensor 1 is sent to ECM.	Harness or connectors     (TP sensor 1 circuit is open or shorted.)
P0223 0223	Throttle position sensor 1 circuit high input	An excessively high voltage from the TP sensor 1 is sent to ECM.	<ul><li>(APP sensor 2 circuit is shorted.)</li><li>Electric throttle control actuator (TP sensor 1)</li></ul>
			<ul> <li>Accelerator pedal position sensor (APP sensor 2)</li> </ul>

### **FAIL-SAFE MODE**

When the malfunction is detected, ECM enters fail-safe mode and the MIL lights up.

Engine operation condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 dearees.

The ECM regulates the opening speed of the throttle valve to be slower than the normal condition.

So, the acceleration will be poor.



PFP:16119



ABS00GUL

# **DTC Confirmation Procedure**

#### NOTE:


If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### **TESTING CONDITION:**

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

#### (I) WITH CONSULT-II

- 1. Turn ignition switch ON.
- 2. Select "DATA MONITOR" mode with CONSULT-II.
- 3. Start engine and let it idle for 1 second.
- 4. If DTC is detected, check possible cause items.



#### **WITHOUT CONSULT-II**

- 1. Start engine and let it idle for 1 second.
- 2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- 3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
- 4. If DTC is detected, check possible cause items.



Н

J


Κ

Т

Μ

А

Wiring Diagram



TBWA0698E

EC-93

ABS00GUO

# DTC P0327, P0328 KS

# **Component Description**

The knock sensor is attached to the cylinder block. It senses engine knocking using a piezoelectric element. A knocking vibration from the cylinder block is sensed as vibrational pressure. This pressure is converted into a voltage signal and sent to the ECM.

# On Board Diagnosis Logic

#### The MIL will not light up for these diagnoses.

DTC No.	Trouble diagnosis name	DTC detected condition	Possible cause
P0327 0327	Knock sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul> <li>Harness or connectors (The sensor circuit is open or shorted.)</li> </ul>
P0328 0328	Knock sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	Knock sensor

# **DTC Confirmation Procedure**

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### **TESTING CONDITION:**

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.


**EC-94** 


#### WITH CONSULT-II

- 1. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
- 2. Start engine and run it for at least 5 seconds at idle speed.
- 3. If 1st trip DTC is detected, check possible cause items.



- 1. Start engine and run it for at least 5 seconds at idle speed.
- 2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- 3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
- 4. If 1st trip DTC is detected, check possible cause items.






PFP:22060

ABS00GUS

ABS00GUU

SEF058)



TBWA0700E

# DTC P0335 CKP SENSOR (POS)

# **Component Description**

The crankshaft position sensor (POS) is located on the oil pan facing the gear teeth (cogs) of the signal plate. It detects the fluctuation of the engine revolution.

The sensor consists of a permanent magnet and Hall IC.


When the engine is running, the high and low parts of the teeth cause the gap with the sensor to change.

The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.

The ECM receives the voltage signal and detects the fluctuation of the engine revolution.

ECM receives the signals as shown in the figure.



# **CONSULT-II** Reference Value in Data Monitor Mode


#### Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION	
ENG SPEED	• Run engine and compare CONSULT-II value with the tachometer indica- tion.	Almost the same speed as the tachometer indication.	

# **On Board Diagnosis Logic**

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause	
P0335 0335	Crankshaft position sensor (POS) circuit	<ul> <li>The crankshaft position sensor (POS) signal is not detected by the ECM during the first few seconds of engine cranking.</li> <li>The proper pulse signal from the crankshaft position sensor (POS) is not sent to ECM while the engine is running.</li> <li>The crankshaft position sensor (POS) signal is not in the normal pattern during engine running.</li> </ul>	<ul> <li>Harness or connectors (The sensor circuit is open or shorted)</li> <li>Crankshaft position sensor (POS)</li> <li>Signal plate</li> </ul>	M

**EC-96** 



PFP:23731

А

F

ABS00GV0

ABS00GV1

K

ABS00GUZ

# **DTC Confirmation Procedure**

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### **TESTING CONDITION:**

Before performing the following procedure, confirm that battery voltage is more than 10.5V with ignition switch ON.

#### B WITH CONSULT-II

- 1. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
- 2. Crank engine for at least 2 seconds and run it for at least 5 seconds at idle speed.
- 3. If 1st trip DTC is detected, check possible cause items.


DATA M	ONITOR	]
MONITOR	NO DTC	
ENG SPEED	XXX rpm	]
		1

# **WITHOUT CONSULT-II**

- 1. Crank engine for at least 2 seconds and run it for at least 5 seconds at idle speed.
- 2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- 3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
- 4. If 1st trip DTC is detected, check possible cause items.

ABS00GV2

# DTC P0335 CKP SENSOR (POS)



TBWB0500E

EC-98

# DTC P0340, P0345 CMP SENSOR (PHASE)

# DTC P0340, P0345 CMP SENSOR (PHASE)

### **Component Description**

The camshaft position sensor (PHASE) senses the retraction of intake valve camshaft to identify a particular cylinder. The camshaft position sensor (PHASE) senses the piston position.


When the crankshaft position sensor (POS) system becomes inoperative, the camshaft position sensor (PHASE) provides various controls of engine parts instead, utilizing timing of cylinder identification signals.

The sensor consists of a permanent magnet and Hall IC.

When engine is running, the high and low parts of the teeth cause the gap with the sensor to change.

The changing gap causes the magnetic field near the sensor to change.


Due to the changing magnetic field, the voltage from the sensor changes. ECM receives the signals as shown in the figure.



# On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause	
P0340 0340		<ul> <li>The cylinder No. signal is not sent to ECM</li> </ul>	Harness or connectors     (The sensor circuit is open or shorted)	0
(Bank 1)	_	for the first few seconds during engine	<ul> <li>Camshaft position sensor (PHASE)</li> </ul>	k
	Osmahatt a saiti an asa	cranking.	Camshaft (Intake)	1
P0345 0345	Camshaft position sen- sor (PHASE) circuit	<ul> <li>The cylinder No. signal is not sent to ECM during engine running.</li> </ul>	<ul> <li>Starter motor (Refer to <u>SC-4, "START-</u> <u>ING SYSTEM"</u>.)</li> </ul>	
(Bank 2)		<ul> <li>The cylinder No. signal is not in the normal pattern during engine running.</li> </ul>	<ul> <li>Starting system circuit (Refer to <u>SC-4,</u> <u>"STARTING SYSTEM"</u>.)</li> </ul>	
			Dead (Weak) battery	N

**EC-99** 



PFP:23731

А

E

Н

ABS00GV8

# **DTC Confirmation Procedure**

#### NOTE:


If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### **TESTING CONDITION:**

Before performing the following procedure, confirm that battery voltage is more than 10.5V with ignition switch ON.

#### B WITH CONSULT-II

- 1. Turn ignition switch ON.
- 2. Select "DATA MONITOR" mode with CONSULT-II.
- 3. Crank engine for at least 2 seconds and run it for at least 5 seconds at idle speed.
- 4. If 1st trip DTC is detected, check possible cause items. If 1st trip DTC is not detected, go to next step.
- 5. Maintaining engine speed at more than 800 rpm for at least 5 seconds.
- 6. If 1st trip DTC is detected, check possible cause items.




### **WITHOUT CONSULT-II**


- 1. Crank engine for at least 2 seconds and run it for at least 5 seconds at idle speed.
- 2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- 3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
- 4. If 1st trip DTC is detected, check possible cause items.
- If 1st trip DTC is not detected, go to next step.
- 5. Start engine and maintaining engine speed at more than 800 rpm for at least 5 seconds.
- 6. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- 7. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
- 8. If 1st trip DTC is detected, check possible cause items.

ABS00GV9

# DTC P0340, P0345 CMP SENSOR (PHASE)



# DTC P0340, P0345 CMP SENSOR (PHASE)




TBWB0504E

# DTC P0550 PSP SENSOR

# **Component Description**

Power steering pressure (PSP) sensor is installed to the power steering high-pressure tube and detects a power steering load. This sensor is a potentiometer which transforms the power steering load into output voltage, and emits the voltage signal to the ECM. The ECM controls the electric throttle control actuator and adjusts the throttle valve opening angle to increase the engine speed and adjusts the idle speed for the increased load.



# **CONSULT-II Reference Value in Data Monitor Mode**

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION	F
PW/ST SIGNAL	• Engine: After warming up, idle	Steering wheel: Not being turned	OFF	
FW/ST SIGNAL	the engine	Steering wheel: Being turned.	ON	G

# **On Board Diagnosis Logic**

The MIL will not light up for this diagnosis.

NOTE:

If DTC P0550 is displayed with DTC P1229, first perform the trouble diagnosis for DTC P1229. Refer to <u>EC-436</u>.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause	.
P0550 0550	Power steering pres- sure sensor circuit	An excessively low or high voltage from the sensor is sent to ECM.	<ul> <li>Harness or connectors (The sensor circuit is open or shorted)</li> <li>Power steering pressure sensor</li> </ul>	J


# **DTC Confirmation Procedure**

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### B WITH CONSULT-II

- 1. Turn ignition switch ON.
- 2. Select "DATA MONITOR" mode with CONSULT-II.
- 3. Start engine and let it idle for at least 5 seconds.
- 4. If 1st trip DTC is detected, check possible cause items.



Μ

K

L

PFP:49763

ARSOOGVK

ABS00GVL

ABS00GVM

Н


A ABS00GVJ

# **WITHOUT CONSULT-II**


- 1. Start engine and let it idle for at least 5 seconds.
- 2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- 3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
- 4. If 1st trip DTC is detected, check possible cause items.

# **DTC P0550 PSP SENSOR**

# Wiring Diagram



Μ



TBWA0707E

# DTC P0605 ECM

# **Component Description** The ECM consists of a microcomputer and connectors for signal input and output and for power supply. The ECM controls the engine.

# On Board Diagnosis Logic

This self-diagnosis has one or two trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition		Possible cause
		A)	ECM calculation function is malfunctioning.	
P0605 0605	Engine control module	B)	ECM EEP-ROM system is malfunctioning.	• ECM
		C)	ECM self shut-off function is malfunctioning.	

# FAIL-SAFE MODE

ECM enters fail-safe mode when the malfunction A is detected.

Detected items	Engine operation condition in fail-safe mode		
Malfunction A	• ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.		
	ECM deactivates ASCD operation.		

# **DTC Confirmation Procedure**

Perform PROCEDURE FOR MALFUNCTION A first. If the 1st trip DTC cannot be confirmed, perform PROCEDURE FOR MALFUNCTION B. If there is no malfunction on PROCEDURE FOR MALFUNCTION B, perform PROCEDURE FOR MALFUNCTION C.


#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### **PROCEDURE FOR MALFUNCTION A**

#### With CONSULT-II

- 1. Turn ignition switch ON.
- 2. Select "DATA MONITOR" mode with CONSULT-II.
- 3. If 1st trip DTC is detected, check possible cause items.




PFP:23710



ARSONGVR

ABS00GVS




#### **Without CONSULT-II**

- 1. Turn ignition switch ON.
- 2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- 3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
- 4. If 1st trip DTC is detected, check possible cause items.

### PROCEDURE FOR MALFUNCTION B

#### With CONSULT-II

- 1. Turn ignition switch ON and wait at least 1 second.
- 2. Select "DATA MONITOR" mode with CONSULT-II.
- 3. Turn ignition switch OFF, wait at least 10 seconds, and then turn ON.
- 4. If 1st trip DTC is detected, check possible cause items.




#### **Without CONSULT-II**

- 1. Turn ignition switch ON and wait at least 1 second.
- 2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- 3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
- 4. If 1st trip DTC is detected, check possible cause items.

#### **PROCEDURE FOR MALFUNCTION C**

#### (I) With CONSULT-II

- 1. Turn ignition switch ON and wait at least 1 second.
- 2. Select "DATA MONITOR" mode with CONSULT-II.
- 3. Turn ignition switch OFF, wait at least 10 seconds, and then turn ON.
- 4. Repeat step 3 for 32 times.
- 5. If 1st trip DTC is detected, check possible cause items.



### **Without CONSULT-II**

- 1. Turn ignition switch ON and wait at least 1 second.
- 2. Turn ignition switch OFF and wait at least 10 seconds.
- 3. Repeat step 1 to 2 for 32 times.
- 4. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- 5. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
- 6. If 1st trip DTC is detected, check possible cause items.

A

EC



Н

# DTC P1031, P1032, P1051, P1052 A/F SENSOR 1 HEATER

#### Description SYSTEM DESCRIPTION

Sensor	Input Signal to ECM	ECM function	Actuator	
Camshaft position sensor (PHASE) Crankshaft position sensor (POS)	Engine speed	Air fuel ratio (A/F) sensor 1 heater control	Air fuel ratio (A/F) sensor 1 heater	
Mass air flow sensor	Amount of intake air	nealer control		

The ECM performs ON/OFF duty control of the A/F sensor 1 heater corresponding to the engine operating condition to keep the temperature of A/F sensor 1 element at the specified range.

# **CONSULT-II** Reference Value in Data Monitor Mode

ABS00GVV

ARSOOGVW

ABS00GVX

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
A/F S1 HTR (B1) A/F S1 HTR (B2)	• Engine: After warming up, idle the engine	0 - 100%

# **On Board Diagnosis Logic**

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause	
P1031 1031 (Bank 1) P1051 1051 (Bank 2)	Air fuel ratio (A/F) sensor 1 heater control circuit low input	The current amperage in the air fuel ratio (A/F) sensor 1 heater circuit is out of the normal range. (An excessively low voltage signal is sent to ECM through the air fuel ratio (A/F) sensor 1 heater.)	<ul> <li>Harness or connectors (The A/F sensor 1 heater circuit is open or shorted.)</li> <li>Air fuel ratio (A/F) sensor 1 heater</li> </ul>	
P1032 1032 (Bank 1)	Air fuel ratio (A/F) sensor 1 heater control circuit	The current amperage in the air fuel ratio (A/F) sensor 1 heater circuit is out of the normal range.	<ul> <li>Harness or connectors (The A/F sensor 1 heater circuit is shorted.)</li> </ul>	
P1052 1052 (Bank 2)	high input	(An excessively high voltage signal is sent to ECM through the air fuel ratio (A/F) sensor 1 heater.)	<ul> <li>Air fuel ratio (A/F) sensor 1 heater</li> </ul>	

# **DTC Confirmation Procedure**

#### NOTE:


If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### **TESTING CONDITION:**

Before performing the following procedure, confirm that battery voltage is between 10.5V and 16V at idle.

#### (I) WITH CONSULT-II

- 1. Turn ignition switch ON and select "DATA MONITOR" mode with CONSULT-II.
- 2. Start engine and let it idle for at least 10 seconds.
- 3. If 1st trip DTC is detected, check possible cause items.




PFP:22693

ABS00GVU


## DTC P1031, P1032, P1051, P1052 A/F SENSOR 1 HEATER

8	WITHOUT CONSULT-II	•
1.	Start engine and let it idle for at least 10 seconds.	А
2.	Turn ignition switch OFF, wait at least 10 seconds and then turn ON.	
3. 4.	Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM. If 1st trip DTC is detected, check possible cause items.	EC
4.	i ist the Die is detected, check possible cause items.	
		0
		С
		D
		Е
		F
		1
		G
		Н
		I
		J
		0
		K
		L
		Μ



TBWA0685E

## DTC P1031, P1032, P1051, P1052 A/F SENSOR 1 HEATER



TBWA0686E

Revision: 2006 December

## DTC P1065 ECM POWER SUPPLY

## **Component Description**

Battery voltage is supplied to the ECM even when the ignition switch is turned OFF for the ECM memory function of the DTC memory, the air-fuel ratio feedback compensation value memory, the idle air volume learning value memory, etc.

## On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1065 1065	ECM power supply cir- cuit	ECM back-up RAM system does not function properly.	<ul> <li>Harness or connectors [ECM power supply (back-up) circuit is open or shorted.]</li> <li>ECM</li> </ul>

## **DTC Confirmation Procedure**

### NOTE:


If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.


### B WITH CONSULT-II

- 1. Turn ignition switch ON and wait at least 1 second.
- 2. Select "DATA MONITOR" mode with CONSULT-II.
- 3. Start engine and let it idle for 1 second.
- 4. Turn ignition switch OFF, wait at least 10 seconds, and then turn ON.
- 5. Repeat steps 3 and 4 for 4 times.
- 6. If 1st trip DTC is detected, check possible cause items.



- 1. Turn ignition switch ON and wait at least 1 second.
- 2. Start engine and let it idle for 1 second.
- 3. Turn ignition switch OFF, wait at least 10 seconds, and then turn ON.
- 4. Repeat steps 2 to 3 for 4 times.
- 5. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- 6. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
- 7. If 1st trip DTC is detected, check possible cause items.






PFP:23710

ARSOOGWA

ABS00GW4

# Wiring Diagram



TBWB0607E

յ

J L L

## DTC P1111, P1136 IVT CONTROL SOLENOID VALVE

## **Component Description**

Intake valve timing control solenoid valve is activated by ON/OFF pulse duty (ratio) signals from the ECM.

The intake valve timing control solenoid valve changes the oil amount and direction of flow through intake valve timing control unit or stops oil flow.

The longer pulse width advances valve angle.

The shorter pulse width retards valve angle.

When ON and OFF pulse widths become equal, the solenoid valve stops oil pressure flow to fix the intake valve angle at the control position.

## **CONSULT-II** Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CON	IDITION	SPECIFICATION	F
	Engine: After warming up	Idle	0% - 2%	
INT/V SOL (B1)	<ul> <li>Shift lever: P or N</li> </ul>			
INT/V SOL (B2)	<ul> <li>Air conditioner switch: OFF</li> </ul>	2,000 rpm	Approx. 0% - 50%	(
	<ul> <li>No load</li> </ul>			

## **On Board Diagnosis Logic**

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause	
P1111 1111 (Bank 1)	Intake valve timing control solenoid valve circuit	through intake value timing control colonaid	(Intake valve timing control solenoid valv	
P1136 1136 (Bank 2)		valve.	<ul><li>circuit is open or shorted.)</li><li>Intake valve timing control solenoid valve</li></ul>	

## **DTC Confirmation Procedure**


NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

### B WITH CONSULT-II

- 1. Turn ignition switch ON.
- 2. Select "DATA MONITOR" mode with CONSULT-II.
- 3. Start engine and let it idle for 5 seconds.
- 4. If 1st trip DTC is detected, check possible cause items.

DATA MONITOR		
MONITOR NO DTC		
ENG SPEED XXX rpm		



ABS00GW8

ABS00GW9 H

L

K

Μ

ABS00GWA


PFP:23796

А

## **WITHOUT CONSULT-II**

- 1. Start engine and let it idle for 5 seconds.
- 2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- 3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
- 4. If 1st trip DTC is detected, check possible cause items.


## DTC P1111, P1136 IVT CONTROL SOLENOID VALVE



## DTC P1111, P1136 IVT CONTROL SOLENOID VALVE

### Bank 2

### EC-IVCB2-01 ■ : DETECTABLE LINE FOR DTC BATTERY : NON-DETECTABLE LINE FOR DTC Ċ 15A IPDM E/R (INTELLIGENT POWER 77 REFER TO PG-POWER. DISTRIBUTION MODULE ENGINE ROOM) οu 00 ECM RELAY (E7), (E9) оIJ 46 18 R/B Т w/в W/В 4 R/B (E109) (E110) W/B (M6) R/B (M7) R/B (M82) R/B (F102) 2 INTAKE VALVE TIMING CONTROL SOLENOID VALVE (BANK 2) ſ 00 (F25) 1 W/B R/B R/B 111 120 119 10 SSOF VB C-IVC (L) VB ECM (M80), (F101)



TBWB0513E

## DTC P1121 ELECTRIC THROTTLE CONTROL ACTUATOR

## **Component Description**

Electric throttle control actuator consists of throttle control motor, throttle position sensor, etc. The throttle control motor is operated by the ECM and it opens and closes the throttle valve. The throttle position sensor detects the throttle valve position, and the opening and closing speed of the throttle valve and feeds the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.

## **On Board Diagnosis Logic**

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition		Possible cause
P1121	Electric throttle control	A)	Electric throttle control actuator does not func- tion properly due to the return spring malfunc- tion.	
1121	actuator	B)	Throttle valve opening angle in fail-safe mode is not in specified range.	Electric throttle control actuator
		C)	ECM detects the throttle valve is stuck open.	

## FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MIL lights up.

Detected items	Engine operating condition in fail-safe mode	Н
Malfunction A	ECM controls the electric throttle actuator by regulating the throttle opening around the idle position. The engine speed will not rise more than 2,000 rpm.	
Malfunction B	ECM controls the electric throttle control actuator by regulating the throttle opening to 20 degrees or less.	
Malfunction C	While the vehicle is driving, it slows down gradually by fuel cut. After the vehicle stops, the engine stalls. The engine can restart in N or P position, and engine speed will not exceed 1,000 rpm or more.	

## **DTC Confirmation Procedure**


NOTE:

- Perform PROCEDURE FOR MALFUNCTION A AND B first. If the DTC cannot be confirmed, perform K PROCEDURE FOR MALFUNCTION C.
- If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

## PROCEDURE FOR MALFUNCTION A AND B

### With CONSULT-II

- 1. Turn ignition switch ON and wait at least 1 second.
- 2. Select "DATA MONITOR" mode with CONSULT-II.
- 3. Shift selector lever to D position and wait at least 3 seconds.
- 4. Shift selector lever to P or N position.
- 5. Turn ignition switch OFF and wait at least 10 seconds.
- 6. Turn ignition switch ON and wait at least 1 second.
- 7. Shift selector lever to D position and wait at least 3 seconds.
- 8. Shift selector lever to P or N position.
- 9. Turn ignition switch OFF, wait at least 10 seconds, and then turn ON.
- 10. If DTC is detected, check possible cause items.



ABSOOGWG

ABSOOGWH

L

M

F

E

А

## DTC P1121 ELECTRIC THROTTLE CONTROL ACTUATOR

### **Without CONSULT-II**

- 1. Turn ignition witch ON and wait at least 1 second.
- 2. Shift selector lever to D position and wait at least 3 seconds.
- 3. Shift selector lever to P or N position.
- 4. Turn ignition switch OFF and wait at least 10 seconds.
- 5. Turn ignition switch ON and wait at least 1 second.
- 6. Shift selector lever to D position and wait at least 3 seconds.
- 7. Shift selector lever to P or N position.
- 8. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- 9. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
- 10. If DTC is detected, check possible cause items.

### **PROCEDURE FOR MALFUNCTION C**

### With CONSULT-II

- 1. Turn ignition switch ON and wait at least 1 second.
- 2. Select "DATA MONITOR" mode with CONSULT-II.
- 3. Shift selector lever to D position and wait at least 3 seconds.
- 4. Shift selector lever to P or N position.
- 5. Start engine and let it idle for 3 seconds.
- 6. If DTC is detected, check possible cause items.

DATA M	ONITOR		
MONITOR NO DTC			
ENG SPEED XXX rpm			

### **Without CONSULT-II**

- 1. Turn ignition witch ON and wait at least 1 second.
- 2. Shift selector lever to D position and wait at least 3 seconds.
- 3. Shift selector lever to N or P position.
- 4. Start engine and let it idle for 3 seconds.
- 5. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- 6. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
- 7. If DTC is detected, check possible cause items.

## DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION

## Description

NOTE: If DTC P1122 is displayed with DTC P1121 or 1126, first perform the trouble diagnosis for DTC P1121 or EC P1126. Refer to EC-411 or EC-416. Electric throttle control actuator consists of throttle control motor, throttle position sensor, etc. The throttle control motor is operated by the ECM and it opens and closes the throttle valve. The current opening angle of the throttle valve is detected by the throttle position sensor and it provides feedback to the ECM to control the throttle control motor to make the throttle valve opening angle properly in

On Board Diagnosis Logic

response to driving condition.

### This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause	1
P1122 1122	Electric throttle control performance problem	Electric throttle control function does not oper- ate properly.	<ul> <li>Harness or connectors (Throttle control motor circuit is open or shorted)</li> <li>Electric throttle control actuator</li> </ul>	I

## **FAIL-SAFE MODE**

When the malfunction is detected, ECM enters fail-safe mode and the MIL lights up.

Engine operating condition in fail-safe mode

ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return sprina.

## **DTC Confirmation Procedure**


### **TESTING CONDITION:**

Before performing the following procedure, confirm that battery voltage is more than 11V at idle. NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

### WITH CONSULT-II

- 1. Turn ignition switch ON and wait at least 2 seconds.
- Select "DATA MONITOR" mode with CONSULT-II. 2.
- 3. Start engine and let it idle for 5 seconds.
- 4. If DTC is detected, check possible cause items.



## R WITHOUT CONSULT-II

- 1. Turn ignition switch ON and wait at least 2 seconds.
- 2. Start engine and let it idle for 5 seconds.
- 3. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM. 4.
- If DTC is detected, check possible cause items. 5.

PFP:16119

ABS00GWJ

ABSOOGWK

ABSOOGWI

А

D


Н

1

Κ

# Wiring Diagram





TBWB0515E

## DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY

## **Component Description**

Power supply for the throttle control motor is provided to the ECM via throttle control motor relay. The throttle control motor relay is ON/OFF controlled by the ECM. When the ignition switch is turned ON, the ECM sends an ON signal to throttle control motor relay and battery voltage is provided to the ECM. When the ignition switch is turned OFF, the ECM sends an OFF signal to throttle control motor relay and battery voltage is not provided to the ECM.

## **CONSULT-II Reference Value in Data Monitor Mode**

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
THRTL RELAY	Ignition switch: ON	ON

## **On Board Diagnosis Logic**

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1124 1124	Throttle control motor relay circuit short	ECM detects the throttle control motor relay is stuck ON.	<ul> <li>Harness or connectors (Throttle control motor relay circuit is shorted)</li> <li>Throttle control motor relay</li> </ul>
P1126 1126	Throttle control motor relay circuit open	ECM detects a voltage of power source for throttle control motor is excessively low.	<ul> <li>Harness or connectors (Throttle control motor relay circuit is open)</li> <li>Throttle control motor relay</li> </ul>

### FAIL-SAFE MODE

When the malfunction is detected, ECM enters fail-safe mode and the MIL lights up.

Engine operating condition in fail-safe mode

ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.

## **DTC Confirmation Procedure**

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.


### **PROCEDURE FOR DTC P1124**

### **TESTING CONDITION:**

Before performing the following procedure, confirm that battery voltage is more than 8V.

### With CONSULT-II

- 1. Turn ignition switch ON and wait at least 1 second.
- 2. Select "DATA MONITOR" mode with CONSULT-II.
- 3. If DTC is detected, check possible cause items.



PFP:16119

ABSOOGWE

ABS00GWS

ABSOOGWT

## DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY


### **Without** CONSULT-II

- 1. Turn ignition switch ON and wait at least 1 second.
- 2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- 3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
- 4. If DTC is detected, check possible cause items.

### **PROCEDURE FOR DTC P1126**

### With CONSULT-II

- 1. Turn ignition switch ON and wait at least 2 seconds.
- 2. Select "DATA MONITOR" mode with CONSULT-II.
- 3. Start engine and let it idle for 5 seconds.
- 4. If DTC is detected, check possible cause items.



### **Without CONSULT-II**

- 1. Turn ignition switch ON and wait at least 2 seconds.
- 2. Start engine and let it idle for 5 seconds.
- 3. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- 4. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
- 5. If DTC is detected, check possible cause items.

А

Н


J

Κ

L

Μ

# Wiring Diagram



TBWB0517E

ABS00GWU

## DTC P1128 THROTTLE CONTROL MOTOR

## **Component Description**

The throttle control motor is operated by the ECM and it opens and closes the throttle valve. The current opening angle of the throttle valve is detected by the throttle position sensor and it provides feedback to the ECM to control the throttle control motor to make the throttle valve opening angle properly in response to driving condition.

## On Board Diagnosis Logic

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1128 1128	Throttle control motor circuit short	ECM detects short in both circuits between ECM and throttle control motor.	<ul> <li>Harness or connectors (Throttle control motor circuit is shorted.)</li> <li>Electric throttle control actuator (Throttle control motor)</li> </ul>

## **FAIL-SAFE MODE**

When the malfunction is detected, the ECM enters fail-safe mode and the MIL lights up.

Engine operating condition in fail-safe mode

ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring

## **DTC Confirmation Procedure**

### NOTE:

1.

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

### (P) WITH CONSULT-II

- 1. Turn ignition switch ON and wait at least 2 seconds.
- 2. Select "DATA MONITOR" mode with CONSULT-II.
- 3. Start engine and let it idle for 5 seconds.
- 4 If DTC is detected, check possible cause items.

2. Start engine and let it idle for 5 seconds.	2.	Start engine and let it idle for 5 seconds.
--	----	---

**WITHOUT CONSULT-II** 

- Turn ignition switch OFF, wait at least 10 seconds and then turn ON. 3.
- 4. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
- 5. If DTC is detected, check possible cause items.

Turn ignition switch ON and wait at least 2 seconds.

DATA MONITOR MONITOR NO DTC ENG SPEED XXX rpm SEF058Y


PFP:16119

ABSOOGWW

ABSOOGWX

ABS00GWY

### Wiring Diagram LHD MODELS



TBWB0519E

ABS00GWZ

А

## DTC P1211 TCS CONTROL UNIT

## Description

The malfunction information related to TCS is transferred through the CAN communication line from ABS actuator and electric unit (control unit) to ECM.

Be sure to erase the malfunction information such as DTC not only for "ABS actuator and electric unit (control unit)" but also for ECM after TCS related repair.

## **On Board Diagnosis Logic**

Freeze frame data is not stored in the ECM for this self-diagnosis. The MIL will not light up for this self-diagnosis.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause	
P1211 1211	TCS control unit	ECM receives a malfunction information from "ABS actuator and electric unit (control unit)".	<ul> <li>ABS actuator and electric unit (control unit) (Refer to <u>BRC-5, "TROUBLE DIAGNO-SIS"</u> or <u>BRC-25, "TROUBLE DIAGNO-SIS"</u>)</li> <li>TCS related parts</li> </ul>	

## **DTC Confirmation Procedure**


### **TESTING CONDITION:**

Before performing the following procedure, confirm that battery voltage is more than 10.5V at idle.

EC-127

### B WITH CONSULT-II

- 1. Turn ignition switch ON.
- 2. Select "DATA MONITOR" mode with CONSULT-II.
- 3. Start engine and let it idle for at least 60 seconds.
- 4. If 1st trip DTC is detected, check possible cause items.



## 🛞 WITHOUT CONSULT-II

- 1. Start engine and let it idle for at least 60 seconds.
- 2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- 3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
- 4. If 1st trip DTC is detected, check possible cause items.

PFP:47850

ABS00H2V

EC

D

F

F

Н

Μ

А

ABS00H2W C

ABS00H2X

## DTC P1212 TCS COMMUNICATION LINE

## Description

NOTE:

If DTC P1212 is displayed with DTC U1000 or U1001, first perform the trouble diagnosis for DTC U1000, U1001. Refer to <u>EC-352, "DTC U1000, U1001 CAN COMMUNICATION LINE"</u>.

This CAN communication line is used to control the smooth engine operation during the TCS operation. Pulse signals are exchanged between ECM and ABS actuator and electric unit (control unit).

Be sure to erase the malfunction information such as DTC not only for "ABS actuator and electric unit (control unit)" but also for ECM after TCS related repair.

## On Board Diagnosis Logic

ABS00H30

Freeze frame data is not stored in the ECM for this self-diagnosis. The MIL will not light up for this selfdiagnosis.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1212 1212	TCS communication line	ECM can not receive the information from "ABS actuator and electric unit (control unit)" continuously.	<ul> <li>Harness or connectors         <ul> <li>(The CAN communication line is open or shorted.)</li> <li>(Refer to <u>LAN-3, "Precautions When Using</u> <u>CONSULT-II"</u>)</li> </ul> </li> <li>ABS actuator and electric unit (control unit)         <ul> <li>(Refer to <u>BRC-5, "TROUBLE DIAGNOSIS"</u> or <u>BRC-25, "TROUBLE DIAGNOSIS"</u>)</li> </ul> </li> <li>Dead (Weak) battery</li> </ul>


## **DTC Confirmation Procedure**

ABS00H31

## TESTING CONDITION: Before performing the following procedure, confirm that battery voltage is more than 10.5V at idle.

### B WITH CONSULT-II

- 1. Turn ignition switch ON.
- 2. Select "DATA MONITOR" mode with CONSULT-II.
- 3. Start engine and let it idle for at least 10 seconds.
- 4. If 1st trip DTC is detected, check possible cause items.



## **WITHOUT CONSULT-II**

- 1. Start engine and let it idle for at least 10 seconds.
- 2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- 3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
- 4. If 1st trip DTC is detected, check possible cause items.

PFP:47850

ABS00H2Z

## DTC P1217 ENGINE OVER TEMPERATURE

### Description SYSTEM DESCRIPTION

PFP:00000

ABS00GX3

А

EC

Н

Μ

NOTE:

If DTC P1217 is displayed with DTC U1000 or U1001, first perform the trouble diagnosis for DTC U1000, U1001. Refer to EC-352, "DTC U1000, U1001 CAN COMMUNICATION LINE".

### Cooling Fan Control


Sensor	Input Signal to ECM	ECM function	Actuator	
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed* <sup>1</sup>			[
Battery	Battery voltage*1			
Wheel sensor*2	Vehicle speed	Cooling fan control	IPDM E/R (Cooling fan relay)	E
Engine coolant temperature sensor	Engine coolant temperature		(Cooling fail felay)	
Air conditioner switch*2	Air conditioner ON signal			
Refrigerant pressure sensor	Refrigerant pressure			ŀ

\*1: The ECM determines the start signal status by the signals of engine speed and battery voltage.

\*2: This signals is sent to ECM through CAN communication line.

The ECM controls the cooling fan corresponding to the vehicle speed, engine coolant temperature, refrigerant pressure, and air conditioner ON signal. The control system has 3-step control [HIGH/LOW/OFF].

### **Cooling Fan Operation**



### **Cooling Fan Relay Operation**

The ECM controls cooling fan relays in the IPDM E/R through CAN communication line.

Cooling fan speed	Cooling fan relay		
	1	2	3
Stop (OFF)	OFF	OFF	OFF
Low (LOW)	OFF	OFF	ON
High (HI)	ON	ON	ON

### **COMPONENT DESCRIPTION**

### **Cooling Fan Motor**

The cooling fan operates at each speed when the current flows in the cooling fan motor as follows.

Cooling fan speed	Cooling fan motor terminals		
Cooling fair speed	(+)	(-)	
	1	4	
Low (LOW)	2	3	
High (HI)	1 and 2	3 and 4	

## **CONSULT-II** Reference Value in Data Monitor Mode

ABS00GX4

Specification data are reference values.

MONITOR ITEM	CO	NDITION	SPECIFICATION
	• Engine: After warming up, idle	Air conditioner switch: OFF	OFF
AIR COND SIG	the engine	Air conditioner switch: ON (Compressor operates.)	ON
	<ul> <li>Engine: After warming up, idle the engine</li> <li>Air conditioner switch: OFF</li> </ul>	Engine coolant temperature is 94°C (201°F) or less	OFF
COOLING FAN		Engine coolant temperature is between 95°C (203°F) and 99°C (210°F)	LOW
		Engine coolant temperature is 100°C (212°F) or more	н

## **On Board Diagnosis Logic**

If the cooling fan or another component in the cooling system malfunctions, engine coolant temperature will rise.

When the engine coolant temperature reaches an abnormally high temperature condition, a malfunction is indicated.

### This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause	_
P1217 1217	Engine over tempera- ture (Overheat)	<ul> <li>Cooling fan does not operate properly (Overheat).</li> <li>Cooling fan system does not operate properly (Overheat).</li> <li>Engine coolant level was not added to the system using the proper filling method.</li> <li>Engine coolant is not within the specified range.</li> </ul>	<ul> <li>Harness or connectors (The cooling fan circuit is open or shorted.)</li> <li>Cooling fan</li> <li>Cooling fan relay (IPDM E/R)</li> <li>Radiator hose</li> <li>Radiator</li> <li>Radiator cap</li> <li>Water pump</li> <li>Thermostat</li> </ul>	_
			For more information, refer to <u>EC-433,</u> "Main 12 Causes of Overheating".	

### **CAUTION:**

When a malfunction is indicated, be sure to replace the coolant. Refer to <u>MA-15</u>, <u>"Changing Engine</u> <u>Coolant"</u>. Also, replace the engine oil. Refer to <u>MA-21</u>, <u>"Changing Engine Oil"</u>.

- 1. Fill radiator with coolant up to specified level with a filling speed of 2 liters per minute. Be sure to use coolant with the proper mixture ratio. Refer to <u>MA-13</u>, "Engine Coolant Mixture Ratio".
- 2. After refilling coolant, run engine to ensure that no water-flow noise is emitted.

## **Overall Function Check**

Use this procedure to check the overall function of the cooling fan. During this check, a DTC might not be confirmed.


### WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could be caused by high pressure fluid escaping from the radiator.

Wrap a thick cloth around cap. Carefully remove the cap by turning it a quarter turn to allow built-up pressure to escape. Then turn the cap all the way off.

### WITH CONSULT-II

- Check the coolant level in the reservoir tank and radiator. Allow engine to cool before checking coolant level. If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and check possible cause items.
- 2. Confirm whether customer filled the coolant or not. If customer filled the coolant, skip the following steps and check possible cause items.
- 3. Turn ignition switch ON.



EC

Н

1

K

ABS00GX6

А

ABS00GX5

- 4. Perform "COOLING FAN" in "ACTIVE TEST" mode with CON-SULT-II.
- 5. If the results are NG, check possible cause items.

P	
ACTIVE TES	т
COOLING FAN	OFF
MONITOR	
COOLAN TEMP/S	xxx °C
	1



1. Check the coolant level in the reservoir tank and radiator. **NOTE:** 

### Allow engine to cool before checking coolant level.

If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and check possible cause items.

2. Confirm whether customer filled the coolant or not. If customer filled the coolant, skip the following steps and check possible cause items.


## Start engine. CAUTION: Be careful not to overheat engine.


- 4. Turn air conditioner switch ON.
- 5. Turn blower fan switch ON.
- Make sure that cooling fan operates at low speed. If NG, check possible cause items. If OK, go to the following step.
- 7. Turn ignition switch OFF.
- 8. Turn air conditioner switch and blower fan switch OFF.
- 9. Disconnect engine coolant temperature sensor harness connector.
- 10. Connect 150  $\!\Omega$  resistor to engine coolant temperature sensor harness connector.
- 11. Restart engine and make sure that cooling fan operates at higher speed than low speed.


### CAUTION:


### Be careful not to overheat engine.

12. If NG, check possible cause items.










TBWB0521E

EC-133



TBWB0863E

EC-134

Engine	Step	Inspection item	Equipment	Standard
OFF	1	Blocked radiator	Visual	No blocking
		Blocked condenser		
		<ul> <li>Blocked radiator grille</li> </ul>		
		<ul> <li>Blocked bumper</li> </ul>		
	2	Coolant mixture	Coolant tester	50 - 50% coolant mixture
	3	Coolant level	• Visual	Coolant up to MAX level in reser- voir tank and radiator filler neck
	4	Radiator cap	Pressure tester	78 - 98 kPa
				(0.78 - 0.98 bar, 0.8 - 1.0 kg/cm <sup>2</sup> , 11 - 14 psi) (Limit)
ON* <sup>2</sup>	5	Coolant leaks	• Visual	No leaks
ON* <sup>2</sup>	6	Thermostat	• Touch the upper and lower radiator hoses	Both hoses should be hot
ON* <sup>1</sup>	7	Cooling fan	CONSULT-II	Operating
OFF	8	Combustion gas leak	Color checker chemical tester     4 Gas analyzer	Negative
ON* <sup>3</sup>	9	Coolant temperature gauge	Visual	Gauge less than 3/4 when driv- ing
		Coolant overflow to reservoir tank	• Visual	No overflow during driving and idling
OFF <sup>*4</sup>	10	Coolant return from reservoir tank to radiator	• Visual	Should be initial level in reservoir tank
OFF	11	Cylinder head	Straight gauge feeler gauge	0.1 mm (0.004 in) Maximum dis- tortion (warping)
	12	Cylinder block and pistons	• Visual	No scuffing on cylinder walls or piston

## Main 12 Causes of Overheating

\*1: Turn the ignition switch ON.

\*2: Engine running at 3,000 rpm for 10 minutes.

\*3: Drive at 90 km/h (55 MPH) for 30 minutes and then let idle for 10 minutes.

\*4: After 60 minutes of cool down time.

Κ

L

Μ

## DTC P1225 TP SENSOR

## **Component Description**

Electric throttle control actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.

# **On Board Diagnosis Logic**

### The MIL will not light up for this diagnosis.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1225 1225	Closed throttle position learning performance problem	Closed throttle position learning value is excessively low.	<ul> <li>Electric throttle control actuator (TP sensor 1 and 2)</li> </ul>

## **DTC Confirmation Procedure**

### NOTE:

2.

3.

4.

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

### **TESTING CONDITION:**

### Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

### WITH CONSULT-II

- 1. Turn ignition switch ON.
- 2. Select "DATA MONITOR" mode with CONSULT-II.
- 3. Turn ignition switch OFF, wait at least 10 seconds.
- 4. Turn ignition switch ON.

WITHOUT CONSULT-II
 Turn ignition switch ON.

5. If 1st trip DTC is detected, check possible cause items.


Turn ignition switch OFF, wait at least 10 seconds and then turn ON.

Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.

If 1st trip DTC is detected, check possible cause items.



Revision: 2006 December



#### 6.0 Hottle position sensor 6.0 4.0 4.0 4.0 4.0 5ensor 1 5ensor 1 5ensor 2 0 4.0 5ensor 2 90 135 Throttle valve opening angle (deg) PBIB0145E

ABS00GXC

ABS00GXD

PFP:16119

### The MIL will not light up for this diagnosis.

opening angle properly in response to driving condition.

P1226 Closed throttle position learning is not per-	ole cause
1226 problem formed successfully, repeatedly. (TP sensor 1 and 2	

## **DTC Confirmation Procedure**

DTC P1226 TP SENSOR

**Component Description** 

the throttle valve movement.

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

### **TESTING CONDITION:**

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

### WITH CONSULT-II

- 1. Turn ignition switch ON.
- 2. Select "DATA MONITOR" mode with CONSULT-II.
- 3. Turn ignition switch OFF, wait at least 10 seconds.
- 4 Turn ignition switch ON.
- 5. Repeat steps 3 and 4 for 32 times.
- If 1st trip DTC is detected, check possible cause items. 6.



- Turn ignition switch ON. 1.
- 2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- 3. Repeat step 2 for 32 times.
- Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM. 4.
- 5. If 1st trip DTC is detected, check possible cause items.


#### Electric throttle control actuator consists of throttle control motor, Throttle position sensor throttle position sensor, etc. The throttle position sensor responds to 6.0 EC Throttle position sensor output voltage 0 0 0 0 0 Sensor 1 The throttle position sensor has two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into С output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the Sensor 2 ECM controls the throttle control motor to make the throttle valve 0∟ 0 45 90 135 Throttle valve opening angle (deg) PBIB0145E F

ARSONGYH

ABSOOGY

F

Н



EC-137

PFP:16119

ABS00GXG

А

## DTC P1229 SENSOR POWER SUPPLY

## On Board Diagnosis Logic

### This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1229 1229	Sensor power supply circuit short	ECM detects a voltage of power source for sensor is excessively low or high.	<ul> <li>Harness or connectors (APP sensor 1 circuit is shorted.) (PSP sensor circuit is shorted.) (Refrigerant pressure sensor circuit is shorted.)</li> <li>Accelerator pedal position sensor</li> <li>Power steering pressure sensor</li> <li>Refrigerant pressure sensor</li> </ul>

### FAIL-SAFE MODE

When the malfunction is detected, ECM enters fail-safe mode and the MIL lights up.

Engine operation condition in fail-safe mode

ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.

## **DTC Confirmation Procedure**

### NOTE:


If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

### **TESTING CONDITION:**

### Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

### B WITH CONSULT-II

- 1. Turn ignition switch ON.
- 2. Select "DATA MONITOR" mode with CONSULT-II.
- 3. Start engine and let it idle for 1 second.
- 4. If DTC is detected, check possible cause items.




### **WITHOUT CONSULT-II**


- 1. Start engine and let it idle for 1 second.
- 2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- 3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
- 4. If DTC is detected, check possible cause items.

ABS00GXL

ABSOOGXM



## 3 1 5 4 2 6 M67



TBWB0525E

## DTC P1271, P1281 A/F SENSOR 1

## **Component Description**

The A/F sensor is a planar dual-cell limit current sensor. The sensor element of the A/F sensor is the combination of a Nernst concentration cell (sensor cell) with an oxygen-pump cell, which transports ions. It has a heater in the element.

The sensor is capable of precise measurement  $\lambda = 1$ , but also in the lean and rich range. Together with its control electronics, the sensor outputs a clear, continuous signal throughout a wide  $\lambda$  range (0.7 <  $\lambda$  < air).

The exhaust gas components diffuse through the diffusion gap at the electrode of the oxygen pump and Nernst concentration cell, where they are brought to thermodynamic balance.

An electronic circuit controls the pump current through the oxygenpump cell so that the composition of the exhaust gas in the diffusion gap remains constant at  $\lambda = 1$ . Therefore, the A/F sensor is able to indicate air/fuel ratio by this pumping of current. In addition, a heater is integrated in the sensor to ensure the required operating temperature of 700 - 800°C (1,292 - 1,472°F).

## **CONSULT-II** Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONE	DITION	SPECIFICATION	-
A/F SEN1 (B1) A/F SEN1 (B2)	• Engine: After warming up	Maintaining engine speed at 2,000 rpm	Fluctuates around 1.5V	_

## **On Board Diagnosis Logic**

To judge the malfunction, the diagnosis checks that the A/F signal computed by ECM from the air fuel ratio (A/F) sensor 1 signal is not inordinately low.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible Cause	L
P1271 1271 (Bank 1) P1281 1281 (Bank 2)	Air fuel ratio (A/F) sensor 1 circuit no activity detected	• The A/F signal computed by ECM from the A/F sensor 1 signal is constantly approx. 0V.	<ul> <li>Harness or connectors (The A/F sensor 1 circuit is open or shorted.)</li> <li>Air fuel ratio (A/F) sensor 1</li> </ul>	Μ

## **DTC Confirmation Procedure**

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.


### **TESTING CONDITION:**

### Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

### WITH CONSULT-II

- 1. Start engine and warm it up to normal operating temperature.
- 2. Select "A/F SEN1 (B1)" or "A/F SEN1 (B2)" in "DATA MONITOR" mode with CONSULT-II.

Holder Protector Zirconia element SEF579Z



ABS00GXS

ABSOOGXE

Н

K

F

А

EC

PFP:22693

ABSOOGXE

 Check "A/F SEN1 (B1)" or "A/F SEN1 (B2)" indication. If the indication is constantly approx. 0V, check possible cause items.
 If the indication is not constantly approx. 0V/ go to post stop

If the indication is not constantly approx. 0V, go to next step.

- 4. Turn ignition switch OFF, wait at least 10 seconds and then restart engine.
- 5. Drive and accelerate vehicle to more than 40 km/h (25 MPH) within 20 seconds after restarting engine.
- Maintain the following conditions for about 20 consecutive seconds.

ENG SPEED	1,000 - 3,200 rpm
VHCL SPEED SE	More than 40 km/h (25 MPH)
B/FUEL SCHDL	1.5 - 9.0 msec
Gear position	Suitable position

### NOTE:

- Keep the accelerator pedal as steady as possible during the cruising.
- If this procedure is not completed within 1 minute after restarting engine at step 4, return to step 4.
- 7. If 1st trip DTC is displayed, check possible cause items.

## **Overall Function Check**

Use this procedure to check the overall function of the A/F sensor 1 circuit.

### **WITHOUT CONSULT-II**


- 1. Start engine and warm it up to normal operating temperature.
- 2. Turn ignition switch OFF, wait at least 10 seconds and then restart engine.
- 3. Drive and accelerate vehicle to more than 40 km/h (25 MPH) within 20 seconds after restarting engine.
- 4. Maintain the following conditions for about 20 consecutive seconds.

Engine speed	1,000 - 3,200 rpm
Vehicle speed	More than 40 km/h (25 MPH)
Shift lever	Suitable position
Driving location	Driving at level road (To avoid overloading will help maintain the driv- ing conditions required for this test.)


### NOTE:

- Keep the accelerator pedal as steady as possible during the cruising.
- If this procedure is not completed within 1 minute after restarting engine at step 2, return to step 2.
- 5. Repeat steps 2 to 4.
- 6. Stop the vehicle.
- 7. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- 8. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
- Make sure that no DTC is detected.
   If 1st trip DTC is detected, check possible cause items.

DATA MON	DATA MONITOR	
MONITOR	NO DTC	
ENG SPEED COOLAN TEMP/S A/F SEN1 (B1)	XXX rpm XXX °C XXX V	



TBWA0692E



## DTC P1272, P1282 A/F SENSOR 1

## **Component Description**

The A/F sensor is a planar dual-cell limit current sensor. The sensor element of the A/F sensor is the combination of a Nernst concentration cell (sensor cell) with an oxygen-pump cell, which transports ions. It has a heater in the element.

The sensor is capable of precise measurement  $\lambda = 1$ , but also in the lean and rich range. Together with its control electronics, the sensor outputs a clear, continuous signal throughout a wide  $\lambda$  range (0.7 <  $\lambda$  < air).

The exhaust gas components diffuse through the diffusion gap at the electrode of the oxygen pump and Nernst concentration cell, where they are brought to thermodynamic balance.

An electronic circuit controls the pump current through the oxygenpump cell so that the composition of the exhaust gas in the diffusion gap remains constant at  $\lambda = 1$ . Therefore, the A/F sensor is able to indicate air/fuel ratio by this pumping of current. In addition, a heater is integrated in the sensor to ensure the required operating temperature of 700 - 800°C (1,292 - 1,472°F).

## **CONSULT-II** Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CON	DITION	SPECIFICATION
A/F SEN1 (B1) A/F SEN1 (B2)	• Engine: After warming up	Maintaining engine speed at 2,000 rpm	Fluctuates around 1.5V

## **On Board Diagnosis Logic**

To judge the malfunction, the diagnosis checks that the A/F signal computed by ECM from the air fuel ratio (A/F) sensor 1 signal is not inordinately high.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible Cause	
P1272 1272 (Bank 1) P1282 1282 (Bank 2)	Air fuel ratio (A/F) sensor 1 circuit no activity detected	• The A/F signal computed by ECM from the A/F sensor 1 signal is constantly approx. 5V.	<ul> <li>Harness or connectors (The A/F sensor 1 circuit is open or shorted.)</li> <li>Air fuel ratio (A/F) sensor 1</li> </ul>	Μ

## **DTC Confirmation Procedure**

### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.


EC-144


## TESTING CONDITION:

### Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

### WITH CONSULT-II

- 1. Start engine and warm it up to normal operating temperature.
- 2. Select "A/F SEN1 (B1)" or "A/F SEN1 (B2)" in "DATA MONITOR" mode with CONSULT-II.





ABS00GY0

ABS00GXZ

K

PFP:22693

А

 Check "A/F SEN1 (B1)" or "A/F SEN1 (B2)" indication. If the indication is constantly approx. 5V, check possible cause items.
 If the indication is not constantly approx. 5V, as to payt stop

If the indication is not constantly approx. 5V, go to next step.

- 4. Turn ignition switch OFF, wait at least 10 seconds and then restart engine.
- 5. Drive and accelerate vehicle to more than 40 km/h (25 MPH) within 20 seconds after restarting engine.
- Maintain the following conditions for about 20 consecutive seconds.

ENG SPEED	1,000 - 3,200 rpm
VHCL SPEED SE	More than 40 km/h (25 MPH)
B/FUEL SCHDL	1.5 - 9.0 msec
Gear position	Suitable position

#### NOTE:

- Keep the accelerator pedal as steady as possible during the cruising.
- If this procedure is not completed within 1 minute after restarting engine at step 4, return to step 4.
- 7. If 1st trip DTC is detected, check possible cause items.

### **Overall Function Check**

Use this procedure to check the overall function of the A/F sensor 1 circuit.

#### **WITHOUT CONSULT-II**

- 1. Start engine and warm it up to normal operating temperature.
- 2. Turn ignition switch OFF, wait at least 10 seconds and then restart engine.
- 3. Drive and accelerate vehicle to more than 40 km/h (25 MPH) within 20 seconds after restarting engine.
- 4. Maintain the following conditions for about 20 consecutive seconds.


Engine speed	1,000 - 3,200 rpm		
Vehicle speed	More than 40 km/h (25 MPH)		
Shift lever	Suitable position		
Driving location	Driving at level road (To avoid overloading will help maintain the driv- ing conditions required for this test.)		

#### NOTE:

- Keep the accelerator pedal as steady as possible during the cruising.
- If this procedure is not completed within 1 minute after restarting engine at step 2, return to step 2.
- 5. Repeat steps 2 to 4.
- 6. Stop the vehicle.
- 7. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- 8. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
- Make sure that no DTC is detected.
   If 1st trip DTC is detected, check possible cause items.


DATA MONI	TOR
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
A/F SEN1 (B1)	XXX V

ABS00GY1



Revision: 2006 December

TBWA0692E



TBWA0693E

# DTC P1276, P1286 A/F SENSOR 1

### **Component Description**

The A/F sensor is a planar dual-cell limit current sensor. The sensor element of the A/F sensor is the combination of a Nernst concentration cell (sensor cell) with an oxygen-pump cell, which transports ions. It has a heater in the element.

The sensor is capable of precise measurement  $\lambda = 1$ , but also in the lean and rich range. Together with its control electronics, the sensor outputs a clear, continuous signal throughout a wide  $\lambda$  range (0.7 <  $\lambda < air$ ).

The exhaust gas components diffuse through the diffusion gap at the electrode of the oxygen pump and Nernst concentration cell, where they are brought to thermodynamic balance.

An electronic circuit controls the pump current through the oxygenpump cell so that the composition of the exhaust gas in the diffusion gap remains constant at  $\lambda = 1$ . Therefore, the A/F sensor is able to indicate air/fuel ratio by this pumping of current. In addition, a heater is integrated in the sensor to ensure the required operating temperature of 700 - 800°C (1,292 - 1,472°F).

# **CONSULT-II** Reference Value in Data Monitor Mode

Specification data are reference values.


MONITOR ITEM	CONDITION		SPECIFICATION
A/F SEN1 (B1) A/F SEN1 (B2)	• Engine: After warming up	Maintaining engine speed at 2,000 rpm	Fluctuates around 1.5V


# **On Board Diagnosis Logic**

To judge the malfunction, the diagnosis checks that the A/F signal computed by ECM from the air fuel ratio (A/F) sensor 1 signal fluctuates according to fuel feedback control.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible Cause	L
P1276 1276 (Bank 1)	Air fuel ratio (A/F) sensor 1	• The A/F signal computed by ECM from the A/	<ul> <li>Harness or connectors (The A/F sensor 1 circuit is open or</li> </ul>	M
P1286 1286 (Bank 2)	circuit high voltage	F sensor 1 signal is constantly approx. 1.5V.	shorted.) • Air fuel ratio (A/F) sensor 1	

**EC-148** 





ABS00GY7

K

PFP:22693

А

# **Overall Function Check**

Use this procedure to check the overall function of the A/F sensor 1 circuit.

#### B WITH CONSULT-II

- 1. Start engine and warm it up to normal operating temperature.
- 2. Select "A/F SEN1 (B1)" or "A/F SEN1 (B2)" in "DATA MONITOR" mode with CONSULT-II.
- Check "A/F SEN1 (B1)" or "A/F SEN1 (B2)" indication. If the indication is constantly approx. 1.5V and does not fluctuates, check possible cause items. If the indication fluctuates around 1.5V, go to next step.
- 4. Turn ignition switch OFF and wait at least 10 seconds.
- 5. Start engine and warm it up to normal operating temperature.
- 6. Select "DATA MONITOR" mode with CONSULT-II.
- 7. Drive the vehicle at a speed of 80 km/h (50 MPH) for a few minutes in the suitable shift position.
- Set D position, then release the accelerator pedal fully until the vehicle speed decreases to 50 km/h (30 MPH).
   NOTE:

Never apply brake during releasing the accelerator pedal.

- 9. Repeat steps 7 to 8 for five times.
- 10. Stop the vehicle and turn ignition switch OFF.
- 11. Wait at least 10 seconds and restart engine.
- 12. Repeat steps 7 to 8 for five times.
- Make sure that no DTC is detected. If 1st trip DTC is detected, check possible cause items.


#### **WITHOUT CONSULT-II**

- 1. Start engine and warm it up to normal operating temperature.
- 2. Drive the vehicle at a speed of 80 km/h (50 MPH) for a few minutes in the suitable shift position.
- Set D position, then release the accelerator pedal fully until the vehicle speed decreases to 50 km/h (30 MPH).

#### NOTE:


Never apply brake during releasing the accelerator pedal.

- 4. Repeat steps 2 to 3 for five times.
- 5. Stop the vehicle and turn ignition switch OFF.
- 6. Wait at least 10 seconds and restart engine.
- 7. Repeat steps 2 to 3 for five times.
- 8. Stop the vehicle.
- 9. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- 10. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
- Make sure that no DTC is detected.
   If 1st trip DTC is detected, check possible cause items.



Revision: 2006 December


TBWA0692E



# DTC P1564 ASCD STEERING SWITCH

# **Component Description**

ASCD steering switch has variant values of electrical resistance for each button. ECM reads voltage variation of switch, and determines which button is operated.



# **CONSULT-II** Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION	
		MAIN switch: Pressed	ON	G
MAIN SW	<ul> <li>Ignition switch: ON</li> </ul>	MAIN switch: Released	OFF	
CANCEL SW	a Impitian awitabu ON	CANCEL switch: Pressed	ON	_ H
CANCEL SW	<ul> <li>Ignition switch: ON</li> </ul>	CANCEL switch: Released	OFF	
RESUME/ACC SW	Ignition switch: ON	RESUME/ACCELERATE switch: Pressed	ON	
RESUME/ACC SW	• Ignition switch. ON	RESUME/ACCELERATE switch: Released	OFF	
SET SW	a Ignition quitable ON	SET/COAST switch: Pressed	ON	J
361 300	<ul> <li>Ignition switch: ON</li> </ul>	SET/COAST switch: Released	OFF	

# **On Board Diagnosis Logic**

This self-diagnosis has the one trip detection logic. The MIL will not light up for this diagnosis.

NOTE:

If DTC P1564 is displayed with DTC P0605, first perform the trouble diagnosis for DTC P0605. Refer to <u>EC-394</u>.

DTC No.	Trouble Diagnosis Name	DTC Detecting Condition	Possible Cause	N
P1564 1564	ASCD steering switch	<ul> <li>An excessively high voltage signal from the ASCD steering switch is sent to ECM.</li> <li>ECM detects that input signal from the ASCD steering switch is out of the specified range.</li> <li>ECM detects that the ASCD steering switch is stuck ON.</li> </ul>	<ul> <li>Harness or connectors (The switch circuit is open or shorted.)</li> <li>ASCD steering switch</li> <li>ECM</li> </ul>	

PFP:25551

А

ABS00GYD

ABS00GYE

Κ

F

### **DTC Confirmation Procedure**

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.


#### B WITH CONSULT-II

- 1. Turn ignition switch ON.
- 2. Select "DATA MONITOR" mode with CONSULT-II.
- 3. Wait at least 10 seconds.
- 4. Press MAIN switch for at least 10 seconds, then release it and wait at least 10 seconds.
- 5. Press CANCEL switch for at least 10 seconds, then release it and wait at least 10 seconds.
- 6. Press RESUME/ACCELERATE switch for at least 10 seconds, then release it and wait at least 10 seconds.
- 7. Press SET/COAST switch for at least 10 seconds, then release it and wait at least 10 seconds.
- 8. If DTC is detected, check possible cause items.

#### **WITHOUT CONSULT-II**

- 1. Turn ignition switch ON and wait at least 10 seconds.
- 2. Press MAIN switch for at least 10 seconds, then release it and wait at least 10 seconds.
- 3. Press CANCEL switch for at least 10 seconds, then release it and wait at least 10 seconds.
- 4. Press RESUME/ACCELERATE switch for at least 10 seconds, then release it and wait at least 10 seconds.
- 5. Press SET/COAST switch for at least 10 seconds, then release it and wait at least 10 seconds.
- 6. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- 7. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
- 8. If DTC is detected, check possible cause items.

ABS00GYF



TBWB0528E

# DTC P1572 ASCD BRAKE SWITCH

### **Component Description**

When the brake pedal is depressed, ASCD brake switch is turned OFF and stop lamp switch is turned ON. ECM detects the state of the brake pedal by this input of two kinds (ON/OFF signal).

# CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION	F
BRAKE SW1	- Ignition owitch: ON	Brake pedal: Fully released	ON	-
(ASCD brake switch)	<ul> <li>Ignition switch: ON</li> </ul>	Brake pedal: Slightly depressed	OFF	
BRAKE SW2	<ul> <li>Ignition switch: ON</li> </ul>	Brake pedal: Fully released	OFF	0
(Stop lamp switch)		Brake pedal: Slightly depressed	ON	_

# **On Board Diagnosis Logic**


This self-diagnosis has the one trip detection logic.

The MIL will not light up for this diagnosis.

NOTE:

- If DTC P1572 is displayed with DTC P0605, first perform the trouble diagnosis for DTC P0605. Refer to <u>EC-394</u>.
- This self-diagnosis has the one trip detection logic. When malfunction A is detected, DTC is not stored in ECM memory. And in that case, 1st trip DTC and 1st trip freeze frame data are displayed. 1st trip DTC is erased when ignition switch OFF. And even when malfunction A is detected in two consecutive trips, DTC is not stored in ECM memory.

DTC No.	Trouble Diagnosis Name		DTC Detecting Condition	Possible Cause
		A)	<ul> <li>When the vehicle speed is above 30 km/ h (19 MPH), ON signals from the stop lamp switch and the ASCD brake switch are sent to the ECM at the same time.</li> </ul>	<ul> <li>Harness or connectors (The stop lamp switch circuit is shorted.)</li> <li>Harness or connectors (The ASCD brake switch circuit is shorted.)</li> </ul>
P1572 1572	ASCD brake switch	B)	<ul> <li>ASCD brake switch signal is not sent to ECM for extremely long time while the vehicle is driving</li> </ul>	<ul> <li>Stop lamp switch</li> <li>ASCD brake switch</li> <li>Incorrect stop lamp switch installation</li> <li>Incorrect ASCD brake switch installation</li> <li>ECM</li> </ul>



PFP:25320

ABS00GYJ

А

F

ARSONGVK

ABSOOGYL

Κ

# **DTC Confirmation Procedure**

#### CAUTION:

#### Always drive vehicle at a safe speed.

NOTE:

- If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.
- Procedure for malfunction B is not described here. It takes extremely long time to complete procedure for malfunction B. By performing procedure for malfunction A, the incident that causes malfunction B can be detected.

#### B WITH CONSULT-II

#### **TESTING CONDITION:**

Steps 4 and 5 may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

- 1. Start engine (VDC switch OFF).
- 2. Select "DATA MONITOR" mode with CONSULT-II.
- Press MAIN switch and make sure that CRUISE indicator lights up.
- 4. Drive the vehicle for at least 5 consecutive seconds under the following condition.

VHCL SPEED SE	More than 30 km/h (19 MPH)
Selector lever	Suitable position

If 1st trip DTC is detected, check possible cause items. If 1st trip DTC is not detected, go to the following step.

<b></b>		
DATA MO	NITOR	
MONITOR	NO DTC	
ENG SPEED	XXX rpm	
VHCL SPEED SE	XXX km/h	
CRUISE LAMP	ON	
BRAKE SW 1	ON	
BRAKE SW 2	OFF	
		PBIB2386E

5. Drive the vehicle for at least 5 consecutive seconds under the following condition.

VHCL SPEED SE	More than 30 km/h (19 MPH)
Selector lever	Suitable position
Driving location	Depress the brake pedal for more than five seconds so as not to come off from the above-mentioned vehicle speed.

6. If 1st trip DTC is detected, check possible cause items.

# **Overall Function Check**


Use this procedure to check the overall function of the ASCD brake switch circuit. During this check, a 1st trip

# DTC might not be confirmed.

- 1. Turn ignition switch ON.
- 2. Check voltage between ECM terminal 108 (ASCD brake switch signal) and ground under the following conditions.

CONDITION	VOLTAGE
Brake pedal: Slightly depressed	Approximately 0V
Brake pedal: Fully released	Battery voltage

3. If NG, check possible cause items. If OK, go to next step.




ABS00GYN

# DTC P1572 ASCD BRAKE SWITCH

4. Check voltage between ECM terminal 101 (Stop lamp switch signal) and ground under the following conditions.

CONDITION	VOLTAGE
Brake pedal: Fully released	Approximately 0V
Brake pedal: Slightly depressed	Battery voltage

5. If NG, check possible cause items.



Н

I

J

Κ

L

Μ

Е

#### Wiring Diagram LHD MODELS

ABS00GYO

EC-ASC/BS-01 ■ : DETECTABLE LINE FOR DTC - : NON-DETECTABLE LINE FOR DTC IGNITION SWITCH ON OR START BATTERY FUSE BLOCK (J/B) Q REFER TO PG-POWER. 10A 12 10A 20 E101 • 1C 8C R/Y P R/Y P Π 1 STOP LAMP SWITCH ASCD BRAKE SWITCH DEPRESSED RELEASED E116 E115 RELEASED DEPRESSED 2 2 -R/G L/B R/G I/B 22 (E110) (E109) (M7) L/B (M6) R/G L/B R/G 108 101 BRAKE BNCSW ECM (M80) REFER TO THE FOLLOWING.  $\overbrace{\text{BOX}}^{\text{E101}} \text{-FUSE BLOCK-JUNCTION} \\ \underset{\text{BOX}}{\text{BOX}} (\text{J/B})$ 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 1 2 3 🗔 4 5 6 7 (M6) (M7) 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 8 9 10 11 12 13 14 15 16 GB ۱۸ 109 110 111 112 113 119 120 121 2 1 (E115) BR 98 99 100 101 102 103 104 105 做 12 E116 B 118 (M80) 117 H.S. 90 91 92 93 94 95 96 97 В 114 115 116 82 83 84 85 86 87 88 89 ٦L

TBWB0530E

#### DTC P1574 ASCD VEHICLE SPEED SENSOR

#### **Component Description**

The ECM receives two vehicle speed sensor signals via CAN communication line. One is sent from "unified meter and A/C amp.", and the other is from TCM (Transmission control module). The ECM uses these signals for ASCD control.

#### On Board Diagnosis Logic

#### This self-diagnosis has the one trip detection logic. The MIL will not light up for this diagnosis.

#### NOTE:

- If DTC P1574 is displayed with DTC U1000 or U1001, first perform the trouble diagnosis for DTC • U1000, U1001. Refer to EC-352, "DTC U1000, U1001 CAN COMMUNICATION LINE" .
- If DTC P1574 is displayed with DTC P0605, first perform the trouble diagnosis for DTC P0605. Refer to EC-394, "DTC P0605 ECM"

DTC No.	Trouble Diagnosis Name	DTC Detecting Condition	Possible Cause
P1574 1574	ASCD vehicle speed sensor	ECM detects a difference between two vehicle speed signals is out of the specified range.	<ul> <li>Harness or connectors (The CAN communication line is open or shorted.) (Refer to LAN-3, "Precautions When Using CONSULT-II")</li> <li>Unified meter and A/C amp. (Refer to <u>DI-31, "UNIFIED METER AND A/C AMP"</u>)</li> <li>ABS actuator and electric unit (control unit) (Refer to <u>BRC-5, "TROUBLE DIAGNOSIS"</u>)</li> <li>ABS actuator and electric unit (control unit) (Refer to <u>BRC-5, "TROUBLE DIAGNOSIS"</u>)</li> <li>Wheel sensor</li> <li>TCM (Refer to <u>CVT-23, "TROUBLE DIAGNOSIS"</u>)</li> <li>ECM</li> </ul>

### **DTC Confirmation Procedure**

#### **CAUTION:**

#### Always drive vehicle at a safe speed.

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### **TESTING CONDITION:**

Step 3 may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

#### (P) WITH CONSULT-II

- 1. Start engine (VDC switch OFF).
- 2. Select "DATA MONITOR" mode with CONSULT-II.
- 3. Drive the vehicle at more than 40 km/h (25 MPH).
- If DTC is detected, check possible cause items. 4.

DATA MON	NITOR
MONITOR	NO DTC
ENG SPEED VHCL SPEED SE	XXX rpm XXX km/h

PFP:31036

ABS00GYR

ABSOOGYS

ABS00GYT

# DTC P1574 ASCD VEHICLE SPEED SENSOR

# **WITHOUT CONSULT-II** А **TESTING CONDITION:** Step 2 may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle. EC 1. Start engine (VDC switch OFF). 2. Drive the vehicle at more than 40 km/h (25 MPH). 3. Turn ignition switch OFF, wait at least 10 seconds and then turn ON. С Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM. 4. If DTC is detected, check possible cause items. 5. D F F G Н I J Κ

L

Μ

# DTC P1700 CVT CONTROL SYSTEM

# Description

This DTC is displayed with other DTC regarding TCM. Perform the trouble diagnosis for displayed other DTC. Refer to <u>CVT-23, "TROUBLE DIAGNOSIS"</u>. When this DTC is detected, the ASCD control is canceled.

PFP:31036

ABS00GYV

# DTC P1706 PNP SWITCH

# **DTC P1706 PNP SWITCH**

### **Component Description**

When the gear position is P or N, park/neutral position (PNP) switch is ON. ECM detects the position because the continuity of the line (the ON signal) exists.

### **CONSULT-II Reference Value in Data Monitor Mode**

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION	
P/N POSI SW	<ul> <li>Ignition switch: ON</li> </ul>	Shift lever: P or N	ON	
F/N FOSI SW	• Ignition switch. ON	Shift lever: Except above	OFF	D

# On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
			Harness or connectors     [The park/neutral position (PNP) switch     circuit is open or shorted.]
		The signal of the park/neutral position (PNP)	<ul> <li>Park/neutral position (PNP) switch</li> </ul>
P1706 1706	Park/neutral position switch	switch is not changed in the process of engine starting and driving.	<ul> <li>Unified meter and A/C amp.</li> <li>(Refer to <u>LAN-3, "Precautions When</u> <u>Using CONSULT-II"</u>)</li> </ul>
			<ul> <li>TCM (Refer to <u>CVT-23, "TROUBLE DIAGNO-</u> <u>SIS"</u>)</li> </ul>

# **DTC Confirmation Procedure**

#### **CAUTION:**

#### Always drive vehicle at a safe speed.

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.


#### B WITH CONSULT-II

- 1. Turn ignition switch ON.
- Select "P/N POSI SW" in "DATA MONITOR" mode with CON-SULT-II. Then check the "P/N POSI SW" signal under the following conditions.

Position (Selector lever)	Known-good signal
P or N position	ON
Except above position	OFF

If NG, check possible cause items. If OK, go to following step.

- 3. Select "DATA MONITOR" mode with CONSULT-II.
- 4. Start engine and warm it up to normal operating temperature.



PFP:32006 ABSOOGYW

ABS00GYX

ABS00GYY

0

А

EC

-

Κ

ABS00H33

5. Maintain the following conditions for at least 60 consecutive seconds.

ENG SPEED	1,100 - 6,375 rpm
COOLAN TEMP/S	More than 70°C (158°F)
B/FUEL SCHDL	4.0 - 31.8 msec
VHCL SPEED SE	More than 64 km/h (40 MPH)
Selector lever	Suitable position

6. If 1st trip DTC is detected, check possible cause items.

# **Overall Function Check**

 DATA MONITOR

 MONITOR
 NO DTC

 ENG SPEED
 XXX rpm

 COOLAN TEMP/S
 XXX 'C

 VHCL SPEED SE
 XXX km/h

 P/N POSI SW
 OFF

 B/FUEL SCHDL
 XXX msec

ABS00GYZ


Use this procedure to check the overall function of the park/neutral position (PNP) switch circuit. During this check, a 1st trip DTC might not be confirmed.

### **WITHOUT CONSULT-II**


- 1. Turn ignition switch ON.
- 2. Check voltage between ECM terminal 102 (PNP switch signal) and ground under the following conditions.


Condition (Gear position)	Voltage V (Known-good data)
P or N position	Approx. 0
Except above position	BATTERY VOLTAGE (11 - 14V)


3. If NG, check possible cause items.



#### Wiring Diagram LHD MODELS







TBWA0385E

# DTC P1715 INPUT SPEED SENSOR (PRIMARY SPEED SENSOR)

#### DTC P1715 INPUT SPEED SENSOR (PRIMARY SPEED SENSOR) PFP:31935 А Description ABS00GZ2 ECM receives primary speed sensor signal from TCM through CAN communication line. EC **CONSULT-II** Reference Value in Data Monitor Mode ABS00GZ3 Specification data are reference values. MONITOR ITEM CONDITION SPECIFICATION Almost the same speed as the I/P PULLY SPD • Vehicle speed: More than 20 km/h (12MPH) tachometer indication On Board Diagnosis Logic ABS00GZ4 NOTE: If DTC P1715 is displayed with DTC U1000 or U1001 first perform the trouble diagnosis for DTC F U1000, U1001. Refer to EC-352. If DTC P1715 is displayed with DTC P0605, first perform the trouble diagnosis for DTC P0605. Refer to EC-394. F If DTC P1715 is displayed with DTC P0335, first perform the trouble diagnosis for DTC P0335. Refer to EC-381. If DTC P1715 is displayed with DTC P0340 or P0345, first perform the trouble diagnosis for DTC P0340, P0345. Refer to EC-385. The MIL will not light up for this diagnosis. Н DTC No. Trouble diagnosis name DTC detecting condition Possible cause Harness or connectors (The CAN communication line is open or shorted) (Refer to LAN-3, "Precautions When Using Primary speed sensor signal is different Input speed sensor CONSULT-II") P1715 from the theoretical value calculated by (Primary speed sensor) ECM from secondary speed sensor sig-1715 • Harness or connectors (TCM output) nal and engine rpm signal. (Primary speed sensor circuit is open or shorted) TCM K (Refer to CVT-23, "TROUBLE DIAGNOSIS") **DTC Confirmation Procedure** ABS00GZ5

#### CAUTION:


#### Always drive vehicle at a safe speed.

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at M least 10 seconds before conducting the next test.

#### B WITH CONSULT-II

- 1. Turn ignition switch ON.
- 2. Select "DATA MONITOR" mode with CONSULT-II.
- 3. Start engine.
- 4. Drive vehicle at a speed of more than 50 km/h (31 MPH) for at least 5 seconds.
- 5. If 1st trip DTC is detected, check possible cause items.



L

# **WITHOUT CONSULT-II**

- 1. Start engine.
- 2. Drive vehicle at a speed of more than 50 km/h (31 MPH) for at least 5 seconds.
- 3. Stop the vehicle.
- 4. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- 5. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
- 6. If 1st trip DTC is detected, check possible cause items.

# DTC P1720 VSS

# DTC P1720 VSS

#### Description

#### NOTE:

If DTC P1720 is displayed with DTC U1000 or U1001, first perform the trouble diagnosis for DTC U1000, U1001. Refer to <u>EC-352, "DTC U1000, U1001 CAN COMMUNICATION LINE"</u>.

ECM receives two vehicle speed signals via CAN communication line. One is sent from "ABS actuator and electric unit (control unit)" via "unified meter and A/C amp.", and the other is from TCM (Transmission control module). ECM uses these signals for engine control.

# **CONSULT-II Reference Value in Data Monitor Mode**

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
VHCL SPEED SE	• Turn drive wheels and compare CONSULT-II value with the speedometer indication.	Almost the same speed as the speedometer indication

# On Board Diagnosis Logic

The MIL will not light up for this self-diagnosis.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
			<ul> <li>Harness or connectors (Secondary speed sensor circuit is open or shorted)</li> </ul>
		Harness or connectors     (Wheel sensor circuit is	•
P1720	Vehicle speed sensor	A difference between two vehicle speed sig-	• TCM (Refer to <u>CVT-23, "TROUBLE DIAGNOSIS"</u> )
1720	720 (TCM output) nals is out of the specified range.	<ul> <li>Secondary speed sensor</li> <li>ABS actuator and electric unit (control unit) (Refer to <u>BRC-5</u>, "<u>TROUBLE DIAGNOSIS</u>" or <u>BRC-25</u>, "<u>TROUBLE DIAGNOSIS</u>")</li> </ul>	
			Wheel sensor
			<ul> <li>Unified meter and A/C amp. (Refer to <u>DI-31, "UNIFIED METER AND A/</u> <u>C AMP"</u>)</li> </ul>

### **DTC Confirmation Procedure**

#### **CAUTION:**


Always drive vehicle at a safe speed.

#### NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

### B WITH CONSULT-II

- 1. Turn ignition switch ON.
- 2. Select "DATA MONITOR" mode with CONSULT-II.
- 3. Start engine.
- 4. Drive vehicle at a speed of 20 km/h (12 MPH) or more for at least 5 seconds without brake pedal depressing.
- 5. If 1st trip DTC is detected, check possible cause items.



ABS00GZ7

EC

А

ABS00GZ8

ABS00GZ9

ABS00GZA

Μ

D

F

E

### **WITHOUT CONSULT-II**

- 1. Start engine.
- 2. Drive vehicle at a speed of 20 km/h (12 MPH) or more for at least 5 seconds without brake pedal depressing.
- 3. Stop the vehicle.
- 4. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- 5. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
- 6. If 1st trip DTC is detected, check possible cause items.

# DTC P1805 BRAKE SWITCH

# **DTC P1805 BRAKE SWITCH**

### Description

Brake switch signal is applied to the ECM through the stop lamp switch when the brake pedal is depressed. This signal is used mainly to decrease the engine speed when the vehicle is driving.

### **CONSULT-II Reference Value in Data Monitor Mode**

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION	
BRAKE SW	<ul> <li>Ignition switch: ON</li> </ul>	Brake pedal: Fully released	OFF	
	• Ignition switch. ON	Brake pedal: Slightly depressed	ON	

### On Board Diagnosis Logic

This self-diagnosis has the one trip detection logic.

Harness or connectors     (2ten large switch signality)		Possible cause	DTC detecting condition	Trouble diagnosis name	DTC No.
P1805       Brake switch       A brake switch signal is not sent to ECM for extremely long time while the vehicle is driving.       (Stop lamp switch circuit is open or shorted.)         • Stop lamp switch       • Stop lamp switch		(Stop lamp switch circuit is open or shorted.)	A brake switch signal is not sent to ECM for extremely long time while the vehicle is driving.	Brake switch	P1805 1805


### FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MIL light up.

Engine operating con	dition in fail-safe mode	
ECM controls the electric throttle control actuator by regulating the Therefore, acceleration will be poor.	e throttle opening to a small range.	
Vehicle condition	Driving condition	
When engine is idling	Normal	
When accelerating	Poor acceleration	J

#### DTC Confirmation Procedure WITH CONSULT-II

- 1. Turn ignition switch ON.
- 2. Fully depress the brake pedal for at least 5 seconds.
- 3. Erase the DTC with CONSULT-II.
- 4. Select "DATA MONITOR" mode with CONSULT-II.
- 5. If DTC is detected, check possible cause items.



#### **WITHOUT CONSULT-II**

- 1. Turn ignition switch ON.
- 2. Fully depress the brake pedal for at least 5 seconds.
- 3. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- 4. Erase the Diagnostic Test Mode II (Self-diagnostic results) memory.
- 5. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- 6. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.



ABSOOGZC

PFP:25320

ABSOOGZD

ABS00GZF

А

EC

F

Н

ABS00GZF

Κ

M

7. If DTC is detected, check possible cause items.

FUSE BLOCK (J/B)

> STOP LAMP SWITCH

(E116)

(E101)

BATTERY

Q

8C


RELEASED

10A 20

DEPRESSED

2

#### Wiring Diagram LHD MODELS











Н



M



TBWA0386E



R/G 101 BRAKE ECM M80

# DTC P2122, P2123 APP SENSOR

# **Component Description**

The accelerator pedal position sensor is installed on the upper end of the accelerator pedal assembly. The sensor detects the accelerator position and sends a signal to the ECM.

Accelerator pedal position sensor has two sensors. These sensors are a kind of potentiometers which transform the accelerator pedal position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the accelerator pedal and feed the voltage signals to the ECM. The ECM judges the current opening angle of the accelerator pedal from these signals and controls the throttle control motor based on these signals.

Idle position of the accelerator pedal is determined by the ECM

receiving the signal from the accelerator pedal position sensor. The ECM uses this signal for the engine operation such as fuel cut.

# **CONSULT-II Reference Value in Data Monitor Mode**

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION	
ACCEL SEN 1	Ignition switch: ON	Accelerator pedal: Fully released	0.5 - 1.0V	G
ACCEL SEN 2*	(Engine stopped)	Accelerator pedal: Fully depressed	4.2 - 4.8V	
CLSD THL POS	Ignition switch: ON	Accelerator pedal: Fully released	ON	H
	(Engine stopped)	Accelerator pedal: Slightly depressed	OFF	

\*: Accelerator pedal position sensor 2 signal is converted by ECM internally. Thus, it differ from ECM terminal voltage.

# **On Board Diagnosis Logic**

These self-diagnoses have the one trip detection logic.

#### NOTE:

If DTC P2122 or P2123 is displayed with DTC P1229, first perform the trouble diagnosis for DTC P1229. Refer to  $\underline{\text{EC-436}}$ .

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause	K
P2122 2122	Accelerator pedal posi- tion sensor 1 circuit low input	An excessively low voltage from the APP sensor 1 is sent to ECM.	Harness or connectors     (APP sensor 1 circuit is open or     shorted.)	L
P2123 2123	Accelerator pedal posi- tion sensor 1 circuit high input	An excessively high voltage from the APP sensor 1 is sent to ECM.	,	M

# FAIL-SAFE MODE


When the malfunction is detected, ECM enters fail-safe mode and the MIL lights up.

Engine operating condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.

The ECM regulates the opening speed of the throttle valve to be slower than the normal condition.

So, the acceleration will be poor.



ABSOOGZI

ABS00GZ.I

А

F

E

nair-sale mode and the MIL lig

### **DTC Confirmation Procedure**

#### NOTE:


If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### TESTING CONDITION:

#### Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

#### WITH CONSULT-II

- 1. Turn ignition switch ON.
- 2. Select "DATA MONITOR" mode with CONSULT-II.
- 3. Start engine and let it idle for 1 second.
- 4. If DTC is detected, check possible cause items.





### **WITHOUT CONSULT-II**

- 1. Start engine and let it idle for 1 second.
- 2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- 3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
- 4. If DTC is detected, check possible cause items.

ABS00GZM







TBWA0717E

EC-174

ABS00GZN

# DTC P2127, P2128 APP SENSOR

# **Component Description**

The accelerator pedal position sensor is installed on the upper end of the accelerator pedal assembly. The sensor detects the accelerator position and sends a signal to the ECM.

Accelerator pedal position sensor has two sensors. These sensors are a kind of potentiometers which transform the accelerator pedal position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the accelerator pedal and feed the voltage signals to the ECM. The ECM judges the current opening angle of the accelerator pedal from these signals and controls the throttle control motor based on these signals.

Idle position of the accelerator pedal is determined by the ECM

receiving the signal from the accelerator pedal position sensor. The ECM uses this signal for the engine operation such as fuel cut.

# **CONSULT-II Reference Value in Data Monitor Mode**

Specification data are reference values.

MONITOR ITEM	COI	NDITION	SPECIFICATION	0
ACCEL SEN 1	<ul> <li>Ignition switch: ON</li> </ul>	Accelerator pedal: Fully released	0.5 - 1.0V	G
ACCEL SEN 2*	(Engine stopped)	Accelerator pedal: Fully depressed	4.2 - 4.8V	_
CLSD THL POS	Ignition switch: ON     (Engine stopped)	Accelerator pedal: Fully released	ON	H
		Accelerator pedal: Slightly depressed	OFF	_

\*: Accelerator pedal position sensor 2 signal is converted by ECM internally. Thus, it differ from ECM terminal voltage.

# **On Board Diagnosis Logic**

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause	
P2127 2127	Accelerator pedal posi- tion sensor 2 circuit low input	An excessively low voltage from the APP sen- sor 2 is sent to ECM.	<ul> <li>Harness or connectors (APP sensor 2 circuit is open or shorted.)</li> </ul>	
P2128 2128	Accelerator pedal posi- tion sensor 2 circuit high input	An excessively high voltage from the APP sensor 2 is sent to ECM.	<ul> <li>(TP sensor circuit is shorted.)</li> <li>Accelerator pedal position sensor (APP sensor 2)</li> <li>Electric throttle control actuator (TP sensor 1 and 2)</li> </ul>	


# FAIL-SAFE MODE

When the malfunction is detected, ECM enters fail-safe mode and the MIL lights up.

Engine operating condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.

The ECM regulates the opening speed of the throttle valve to be slower than the normal condition. So, the acceleration will be poor.



ABS00GZS

А

F

E

### **DTC Confirmation Procedure**

#### NOTE:


If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### TESTING CONDITION:

#### Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

#### WITH CONSULT-II

- 1. Turn ignition switch ON.
- 2. Select "DATA MONITOR" mode with CONSULT-II.
- 3. Start engine and let it idle for 1 second.
- 4. If DTC is detected, check possible cause items.




### **WITHOUT CONSULT-II**

- 1. Start engine and let it idle for 1 second.
- 2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- 3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
- 4. If DTC is detected, check possible cause items.

ABS00GZU

Wiring Diagram



315426 M67 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 106 107 108 109 110 111 112 113 5 119 120 4 121 43 42 41 40 39 38 37 36 35 34 33 32 31 30 29 28 27 26 25 98 99 100 101 102 103 104 105 3 117 118 (M80) (F101) 62 61 60 59 58 54 53 52 51 50 49 48 47 46 45 44 90 91 92 93 94 95 96 97 57 56 55 В В 2 114 115 116 1 82 83 84 85 86 87 88 89 81 80 79 78 77 76 75 74 73 72 71 70 69 68 67 66 65 64 63 Ŀ ┓Ш┏ լ

TBWA0718E


EC-177

# DTC P2135 TP SENSOR

# **Component Description**

Electric throttle control actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has the two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.



# **CONSULT-II Reference Value in Data Monitor Mode**

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION	-
THRTL SEN 1 THRTL SEN 2*	Ignition switch: ON	Accelerator pedal: Fully released	More than 0.36V	_
	<ul><li>(Engine stopped)</li><li>Shift lever: D</li></ul>	Accelerator pedal: Fully depressed	Less than 4.75V	G

\*: Throttle position sensor 2 signal is converted by ECM internally. Thus, it differ from ECM terminal voltage signal.

# **On Board Diagnosis Logic**

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause	
P2135 2135	Throttle position sensor circuit range/perfor- mance problem	Rationally incorrect voltage is sent to ECM compared with the signals from TP sensor 1 and TP sensor 2.	<ul> <li>Harness or connector (TP sensor 1 and 2 circuit is open or shorted.) (APP sensor 2 circuit is shorted)</li> <li>Electric throttle control actuator (TP sensor 1 and 2)</li> <li>Accelerator pedal position sensor (APP sensor 2)</li> </ul>	J

#### FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MIL lights up.

Engine operation condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.

The ECM regulates the opening speed of the throttle valve to be slower than the normal condition.

So, the acceleration will be poor.

PFP:16119

ABS00GZZ

А

4B\$00H01

Н

Μ

ABS00H00

### **DTC Confirmation Procedure**

#### NOTE:


If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### TESTING CONDITION:

#### Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

#### WITH CONSULT-II

- 1. Turn ignition switch ON.
- 2. Select "DATA MONITOR" mode with CONSULT-II.
- 3. Start engine and let it idle for 1 second.
- 4. If DTC is detected, check possible cause items.




### **WITHOUT CONSULT-II**

- 1. Start engine and let it idle for 1 second.
- 2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- 3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
- 4. If DTC is detected, check possible cause items.

ABS00H02





43

3

1 2 12

62 61 60

81 80 79

76

**EC-180** 

(F101)

В

98 99

90 91 92

1100

105

93 94 95 96 97

82 83 84 85 86 87 88 89

117 118

114 115 116

(M80)

В

20 28 27 26

51 50 49 48 47 46 45 44

71 70 69 68 67 66 65 64 63

TBWA0715E

# DTC P2138 APP SENSOR

### **Component Description**

The accelerator pedal position sensor is installed on the upper end of the accelerator pedal assembly. The sensor detects the accelerator position and sends a signal to the ECM.

Accelerator pedal position sensor has two sensors. These sensors are a kind of potentiometers which transform the accelerator pedal position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the accelerator pedal and feed the voltage signals to the ECM. The ECM judges the current opening angle of the accelerator pedal from these signals and controls the throttle control motor based on these signals.

Idle position of the accelerator pedal is determined by the ECM

receiving the signal from the accelerator pedal position sensor. The ECM uses this signal for the engine operation such as fuel cut.

# **CONSULT-II Reference Value in Data Monitor Mode**

Specification data are reference values.

MONITOR ITEM	COM	NDITION	SPECIFICATION	
ACCEL SEN 1	Ignition switch: ON	Accelerator pedal: Fully released	0.5 - 1.0V	(
ACCEL SEN 2*	(Engine stopped)	Accelerator pedal: Fully depressed	4.2 - 4.8V	
CLSD THL POS	Ignition switch: ON	Accelerator pedal: Fully released	ON	ŀ
	(Engine stopped)	Accelerator pedal: Slightly depressed	OFF	

\*: Accelerator pedal position sensor 2 signal is converted by ECM internally. Thus, it differ from ECM terminal voltage.

# **On Board Diagnosis Logic**

This self-diagnosis has the one trip detection logic.

#### NOTE:

If DTC P2138 is displayed with DTC P1229, first perform the trouble diagnosis for DTC P1229. Refer to  $\underline{\text{EC-436}}$ .

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause	K
P2138 2138	Accelerator pedal posi- tion sensor circuit range/performance problem	Rationally incorrect voltage is sent to ECM compared with the signals from APP sensor 1 and APP sensor 2.	<ul> <li>Harness or connector (APP sensor 1 and 2 circuit is open or shorted.) (TP sensor circuit is shorted)</li> <li>Accelerator pedal position sensor (APP sensor 1 and 2)</li> <li>Electric throttle control actuator (TP sensor 1 and 2)</li> </ul>	L

#### FAIL-SAFE MODE

When the malfunction is detected, ECM enters fail-safe mode and the MIL lights up.


Engine operating condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.

EC-181

The ECM regulates the opening speed of the throttle valve to be slower than the normal condition.

So, the acceleration will be poor.



PFP:18002

ABS00H07

А

F

E

ABS00H08

ABSOOHOG

Z50

#### **DTC Confirmation Procedure**

#### NOTE:


If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

#### TESTING CONDITION:

#### Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

#### WITH CONSULT-II

- 1. Turn ignition switch ON.
- 2. Select "DATA MONITOR" mode with CONSULT-II.
- 3. Start engine and let it idle for 1 second.
- 4. If DTC is detected, check possible cause items.




#### **WITHOUT CONSULT-II**

- 1. Start engine and let it idle for 1 second.
- 2. Turn ignition switch OFF, wait at least 10 seconds and then turn ON.
- 3. Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM.
- 4. If DTC is detected, check possible cause items.

ABS00H0A






M

315426 M67 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 106 107 108 109 110 111 112 113 4 5 119 120 121 43 42 41 40 39 38 37 36 35 34 33 32 31 30 29 28 27 26 25 98 99 100 101 102 103 104 105 3 (F101) 117 118 (M80) 62 61 60 59 58 57 56 55 54 53 52 51 50 49 48 47 46 45 44 90 91 92 93 94 95 96 97 В В 2 114 115 116 1 82 83 84 85 86 87 88 89 81 80 79 78 77 76 75 74 73 72 71 70 69 68 67 66 65 64 63 լ ┓Ш┏ լ


TBWA0716E

#### **HO2S2 HEATER**



TBWB0615E


#### **HO2S2 HEATER**



TBWB0616E

#### IAT SENSOR Wiring Diagram LHD MODELS


ABSOOHOM **EC-IATSEN-01** EC ■ : DETECTABLE LINE FOR DTC - : NON-DETECTABLE LINE FOR DTC С MASS AIR FLOW SENSOR (INTAKE AIR TEMPERATURE SENSOR) D (F4) 5 Y/G 6 Ē Е F G Н 4 L J Κ Y/G 34 L 67 GND-A ΤA ECM Μ (F101)



TBWA0420E


PFP:22630

А




TBWB0615E

#### HO2S2




TBWB0616E

#### **IGNITION SIGNAL**




#### **IGNITION SIGNAL**




TBWA0388E

#### **IGNITION SIGNAL**




TBWA0389E

EC-191




TBWB0619E




TBWB0541E


#### **INJECTOR CIRCUIT**



EC-194





#### **ELECTRONIC CONTROLLED ENGINE MOUNT**



### **REFRIGERANT PRESSURE SENSOR**

# Wiring Diagram LHD MODELS





ABS00H1U

А

PFP:92136

# ASCD BRAKE SWITCH


Wiring Diagram LHD MODELS




ABS00H22

А

AB000122




#### ASCD INDICATOR



#### MIL AND DATA LINK CONNECTOR


#### MIL AND DATA LINK CONNECTOR PFP:24814 А Wiring Diagram LHD MODELS ABS00H29 EC-MIL/DL-01 EC IGNITION SWITCH ON OR START BATTERY FUSE BLOCK REFER TO PG-POWER. Ċ С Ż (J/B) 10A 10A 10A (M1), (M2) 19 21 14 : DETECTABLE LINE FOR DTC • - : NON-DETECTABLE LINE FOR DTC 4B A8 I 5A DATA LINE D . Y/R Y/R 0 F Y/R ō 21 20 F MALFUNCTION INDICATOR LAMP COMBINATION METER G (M25) UNIFIED METER CONTROL UNIT Н 22 24 19 18 23 R/B R/L R R R 9 19 UNIFIED TX (COMB RX (COMB METER AND A/C METER) METER) J AMP. CAN-H CAN-(M49) 11 F Κ TO LAN-CAN В В L 86 94 (M78) (M14) Μ CAN-H CAN-L ECM (M80) REFER TO THE FOLLOWING. (M1), (M2) -FUSE BLOCK-4 5 6 7 8 9 10 12 11 10 9 8 7 6543 2 1 12 3 (M49) JUNCTION BOX (J/B) (M25 11 12 13 14 15 16 17 18 19 20 24 23 22 21 20 19 18 17 16 15 14 13 GB 7 106 107 108 109 110 111 112 113 119 120 121 98 99 100 101 102 103 104 105 117 118 (M80) 90 91 92 93 94 95 96 97 B 114 115 116 82 83 84 85 86 87 88 89

#### EC-MIL/DL-02



TBWA0375E

# EC-MIL/DL-02



TBWB0791E

# SERVICE DATA AND SPECIFICATIONS (SDS)

	ID SPECIFICATIONS (SDS)		PFP:00030
Fuel Pressure			ABS00H2A
Fuel pressure at idling kPa (bar, kg/cm <sup>2</sup> , psi)       Approximately 350 (3.5, 3.57, 51)			
Idle Speed and Ign	ition Timing		ABS00H2E
Target idle speed	No load* (in P or N position)	$625\pm50~\text{rpm}$	
Air conditioner: ON	In P or N position	700 rpm or more	
Ignition timing	In P or N position	$15\pm5^\circ$ BTDC	
<ul> <li>*: Under the following conditions</li> <li>Air conditioner switch: OFF</li> <li>Electric load: OFF (Lights, he</li> <li>Steering wheel: Kept in straig</li> </ul>	eater fan & rear window defogger)		
Mass Air Flow Sen	sor		ABS00H2C
Supply voltage		Battery voltage (11 - 14V)	
Output voltage at idle		0.9 - 1.2*V	
*: Engine is warmed up to norma	al operating temperature and running under no	load.	
Intake Air Tempera	ture Sensor		ABS00H2D
Temperature °C (°F)		Resistance k $\Omega$	
25 (77)		1.800 - 2.200	
80 (176)		0.283 - 0.359	
Engine Coolant Ter	mperature Sensor		ABS00H2E
Engine Coolant Ter Temperature °C (°F)	mperature Sensor	Resistance kΩ	ABS00H2E
	mperature Sensor	Resistance kΩ 2.1 - 2.9	ABS00H2E
Temperature °C (°F)	mperature Sensor		ABSooH2E
Temperature °C (°F) 20 (68)	mperature Sensor	2.1 - 2.9	ABSooH2E
Temperature °C (°F)           20 (68)           50 (122)           90 (194)		2.1 - 2.9 0.68 - 1.00	ABSOOH2E
Temperature °C (°F)           20 (68)           50 (122)           90 (194)		2.1 - 2.9 0.68 - 1.00	
Temperature °C (°F)           20 (68)           50 (122)           90 (194)           Air Fuel Ratio (A/F)           Resistance [at 25°C (77°F)]	) Sensor 1 Heater	2.1 - 2.9 0.68 - 1.00 0.236 - 0.260	
Temperature °C (°F)           20 (68)           50 (122)           90 (194)           Air Fuel Ratio (A/F)           Resistance [at 25°C (77°F)]	) Sensor 1 Heater	2.1 - 2.9 0.68 - 1.00 0.236 - 0.260	ABSooH2F
20 (68) 50 (122) 90 (194) Air Fuel Ratio (A/F) Resistance [at 25°C (77°F)] Heated Oxygen Set	) Sensor 1 Heater nsor 2 Heater	2.1 - 2.9         0.68 - 1.00         0.236 - 0.260         2.3 - 4.3Ω	ABSooH2F
Temperature °C (°F)           20 (68)           50 (122)           90 (194)           Air Fuel Ratio (A/F)           Resistance [at 25°C (77°F)]           Heated Oxygen Set           Resistance [at 25°C (77°F)]	) Sensor 1 Heater nsor 2 Heater	2.1 - 2.9         0.68 - 1.00         0.236 - 0.260         2.3 - 4.3Ω	ABS00H2F ABS00H2G
Temperature °C (°F)           20 (68)           50 (122)           90 (194)           Air Fuel Ratio (A/F)           Resistance [at 25°C (77°F)]           Heated Oxygen Set           Resistance [at 25°C (77°F)]           Throttle Control Mo           Resistance [at 25°C (77°F)]	) Sensor 1 Heater nsor 2 Heater	2.1 - 2.9         0.68 - 1.00         0.236 - 0.260         2.3 - 4.3Ω         5.0 - 7.0Ω	ABS00H2F ABS00H2G
Temperature °C (°F)         20 (68)         50 (122)         90 (194)         Air Fuel Ratio (A/F)         Resistance [at 25°C (77°F)]         Heated Oxygen Set         Resistance [at 25°C (77°F)]         Throttle Control Mode	) Sensor 1 Heater	2.1 - 2.9         0.68 - 1.00         0.236 - 0.260         2.3 - 4.3Ω         5.0 - 7.0Ω	ABS00H2G ABS00H2G ABS00H2J
Temperature °C (°F)         20 (68)         50 (122)         90 (194)         Air Fuel Ratio (A/F)         Resistance [at 25°C (77°F)]         Heated Oxygen Set         Resistance [at 25°C (77°F)]         Throttle Control Mo         Resistance [at 25°C (77°F)]         Injector	) Sensor 1 Heater	2.1 - 2.9 0.68 - 1.00 0.236 - 0.260 2.3 - 4.3Ω 5.0 - 7.0Ω Approximately 1 - 15Ω	ABS00H2G ABS00H2G ABS00H2J