

Engine Relay Box			
Relay Number	Details	Loads	Schematic
R3	35A 1 Contact BR	Side Lamp	
R4	35A 1 Contact BR	Horn	
R5	30A 2 Contact YL	Wiper	
R6	30A 2 Contact YL		
RA	40A 1 Contact BK	Double Relay (1304)	
RB	30A 1 Contact BK		