





The diagram illustrates the electrical connections for the IBCM (Intelligent Battery Control Module). Key components and their connections include:

- DAY LIGHT LH and DAY LIGHT RH:** Connected to GPE4 and GPE6 terminals.
- SSB (Signal Switching Board):** Connected to INST terminals (PI, SBAL, SSBG).
- INST (Instrument Cluster):** Receives signals from the SSB and provides outputs to the FRONT and MFB (IFB) sections.
- FRONT:** Contains terminals for GPE4, GPE6, and XFTI1 (INTER CONN1 TO INST).
- IBCM (Intelligent Battery Control Module):** The central unit with multiple pins (J1, J3, J4) connected to various sensors and actuators.
- MFB (IFB) (Main Fuel Injection Board):** Contains terminals for GPT, ACCR, ACIG, ACC, IG1R, IG1, BCMD, F50B, MBM, MNBM, BCM1, BCM2, F50C, and ACIG, connected to various actuators and sensors.
- BATTERY RA00:** Connected to the F50B R terminal.
- GROUND POINTS:** Connected to GPT and GPT2 terminals.


SHAHIN.AT DAY LIGHT








کانکتور بی سی ام
J1



کانکتور چراغ روز




کانکتور بی سی ام
J4




کانکتور دسته سیم اصلی به دسته سیم داشبورد 1
XFTI1




کانکتور کلید استارت استپ




کانکتور بی سی ام
J1



کانکتور بی سی ام
J3




کانکتور چراغ جلو




کانکتور کلید فلاشر



کانکتور بی سی ام
J4




کانکتور برق اصلی به دسته سیم داشبورد



کانکتور راهنما



کانکتور دسته سیم اصلی به دسته سیم داشبورد 1
XFTI1



کانکتور دسته سیم اصلی به دسته سیم داشبورد 2
XFTI2

دیجیتال خودرو
digital khodro