



S2 HEAD LIGHT LOW


The diagram illustrates the wiring for the S2 Head Light Low system. It shows the connections between the INST (Instrument) panel, IBCM (Interconnect Box), MFB (IFB) (Main Fuse Block), BFB (Beam Fuse Block), and FR.LH 2610 (Front Left Headlight). The INST panel has terminals for PT, SBAL, G, SBGL, R, SSBG, W, LWBS, and J2. The IBCM has terminals J1, J3, and J4. The MFB (IFB) has terminals for GPT, ACCR, ACIG, ACC, IG1R, IG1, BCM1, BCM2, and F50B. The BFB has terminals for LBLR, ALRL, F50A, and F50B. The FR.LH 2610 has terminals for FRLB, GPE4, and GPE3. The diagram also shows the connections for the BATTERY FUSE BOX 1 and BATTERY FUSE BOX 2, and the LEVELING SWITCH 2639.

S2 HEAD LIGHT LOW







کانکتور بی سی ام
J1




کانکتور کلید استارت استپ




کانکتور مجموعه دسته راهنما 2




کانکتور مجموعه دسته راهنما 1




کانکتور بی سی ام
J2




کانکتور بی سی ام
J1




کانکتور بی سی ام
J3




کانکتور چراغ جلو




کانکتور بی سی ام
J4




کانکتور لولینگ تنظیم چراغ جلو




کانکتور بی سی ام
J4



کانکتور برق اصلی به دسته سیم داشبورد





کانکتور کلید لولینگ تنظیم چراغ جلو




کانکتور دسته سیم اصلی به دسته سیم داشبورد 1
XFT11



کانکتور دسته سیم اصلی به دسته سیم داشبورد 2
XFT12





دیجیتال خودرو
digital khodro